

Montana Tech Library

**Digital Commons @ Montana Tech**

---

Silver Bow Creek/Butte Area Superfund Site

Montana Superfund

---

Summer 8-2021

**SILVER BOW CREEK/BUTTE AREA NPL SITE BUTTE PRIORITY  
SOILS OPERABLE UNIT**

Pioneer Technical Services, Inc.

Follow this and additional works at: [https://digitalcommons.mtech.edu/superfund\\_silverbowbutte](https://digitalcommons.mtech.edu/superfund_silverbowbutte)



Part of the [Environmental Health and Protection Commons](#), [Environmental Indicators and Impact Assessment Commons](#), and the [Environmental Monitoring Commons](#)

---

**Josh Bryson**  
Liability Manager

317 Anaconda Road  
Butte MT 59701  
Direct (406) 782-9964  
Fax (406) 782-9980

August 3, 2021

Nikia Greene  
Remedial Project Manager  
US EPA – Montana Office  
Baucus Federal Building  
10 West 15th Street, Suite 3200  
Helena, Montana 59626

Erin Agee  
Senior Assistant Regional Counsel  
US EPA Region 8 Office of Regional Counsel  
CERCLA Enforcement Section  
1595 Wynkoop Street  
Denver, CO 80202  
Mail Code: 8ORC-C

Daryl Reed  
DEQ Project Officer  
P.O. Box 200901  
Helena, Montana 59620-0901

Jonathan Morgan, Esq.  
DEQ, Legal Counsel  
P.O. Box 200901  
Helena, Montana 59620-0901

**RE: Butte Reduction Works (BRW) Smelter Area Mine Waste Remediation and Contaminated Groundwater Hydraulic Control Site Field Sampling Plan for Microbial Analysis and Biotreatability Study**

Agency Representatives:

I am writing you on behalf of Atlantic Richfield Company to submit the *Draft Final Butte Reduction Works (BRW) Smelter Area Mine Waste Remediation and Contaminated Groundwater Hydraulic Control Site Field Sampling Plan for Microbial Analysis and Biotreatability* (BRW Biotreatability Study FSP) for your review and approval. In short, the BRW Biotreatability Study FSP provides the sampling and analytical procedures and protocols necessary to conduct a bench-scale biotreatability study, including microbial analysis, as part of the overall remedial design effort for the BRW Site. The main data quality objective for this work, additional solid material characterization, is described in the BRW Phase III Quality Assurance Project Plan. Fieldwork will begin once Agency approval has been received. A proposed schedule is included in the BRW Biotreatability Study FSP.

The report may be downloaded at the following link:

[https://pioneertechnicalservices.sharepoint.com/:f/s/submitted/Elc3To\\_Jyh1MscrXuMddJu0B1YJ5RNhK2zhY4K\\_-W7kAeQ](https://pioneertechnicalservices.sharepoint.com/:f/s/submitted/Elc3To_Jyh1MscrXuMddJu0B1YJ5RNhK2zhY4K_-W7kAeQ)

# Atlantic Richfield Company

**Josh Bryson**  
Liability Manager

317 Anaconda Road  
Butte MT 59701  
Direct (406) 782-9964  
Fax (406) 782-9980

If you have any questions or comments, please call me at (406) 723-1834.

Sincerely,



Josh Bryson, PE, PMP  
Liability Manager  
Remediation Management Services Company  
An affiliate of **Atlantic Richfield Company**

Cc: Patricia Gallery / Atlantic Richfield - email  
Chris Greco / Atlantic Richfield – email  
Mike Mc Anulty / Atlantic Richfield - email  
Loren Burmeister / Atlantic Richfield – email  
Dave Griffis / Atlantic Richfield - email  
Jean Martin / Atlantic Richfield - email  
Irene Montero / Atlantic Richfield - email  
David A. Gratson / Environmental Standards / email  
Mave Gasaway / DGS - email  
John Davis / PRR - email  
Joe Vranka / EPA - email  
David Shanight / CDM - email  
Curt Coover / CDM - email  
James Freeman / DOJ - email  
John Sither / DOJ - email  
Jenny Chambers / DEQ - email  
Dave Bowers / DEQ - email  
Carolina Balliew / DEQ - email  
Matthew Dorrington / DEQ - email  
Jim Ford / NRDP - email  
Ray Vinkey / NRDP - email  
Harley Harris / NRDP - email  
Katherine Hausrath / NRDP - email  
Meranda Flugge / NRDP - email  
Ted Duaine / MBMG - email  
Gary Icopini / MBMG - email  
Becky Summerville / MR - email  
Kristen Stevens / UP - email

Robert Bylsma / UP - email  
John Gilmour / Kelley Drye - email  
Leo Berry / BNSF - email  
Robert Lowry / BNSF - email  
Brooke Kuhl / BNSF – email  
Mark Engdahl / BNSF - email  
Jeremie Maehr / Kennedy Jenks - email  
Annika Silverman / Kennedy Jenks - email  
Matthew Mavrinac / RARUS - email  
Harrison Roughton / RARUS - email  
Brad Gordon / RARUS - email  
Mark Neary / BSB - email  
Eric Hassler / BSB - email  
Julia Crain / BSB - email  
Chad Anderson / BSB - email  
Brandon Warner / BSB – email  
Abigail Peltomaa / BSB - email  
Eileen Joyce / BSB – email  
Sean Peterson/BSB – email  
Gordon Hart / BSB – email  
Jeremy Grotbo / BSB – email  
Josh Vincent / WET - email  
Craig Deeney / TREC - email  
Scott Bradshaw / TREC - email  
Brad Archibald / Pioneer - email  
Pat Sampson / Pioneer - email  
Mike Borduin / Pioneer - email  
Joe McElroy / Pioneer – email  
Andy Dare / Pioneer – email  
Karen Helfrich / Pioneer - email  
Leesla Jonart / Pioneer - email  
Connie Logan/ Pioneer – email  
Ian Magruder/ CTEC- email  
CTEC of Butte / email  
Scott Juskiewicz / Montana Tech – email

File: MiningSharePoint@bp.com - email  
BPSOU SharePoint - upload

---

**SILVER BOW CREEK/BUTTE AREA NPL SITE  
BUTTE PRIORITY SOILS OPERABLE UNIT**

---

***2021***

***Draft Final***

***Butte Reduction Works (BRW) Smelter Area Mine  
Waste Remediation and Contaminated Groundwater  
Hydraulic Control Site  
Field Sampling Plan for Microbial Analysis and  
Biotreatability Study***

***Atlantic Richfield Company***

**Revision 0. August 2021**

---

**SILVER BOW CREEK/BUTTE AREA NPL SITE  
BUTTE PRIORITY SOILS OPERABLE UNIT**

---

***2021***

***Draft Final***

***Butte Reduction Works (BRW) Smelter Area Mine  
Waste Remediation and Contaminated Groundwater  
Hydraulic Control Site  
Field Sampling Plan for Microbial Analysis and  
Biotreatability Study***

Prepared for:

***Atlantic Richfield Company***  
317 Anaconda Road  
Butte, Montana 59701

Prepared by:

***Pioneer Technical Services, Inc.***  
1101 S. Montana Street  
Butte, Montana 59701

**Revision 0. August 2021**

# APPROVAL PAGE

## Silver Bow Creek/Butte Area NPL Site Butte Reduction Works Smelter Area Mine Waste Remediation and Contaminated Field Sampling Plan for Microbial Analysis and Biotreatability Study

Approved: \_\_\_\_\_ Date: \_\_\_\_\_  
Nikia Greene, Site Project Manager, EPA, Region 8

Approved: \_\_\_\_\_ Date: \_\_\_\_\_  
Daryl Reed, Project Officer, Montana DEQ

Approved: \_\_\_\_\_ Date: \_\_\_\_\_  
Josh Bryson, Liability Manager  
Atlantic Richfield Company

Approved: \_\_\_\_\_ Date: \_\_\_\_\_  
David Gratson, Quality Assurance Manager  
Environmental Standards, Inc.

Plan is effective on date of approval.

### DOCUMENT REVISION TRACKING TABLE

Revision No.	Author	Version	Description	Date
Rev 0	K. Helfrich	Draft Final	Issued for Agency Approval	08/03/2021

## DISTRIBUTION LIST

### Silver Bow Creek/Butte Area NPL Site Butte Reduction Works Smelter Area Mine Waste Remediation and Contaminated Groundwater Hydraulic Control Site Field Sampling Plan for Microbial Analysis and Biotreatability Study

<b>Key Personnel Recipients</b>	<b>Title</b>	<b>Organization</b>	<b>Telephone Number</b>	<b>E-mail Address</b>
Nikia Greene	Remedial Project Manager	EPA	(406) 457-5019	<a href="mailto:Nikia.Greene@epa.gov">Nikia.Greene@epa.gov</a>
Erin Agee	Legal Counsel	EPA	(303) 312-6374	<a href="mailto:Erin.Agee@epa.gov">Erin.Agee@epa.gov</a>
Daryl Reed	State Project Officer	DEQ	(406) 444-6433	<a href="mailto:dreed@mt.gov">dreed@mt.gov</a>
Jonathan Morgan	Legal Counsel	DEQ	(406) 444-6589	<a href="mailto:JMorgan3@mt.gov">JMorgan3@mt.gov</a>
Josh Bryson	Liability Manager	Atlantic Richfield	(406) 782-9964	<a href="mailto:josh.bryson@bp.com">josh.bryson@bp.com</a>
Irene Montero	Senior Technologist - RET Lead	Atlantic Richfield	(713) 538-0875	<a href="mailto:irene.montero@bp.com">irene.montero@bp.com</a>
David Gratson	Atlantic Richfield Quality Assurance Manager	Environmental Standards	(505)-660-8521	<a href="mailto:dgratson@envstd.com">dgratson@envstd.com</a>
David Shanight	EPA Contractor	CDM Smith	(406) 441-1400	<a href="mailto:ShanightDT@cdmsmith.com">ShanightDT@cdmsmith.com</a>
Eric Hassler	Director, Department of Reclamation and Environmental Services	Butte-Silver Bow	(406) 497-5042	<a href="mailto:ehassler@bsb.mt.gov">ehassler@bsb.mt.gov</a>
Julia Crain	Assistant Director, Department of Reclamation and Environmental Services / Quality Assurance Manager	Butte-Silver Bow	(406) 497-6264	<a href="mailto:jcrain@bsb.mt.gov">jcrain@bsb.mt.gov</a>
Abigail Peltomaa	Manager, Data Management Division/Quality Assurance Officer	Butte-Silver Bow	(406) 497-5045	<a href="mailto:apeltoaa@bsb.mt.gov">apeltoaa@bsb.mt.gov</a>
Chad Anderson	Manager, Human Health/RMAP Division	Butte-Silver Bow	(406) 497-6278	<a href="mailto:canderson@bsb.mt.gov">canderson@bsb.mt.gov</a>
Brandon Warner	Manager, Environmental Division	Butte-Silver Bow	(406) 497-5022	<a href="mailto:bwarn@bsb.mt.gov">bwarn@bsb.mt.gov</a>
Jeremy Grotbo	GIS Data Specialist	Butte-Silver Bow	(406) 497-6261	<a href="mailto:jgrotbo@bsb.mt.gov">jgrotbo@bsb.mt.gov</a>
Pat Sampson	Atlantic Richfield Contractor – Project Oversight	Pioneer Technical Services, Inc.	(406) 490-0706	<a href="mailto:psampson@pioneer-technical.com">psampson@pioneer-technical.com</a>



<b>For Information Only Recipients</b>	<b>Organization</b>	<b>E-mail Address</b>
Joe Vranka	EPA	<a href="mailto:vranka.joe@epa.gov">vranka.joe@epa.gov</a>
Jean Martin	Atlantic Richfield	<a href="mailto:jean.martin@bp.com">jean.martin@bp.com</a>
John Davis	Poore, Roth and Robinson	<a href="mailto:jpd@prrlaw.com">jpd@prrlaw.com</a>
Mave Gasaway	Davis, Graham & Stubbs, LLP	<a href="mailto:Mave.Gasaway@dgslaw.com">Mave.Gasaway@dgslaw.com</a>
Patricia Gallery	Atlantic Richfield	<a href="mailto:patricia.gallery@bp.com">patricia.gallery@bp.com</a>
Loren Burmeister	Atlantic Richfield	<a href="mailto:loren.burmeister@bp.com">loren.burmeister@bp.com</a>
Irene Montero	Atlantic Richfield	<a href="mailto:irene.montero@bp.com">irene.montero@bp.com</a>
Chris Greco	Atlantic Richfield	<a href="mailto:chris.greco@bp.com">chris.greco@bp.com</a>
Dave Griffis	Atlantic Richfield	<a href="mailto:dave.griffis@bp.com">dave.griffis@bp.com</a>
Curt Coover	CDM	<a href="mailto:CooverCA@cdmsmith.com">CooverCA@cdmsmith.com</a>
James Freeman	DOJ	<a href="mailto:james.freeman2@usdoj.gov">james.freeman2@usdoj.gov</a>
John Sither	DOJ	<a href="mailto:john.sither@usdoj.gov">john.sither@usdoj.gov</a>
Jenny Chambers	DEQ	<a href="mailto:jchambers@mt.gov">jchambers@mt.gov</a>
Dave Bowers	DEQ	<a href="mailto:dbowers@mt.gov">dbowers@mt.gov</a>
Carolina Balliew	DEQ	<a href="mailto:carolina.balliew@mt.gov">carolina.balliew@mt.gov</a>
Matthew Dorrington	DEQ	<a href="mailto:Matthew.Dorrington@mt.gov">Matthew.Dorrington@mt.gov</a>
John Gilmour	KelleyDrye	<a href="mailto:jgilmour@kelleydrye.com">jgilmour@kelleydrye.com</a>
Jim Ford	NRDP	<a href="mailto:jford@mt.gov">jford@mt.gov</a>
Ray Vinkey	NRDP	<a href="mailto:Ray.Vinkey@mt.gov">Ray.Vinkey@mt.gov</a>
Harley Harris	NRDP	<a href="mailto:harleyharris@mt.gov">harleyharris@mt.gov</a>
Katherine Hausrath	NRDP	<a href="mailto:KHausrath@mt.gov">KHausrath@mt.gov</a>
Meranda Flugge	NRDP	<a href="mailto:Meranda.Flugge@mt.gov">Meranda.Flugge@mt.gov</a>
Ted Duaine	MBMG	<a href="mailto:TDuaine@mtech.edu">TDuaine@mtech.edu</a>
Gary Icopini	MBMG	<a href="mailto:gicopini@mtech.edu">gicopini@mtech.edu</a>
Robert Bylsma	Union Pacific	<a href="mailto:rbylsma@up.com">rbylsma@up.com</a>
Kristen Stevens	Union Pacific	<a href="mailto:kmstevens@up.com">kmstevens@up.com</a>
Leo Berry	BNSF	<a href="mailto:leo@bkbh.com">leo@bkbh.com</a>
Robert Lowry	BNSF	<a href="mailto:rlowry@kelrun.com">rlowry@kelrun.com</a>
Brooke Kuhl	BNSF	<a href="mailto:brooke.kuhl@bnsf.com">brooke.kuhl@bnsf.com</a>
Mark Engdahl	BNSF	<a href="mailto:Mark.Engdahl@BNSF.com">Mark.Engdahl@BNSF.com</a>
Jeremie Maehr	Kennedy/Jenks	<a href="mailto:jeremiemaehr@kennedyjenks.com">jeremiemaehr@kennedyjenks.com</a>
Annika Silverman	Kennedy/Jenks	<a href="mailto:annikasilverman@kennedyjenks.com">annikasilverman@kennedyjenks.com</a>
Matthew Mavrinac	RARUS	<a href="mailto:Matthew.Mavrinac@patriotrail.com">Matthew.Mavrinac@patriotrail.com</a>
Harrison Roughton	RARUS	<a href="mailto:harrison.roughton@patriotrail.com">harrison.roughton@patriotrail.com</a>
Brad Gordon	RARUS	<a href="mailto:Brad.Gordon@Patriotrail.com">Brad.Gordon@Patriotrail.com</a>
Becky Summerville	MR	<a href="mailto:bsummerville@mtresourcesinc.com">bsummerville@mtresourcesinc.com</a>
Mark Neary	BSB	<a href="mailto:mneary@bsb.mt.gov">mneary@bsb.mt.gov</a>
Jeremy Grotbo	BSB	<a href="mailto:jgrotbo@bsb.mt.gov">jgrotbo@bsb.mt.gov</a>
Eileen Joyce	BSB	<a href="mailto:ejoyce@bsb.mt.gov">ejoyce@bsb.mt.gov</a>
Sean Peterson	BSB	<a href="mailto:speterson@bsb.mt.gov">speterson@bsb.mt.gov</a>
Gordon Hart	BSB	<a href="mailto:gordonhart@paulhastings.com">gordonhart@paulhastings.com</a>
Josh Vincent	WET	<a href="mailto:jvincent@waterenvtech.com">jvincent@waterenvtech.com</a>
Craig Deeney	TREC	<a href="mailto:cdeeney@woodardcurran.com">cdeeney@woodardcurran.com</a>
Scott Bradshaw	TREC	<a href="mailto:sbradshaw@woodardcurran.com">sbradshaw@woodardcurran.com</a>
Brad Archibald	Pioneer Technical Services, Inc.	<a href="mailto:barchibald@pioneer-technical.com">barchibald@pioneer-technical.com</a>
Joe McElroy	Pioneer Technical Services, Inc.	<a href="mailto:jmcelroy@pioneer-technical.com">jmcelroy@pioneer-technical.com</a>
Mike Borduin	Pioneer Technical Services, Inc.	<a href="mailto:mborduin@pioneer-technical.com">mborduin@pioneer-technical.com</a>

<b>For Information Only Recipients</b>	<b>Organization</b>	<b>E-mail Address</b>
Andy Dare	Pioneer Technical Services, Inc.	<a href="mailto:adare@pioneer-technical.com">adare@pioneer-technical.com</a>
Karen Helfrich	Pioneer Technical Services, Inc.	<a href="mailto:khelfrich@pioneer-technical.com">khelfrich@pioneer-technical.com</a>
Leesla Jonart	Pioneer Technical Services, Inc.	<a href="mailto:ljonart@pioneer-technical.com">ljonart@pioneer-technical.com</a>
Connie Logan	Pioneer Technical Services, Inc.	<a href="mailto:clogan@pioneer-technical.com">clogan@pioneer-technical.com</a>
Ian Magruder	Citizen's Environmental Technical Committee	<a href="mailto:imagruder@wwcengineering.com">imagruder@wwcengineering.com</a>
CTEC of Butte	Citizen's Environmental Technical Committee	<a href="mailto:BUTTECTEC@hotmail.com">BUTTECTEC@hotmail.com</a>
Montana Tech Library	Montana Tech	<a href="mailto:sjuskiewicz@mtech.edu">sjuskiewicz@mtech.edu</a>
Mining SharePoint	Atlantic Richfield	<a href="mailto:MiningSharePoint@bp.com">MiningSharePoint@bp.com</a>

## TABLE OF CONTENTS

<b>APPROVAL PAGE .....</b>	<b>I</b>
<b>DOCUMENT REVISION TRACKING TABLE .....</b>	<b>I</b>
<b>DISTRIBUTION LIST.....</b>	<b>I</b>
<b>TABLE OF CONTENTS .....</b>	<b>I</b>
<b>LIST OF FIGURES .....</b>	<b>II</b>
<b>LIST OF TABLES .....</b>	<b>II</b>
<b>LIST OF APPENDICES .....</b>	<b>II</b>
<b>ACRONYMS.....</b>	<b>III</b>
<b>1.0 INTRODUCTION.....</b>	<b>1</b>
<b>2.0 SITE BACKGROUND.....</b>	<b>1</b>
<b>3.0 SAMPLING OBJECTIVES.....</b>	<b>2</b>
<b>4.0 SAMPLING PROCESS AND DESIGN .....</b>	<b>3</b>
4.1 Preparation for Fieldwork.....	3
4.1.1 Training.....	3
4.1.2 Property Access .....	4
4.1.3 Utility Locates.....	4
4.2 Sample Location and Frequency.....	4
4.3 Sample Designation .....	4
4.4 Sampling Equipment and Procedures .....	5
4.4.1 Equipment.....	5
4.4.2 Procedures.....	6
4.4.3 Standard Operating Procedures.....	9
4.4.4 Field Documentation.....	10
4.5 Sample Handling and Analysis.....	12
4.5.1 Documentation and Shipping.....	12
4.5.2 Chain of Custody .....	12
4.5.3 Laboratory Analysis Methods.....	13
4.5.4 Quality Assurance/Quality Control Samples .....	16
<b>5.0 QUALITY ASSURANCE/QUALITY CONTROL .....</b>	<b>19</b>
5.1 Data Verification and Validation Requirements.....	19

**6.0 ADDITIONAL PROJECT DETAILS ..... 21**  
**7.0 REFERENCES..... 22**

**LIST OF FIGURES**

- Figure 1. Site Location Map
- Figure 2. Site Map
- Figure 3. Proposed Sample Areas for Biotreatability Test Pits
- Figure 4. Project Organizational Chart

**LIST OF TABLES**

- Table 1. Schedule
- Table 2. Sample Location Information
- Table 3. Sample Collection, Preservation, and Holding Times
- Table 4. Limit of Detection for XRF
- Table 5. Applicable and Relevant Standard Operating Procedures

**LIST OF APPENDICES**

- Appendix A. Standard Operating Procedures
- Appendix B. Field Forms and Tables
- Appendix C. Data Validation Checklists

## ACRONYMS

<b>Acronym</b>	<b>Definition</b>	<b>Acronym</b>	<b>Definition</b>
<b>%R</b>	Percent Recovery	<b>Pace</b>	Pace Analytical Services, LLC
<b>°C</b>	Degree Celsius	<b>PCB</b>	Polychlorinated Biphenyl
<b>AECOM</b>	AECOM Technical Services, Inc.	<b>PCP</b>	Pentachlorophenol
<b>Atlantic Richfield</b>	Atlantic Richfield Company	<b>pH</b>	Potential Hydrogen
<b>ATP</b>	Adenosine Triphosphate	<b>PID</b>	Photoionization Detector
<b>BNSF</b>	Burlington Northern Santa Fe Railway	<b>Pioneer</b>	Pioneer Technical Services, Inc.
<b>BOD</b>	Biological Oxygen Demand	<b>PPE</b>	Personal Protective Equipment
<b>BPSOU</b>	Butte Priority Soils Operable Unit	<b>Provectus</b>	Provectus Environmental Products
<b>BRW</b>	Butte Reduction Works	<b>QA</b>	Quality Assurance
<b>BSB</b>	Butte-Silver Bow	<b>QAO</b>	Quality Assurance Officer
<b>CECRA</b>	Comprehensive Environmental Cleanup and Responsibility Act	<b>QAPP</b>	Quality Assurance Project Plan
<b>CD</b>	Consent Decree	<b>QC</b>	Quality Control
<b>COC</b>	Contaminant of Concern	<b>RCRA</b>	Resource Conservation and Recovery Act
<b>CPM</b>	Contractor Project Manager	<b>RPD</b>	Relative Percent Difference
<b>DO</b>	Dissolved Oxygen	<b>S1VM</b>	Stage 1 Validation Manual
<b>DQO</b>	Data Quality Objective		
<b>EDD</b>	Electronic Data Deliverable	<b>S2AVEM</b>	Stage 2A Validation Electronic and Manual
<b>EPA</b>	Environmental Protection Agency	<b>SC</b>	Specific Conductance
<b>eV</b>	electron volt	<b>SIO2</b>	Silicon Dioxide
<b>FSP</b>	Field Sampling Plan	<b>SOP</b>	Standard Operating Procedure
<b>GPS</b>	Global Positioning System	<b>SRM</b>	Standard Reference Material
<b>LCS</b>	Laboratory Control Sample	<b>SSHASP</b>	Site-Specific Health and Safety Plan
<b>LCSD</b>	Laboratory Control Sample Duplicate	<b>T</b>	Duplicate Identification for Field Samples
<b>LDS</b>	Laboratory Duplicate Sample	<b>TPH</b>	Total Petroleum Hydrocarbons
<b>MB</b>	Method Blank	<b>USCS</b>	Unified Soil Classification System
<b>MS</b>	Matrix Spike	<b>USGS</b>	US Geological Survey
<b>MSD</b>	Matrix Spike Duplicate	<b>VOC</b>	Volatile Organic Compound
<b>ORP</b>	Oxidation Reduction Potential	<b>VPH</b>	Volatile Petroleum Hydrocarbon
<b>OUR</b>	Oxygen Uptake Rate	<b>XRF</b>	X-Ray Fluorescence

## 1.0 INTRODUCTION

This Butte Reduction Works (BRW) Field Sampling Plan (FSP) for Microbial Analysis and Biotreatability Study (BRW Biotreatability Study FSP) provides the sampling and analytical procedures and protocols necessary to conduct a bench-scale biotreatability study, including microbial analysis, as a part of the overall remedial design effort for the BRW Smelter Area Mine Waste Remediation and Contaminated Groundwater Hydraulic Control Site (Site). To detail the sampling and analytical procedures and methodologies for this work, this document includes the following information, as generally required in the U.S. Environmental Protection Agency (EPA) *Remedial Design/Remedial Action Handbook, EPA 540/R- 95/059* (EPA, 1995):

1. Site Background (Section 2.0).
2. Sampling Objectives (Section 3.0).
3. Sample Process and Design (Section 4.0).
  - Sample Location and Frequency (Section 4.2).
  - Sample Designation (Section 4.3).
  - Sampling Equipment and Procedures (Section 4.4).
  - Sample Handling and Analysis (Section 4.5).
4. Quality Assurance/Quality Control (Section 5.0).

The main data quality objective (DQO) for this work, additional solid material characterization, is described in the *BRW Phase III Quality Assurance Project Plan (QAPP)* (Atlantic Richfield, 2021a), referred to herein as BRW Phase III QAPP.

## 2.0 SITE BACKGROUND

The Site is in Butte, Montana, covers approximately 24 acres, and is located immediately west of Montana Street between Silver Bow Creek and the Burlington Northern Santa Fe (BNSF) Railway line (Figure 1 and Figure 2).

Beginning in 1885 to the time of this writing, the Site has been the location of multiple industrial operations including a copper smelter and a zinc concentrator, and it was also used by the Domestic Manganese and Development Company (Sanborn, 1943) and Rocky Mountain Phosphates, Inc. (GCM Services, Inc., 1991). This complex history of activities has resulted in a complex distribution of materials within the Site (including slag, tailings, manganese waste, demolition debris, foundations, and other historic structures) as well as impacted soil and groundwater (Atlantic Richfield, 2021b). Currently, Butte-Silver Bow (BSB) uses the Site to store materials.

The Site is also adjacent to other impacted areas. To the south and west of the Site, the Montana Pole and Treating Plant Site (Figure 2) treats extracted groundwater impacted by nearly 40 years of uncontrolled releases of a solution of approximately 5% pentachlorophenol (PCP) mixed with a petroleum carrier oil that was used to preserve poles, posts, and bridge timbers from 1946 to 1984 (EPA, 2017). NorthWestern Energy has a storage yard and operating center immediately south of the Site (Figure 2). The storage yard has been there since 1899 and is a Comprehensive

Environmental Cleanup and Responsibility Act (CECRA) site. Underground storage tanks and on-site use or disposal of various substances such as paints, solvents, mercury, Fuller's earth, wood-treating compounds, and transformer oil containing polychlorinated biphenyls (PCBs) have resulted in on-site soil contamination and possibly localized groundwater contamination at the NorthWestern Energy storage yard (DEQ, 2002).

As a result of the multiple industrial operations within and adjacent to the Site, there is a potential that there are areas within the Site where the soil and/or groundwater are impacted with organic pollutants (i.e., hydrocarbon compounds, PCP, PCBs, and dioxins) in addition to the contaminants of concern (COCs) identified in the *Consent Decree for The Butte Priority Soils Operable Unit Partial Remedial Design/Remedial Action and Operation and Maintenance* (BPSOU CD) (EPA, 2020) (i.e., arsenic, cadmium, copper, lead, mercury, and zinc). Based on previous Site investigations, it appears that the primary organic pollutant of concern is hydrocarbon compounds (Atlantic Richfield, 2021b).

As required by the BPSOU CD (EPA, 2020), soil and groundwater impacted with organic pollutants within the Site above Site-specific action levels must be properly managed in a manner that is consistent with the remedy. Soil within the preliminary waste removal corridor that is impacted with organic pollutants above Site-specific action levels must be segregated and disposed of appropriately. Soil outside the preliminary waste removal corridor that is impacted with organic pollutants above Site-specific action levels must be managed in a manner that is consistent with the Applicable or Relevant and Appropriate Requirements (ARARs) identified in the *Draft Final Preliminary 30% Remedial Design Report for the Butte Reduction Works (BRW) Smelter Area* (Atlantic Richfield, 2021c).

To help determine appropriate Site-specific action levels and define the proper management plan for soil impacted with organic pollutants, additional information is needed on the characteristics of the soil, specifically on the soil's leachability and microbial activity and biological degradation potential for hydrocarbon compounds within the soil. One of the concerns is that the microbial communities within the soil may be impacted by the elevated concentrations of COCs within the soil that may limit the hydrocarbon-compound biodegradation process. The bench-scale biotreatability study will include collecting samples from five locations within the Site with varying soil conditions that include hydrocarbon-compounds and COC concentrations and submitting the samples for laboratory analyses to help estimate the biological degradation potential for the impacted soil.

### **3.0 SAMPLING OBJECTIVES**

The main DQO for this work, additional solid material characterization, is identified in the BRW Phase III QAPP. The specific objectives of the microbial analysis and bench-scale biotreatability study are to collect additional data regarding the soil characteristics (e.g., COC concentrations, hydrocarbon-compound concentrations, nutrients, microbial populations, etc.) to help estimate the biological degradation potential for the hydrocarbon-impacted soil, help determine if high COC concentrations are impacting the microbial communities within the soil and possibly inhibiting the biodegradation process, help determine whether there are other reduced species (e.g., iron, manganese, organic carbon) in the soil sample that would consume the oxidant agent

where *in-situ* chemical oxidation is not practicable as a treatment option, and subsequently help determine the proper management plan for hydrocarbon-impacted soil within the Site.

## **4.0 SAMPLING PROCESS AND DESIGN**

The bench-scale biotreatability study, including microbial analysis, will include sampling and lab analysis that may consist of up to four parts: an initial characterization of soil, a total oxidant demand analysis, an initial soil slurry analysis, and possibly an enhanced slurry analysis. Composite soil samples will be collected from test pits from the anticipated depths and soil conditions (i.e., soil type, hydrocarbon-compound concentrations, and/or COC concentrations) (Table 2). The samples will be thoroughly mixed per standard operating procedure (SOP) SOP-S-06 (Appendix A) to ensure homogenized, aliquot split samples. Split samples will be sent to Pace Analytical Services, LLC (Pace) for the initial characterization analysis, to Provectus Environmental Products (Provectus) for the total oxidant demand analysis, and to AECOM Technical Services, Inc. (AECOM) to complete the soil slurry analyses. The following subsections provide the procedures and protocols necessary to complete these tasks. The project schedule is included as Table 1.

### **4.1 Preparation for Fieldwork**

The following tasks will be completed prior to conducting field activities.

#### **4.1.1 Training**

All field personnel will have a current certification for the 40-hour Occupational Safety and Health Administration Hazardous Waste Site and Emergency Response Training. Current certification records will be maintained at Pioneer Technical Services, Inc. (Pioneer) headquarters at 1101 S. Montana Street in Butte, Montana.

In a project meeting held prior to fieldwork, all field personnel will review this BRW Biotreatability Study FSP and the BRW Phase III QAPP and receive any specified training. Field personnel will review sampling and monitoring procedures and requirements prior to field activities to ensure collecting and handling methods are completed according to the BRW Biotreatability Study FSP requirements. Field personnel will be trained in how to properly use field equipment and complete activities according to field data collection SOPs in Appendix A.

The Field Team Leader will review the internal BRW Site-Specific Health and Safety Plan (SSHASP) with all field personnel prior to fieldwork to assess the Site's specific hazards and the control measurements put in place to mitigate these hazards. The BRW SSHASP review will cover all other safety aspects related to the Site including personnel responsibilities and contact information, additional safety requirements and procedures, and the emergency response plan.

The Field Team Leader will be responsible for training field personnel on how to calibrate field measurement instruments. The Field Team Leader will be experienced in the use and calibration of the equipment that will be used and responsible for training and overseeing the support staff. One hard copy of the current approved version of the BRW Phase III QAPP and this BRW



Biotreatability Study FSP will be maintained for reference purposes in the field vehicle and/or field office. All field team personnel will have access to electronic PDF format files of all documents pertaining to fieldwork.

#### **4.1.2 Property Access**

As Atlantic Richfield Company (Atlantic Richfield) owns the property where the field activities will be performed, there are no property access tasks to be completed.

#### **4.1.3 Utility Locates**

Utility locates will be performed prior to any fieldwork and will follow BP Remediation Management Defined Procedures for ground disturbance in addition to applicable control measures addressed in the internal BRW SSHASP. Final utility locates for the work area will be completed by the performing authority prior to any ground disturbance activities. There is a possibility that investigation points could shift once underground utilities are located throughout the Site.

### **4.2 Sample Location and Frequency**

To help determine appropriate Site-specific action levels and define the proper management plan for soil impacted with organic pollutants (both within and outside the waste removal corridor), additional information is needed on the characteristics of the soil, specifically on the soil's leachability and microbial activity and biological degradation potential for hydrocarbon compounds within the soil.

It is anticipated that five test pits will be excavated at the approximate locations shown on Figure 3 and described in Table 2. These locations were selected to provide a range of soil types and COC and hydrocarbon compound concentrations within the Site based on data collected from the Phase I Site Investigation (Atlantic Richfield, 2021b). The anticipated soil type, general concentrations, and justification for each sample location and depth are described in Table 2.

The final number and locations of test pits will be determined by the Field Team Leader and Contractor Project Manager (CPM) in consultation with the Contractor Quality Assurance Officer (QAO). Considerations that will impact the decision on sampling locations include location of utilities, infrastructure and land use in the area due to ongoing BSB operations, safety concerns, and equipment access.

### **4.3 Sample Designation**

A sample number system will be used to uniquely identify the project site, the sample medium, and the specific sample location and depth interval. The sample identification number will be derived from the test pit number with the Site name followed by the sample interval enclosed in parentheses followed by the date. For example, a sample designated BRW21-TP75(1.5-3.2)-10072021 describes a sample from test pit BRW21-TP75 taken from a depth of 1.5-3.2 feet below existing grade on October 7, 2021. All measurements will be decimal feet. There will be

no blank spaces permitted in the identification. The following is an example of the sample numbering system:

<b><u>Sample Number:</u></b>	<b><u>BRW21-TP75(1.5-3.2)-10072021</u></b>
<u>Location/Year:</u>	“BRW21” - BRW project area, collected in 2021.
<u>Type:</u>	“TP” - Test Pit
<u>Location/Number:</u>	“75” - Sample Location (corresponds with Test Pit ID No.). All sample locations will be plotted on the sampling maps.
<u>Depth Interval:</u>	“(1.5-3.2)” (upper limit-lower limit in feet).
<u>Date:</u>	“10072021” - sample collected on October 7, 2021.

For field duplicates, the depth interval will be replaced by “(T).” For example, a duplicate of BRW21-TP75(1.5-3.2)-10072021 would be BRW21-TP75(T)-10072021. Field duplicate samples will be recorded in the log or logbook, and the primary sample will be clearly indicated.

## 4.4 Sampling Equipment and Procedures

### 4.4.1 Equipment

Equipment used will include, but is not limited to, the following:

- Field logbook and pens.
- Field forms and references (Appendix B).
- Unified Soil Classification System (USCS) chart (ASTM D-2488) (Appendix B).
- Munsell color chart (Munsell, 2009).
- Measuring tape/wheel.
- X-ray fluorescence (XRF) field unit – Niton™ XL# Analyzer (XL3).
- Sieve.
- Portable heater or oven.
- Two photoionization detectors (PIDs) - 9.8 electron volt (eV) and 10.6 eV lamps with humidity filter.
- Hanby Total Petroleum Hydrocarbon (TPH) Soil Kit.
- Digital camera and/or digital video camera.
- Sharpshooter shovels and spoons or disposable sampling spoons.
- Sample containers and labels.
- Chain of custody forms.
- Coolers.
- Decontamination equipment (pressure washer, tap water, dilute nitric acid, liquinox soap, decontamination containers, paper towels, scrub brushes, and spray bottles) (refer to SOP-DE-02 in Appendix A).
- Personal Protective Equipment (PPE).
- Resource-grade Global Positioning System (GPS) unit.

Field equipment will be examined by the Field Team Leader or field team members to verify that it is in proper operating order prior to use. Equipment, instruments, tools, and other items

requiring preventive maintenance will be serviced and/or calibrated in accordance with the manufacturer's specified recommendations, as necessary. Field equipment will be cleaned (decontaminated) and safely stored between each use. Any routine maintenance recommended by the equipment manufacturer will also be performed and documented in field logbooks. Calibration of field equipment will be completed in the field at the beginning of each day and recorded in the field logbooks. Any equipment deficiencies or malfunctions during fieldwork will be recorded as appropriate in the field logbooks. The SOPs for the field equipment are in Appendix A.

All supplies and consumables received for the project (e.g., sampling equipment, calibration standards, etc.) will be checked to ensure their condition is satisfactory, such as free of defects that would affect performance. The types of supplies and consumables needed to complete sampling activities are described in the relevant field SOPs (Appendix A). Inspections of field supplies will be performed by the Field Team Leader or field team members.

#### **4.4.2 Procedures**

Excavation of test pits will follow the general procedures in SOP-S-06 (Appendix A). Specific to this investigation, certain modifications to the SOP are described in this section.

##### **4.4.2.1 Test Pit Excavation**

Test pits will be excavated using the appropriate excavating equipment capable of collecting samples up to a maximum depth of 15 feet. During excavation of the test pit, the following limits will be observed:

- Test pits will be excavated using a track-mounted or rubber-tired excavator capable of excavating to a maximum depth of 15 feet. The type of excavation equipment used (e.g., excavator model number, bucket type, teeth type, etc.) as well as any modifications to the equipment (e.g., hydraulic modifications, counterweights, boom extensions, bucket thumbs, attachments, etc.) will be documented.
- Test pits will be excavated until the anticipated depth is reached, until the equipment hits refusal (i.e., cannot excavate through material), to the limits of the equipment (i.e., 15 feet), or other site-specific limitations are encountered (e.g., sidewall stability becomes insufficient, etc.). The final depth of the test pit will ultimately be determined by the Field Team Leader and CPM in consultation with the Contractor QAO based on field conditions and results from previous investigations.
- Excavated materials will be stockpiled a minimum of 3 feet from the edge of the excavation.
- From the ground surface to a depth of 4 feet, 1 wall of the test pit will be prepared for evaluation if the desired sample interval does not exceed 4 feet. The test pit should have 1 vertical smooth wall for evaluation and 1 sloping or stepped wall for egress into and out of the test pit. Field personnel may only enter the test pit if a competent person (as identified in the corresponding Task Risk Assessment) has examined the test pit and determined it is safe to enter.

- No personnel will be permitted access to test pits deeper than 4 feet during performance of this work.
- If the depth of the test pit is greater than 6 feet, field personnel must maintain a 6-foot horizontal distance from the edge of the test pit unless they are wearing a safety harness anchored to the excavator bucket.
- Indicators of test pit stability will be documented in the corresponding Task Risk Assessment to establish protocols to cease excavation and safely backfill if a test becomes or appears to become unstable.
- Dewatering of test pits will not be conducted due to the considerations of impacted groundwater.

#### **4.4.2.2 Logging**

The classification and lithology of the test pit sidewalls will be logged, and the areas photographed and/or videoed. This will include a soil log of the test pit sidewall that lists USCS classification (Appendix B); visual estimate of rock content (2-inch plus fraction); color (as per Munsell color chart [Munsell, 2009]); depth to top and bottom of each lithological unit; presence or absence of soil staining, odors, nodules, organic matter, and/or groundwater; and bedrock depth (if encountered). All relevant observations will be recorded in a bound field logbook and on the forms included in Appendix B.

#### **4.4.2.3 PID Screening Analysis**

During excavation of the test pit, visual observations (sight and/or smell) and two PIDs (9.8 eV and 10.6 eV lamps) will be used to identify sources of hydrocarbons. A slow sweeping motion will be used to detect petroleum compounds with the PIDs. The PIDs will be used to screen the soils within the test pit immediately after excavation (if it is safe to enter the pit) or the PIDs will be used to screen the soils immediately after they are excavated. If it has been determined that volatile petroleum hydrocarbons (VPHs) might be present, a combustible gas meter will be used to monitor the atmosphere for hazardous conditions. The combustible gas meter will be mounted on or near the excavator to monitor conditions near the test pit. If hazardous conditions are present, appropriate action will be taken by safety personnel.

#### **4.4.2.4 Sampling and Analysis Procedures**

Because the objective of this work is to gather data for soil with a range of hydrocarbon-compound and COC concentrations, field screening tools will be used to verify the soil conditions assumed from previous investigations. For each test pit, once the anticipated depth is reached the Field Team Leader will visually inspect the soil to determine if the anticipated lithological layer and soil type are present (Table 2).

If the anticipated lithological layer and soil type are not present, the Field Team Leader and CPM in consultation with the Contractor QAO will determine the appropriate action, which may include excavating another test pit within the same area. If the anticipated lithological layer and

soil type are present, samples will be collected for field screening following the general procedures below:

- Use two PIDs, one with a 9.8 eV lamp and another with a 10.6 eV lamp, to screen for any petroleum compounds via the headspace method. The procedures for using the PID units are summarized below, and additional detail is included in applicable user manuals. It is anticipated that a MiniRae 3000 unit and a UltraRAE 3000+ unit will be used, or equivalent. The MiniRae 3000 unit has a 10.6 eV lamp and can detect volatile organic compounds (VOCs) with ionization potentials below 10.6 eV (i.e., most VOCs) with a detection range of 0 to 15,000 parts per million (ppm). The UltraRAE 3000+ unit has a 9.8 eV lamp and can detect VOCs with ionization potentials below 9.8 eV (e.g., benzene), with a detection range of 50 parts per billion (ppb) to 200 ppm for benzene.
  - Once the anticipated soil conditions are verified, a laboratory sample will be immediately collected for hydrocarbon compounds (Table 3) in the appropriate sample containers (i.e., two 4-ounce amber glass containers and one 8-ounce amber glass container). Additionally, the field team will immediately collect a sample in a ziplock bag with air space at the top above the sample (headspace) to allow testing using the headspace screening method.
  - For the headspace screening method, the sample is brought to room temperature, the sample is mixed or shaken depending on soil type to allow the contaminants to volatilize, and then the PID probe is inserted into the bag and the headspace concentration is measured and recorded.
- Use a Hanby TPH Soil Kit (or similar test kit as determined by field personnel) to screen for hydrocarbon compounds. The detection limit for the Hanby TPH Soil Kit ranges from 1 ppm to 1,000 ppm. The general procedures for using the field test kit are summarized below and additional detail is included in the user manual accompanying the test kit:
  - Weigh 5 grams of soil sample to be analyzed.
  - Place sample into beaker.
  - Add solvent to sample in beaker.
  - Stir or mix sample and solvent to form an extract.
  - Pour extract into test tube.
  - Add catalyst to test tube.
  - Shake test tube.
  - Compare test tube to color ID chart to determine presence of TPHs.

If another field test kit is used, the user manual for that unit will be followed.

- Use field XRF analyses as a guide to screen the soil for COC concentrations. The detection limits for the XRF are included in Table 4.
  - For the XRF analysis, use a Niton™ XL3 XRF Analyzer (XL3) and follow the procedures outlined in SOP-SFM-02 (Appendix A) as well as the XL3 user manual to ensure that the techniques employed are appropriate for the analytes of interest.

- Collect samples in a ziplock bag and mix the soil.
- Dry the samples if conditions require it and deemed necessary by field personnel. If a portable heater or oven is used to dry samples, the sample will be dried while maintaining a temperature that does not exceed the boiling point of water (100 degrees Celsius [°C]).

Once field screening has been completed and the results confirm the anticipated soil conditions (i.e., soil type, hydrocarbon-compound concentrations, and/or COC concentrations) are present, a sample will be collected from the anticipated depth and soil conditions specified in Table 2. If the anticipated soil conditions are not present, the Field Team Leader and CPM in consultation with the Contractor QAO will determine the appropriate action, which may include excavating another test pit within the same area.

Samples will be collected in accordance with the general procedures in SOP-S-06 (Appendix A). Samples will be collected using a disposable hand scoop or decontaminated shovel by scraping soil from the sidewall or collecting it from the appropriate excavated piles or from the excavator bucket. An appropriate sample volume will be collected to provide enough material for each required analysis (Table 3). Any large and/or coarse fragments greater than 0.5 inches will be removed from the sample.

No water samples will be collected for laboratory analysis; however, the potential hydrogen (pH), specific conductance (SC), oxidation reduction potential (ORP), and dissolved oxygen (DO) of groundwater that enters the pit will be tested, if feasible. All field water sampling results will be recorded in the field logbook. The field team will record the information on the Test Pit Log form provided in Appendix B. The field team will also record the resource-grade GPS coordinates of all test pits.

#### **4.4.3 Standard Operating Procedures**

This document references Pioneer SOPs for activities that outline specific procedures to safely complete tasks involved in the biotreatability study. The SOPs applicable to the work are referenced in the appropriate sections throughout this report, are listed in Table 5, and included in Appendix A.

Depending on circumstances and needs, it may not be possible or appropriate to follow the SOPs exactly in all situations due to Site conditions, equipment limitations, and SOP limitations. When necessary to perform an activity that does not have a specific SOP, or when the SOP cannot be followed, existing SOPs may be used as a general guidance or similar SOPs (not listed in this report) may be adopted if they meet the project DQO. All modifications or adoptions will be approved by the Field Team Leader, CPM, and Contractor QAO and documented in the field logbook and/or the final project report, as appropriate.

#### **4.4.4 Field Documentation**

##### **4.4.4.1 Field Logbook**

To provide a permanent record of all field activities, field personnel will document all activities in a bound field logbook (refer to field SOPs in Appendix A). This will include a description of conditions during sampling activities. When field logbooks are used, each logbook will have a unique document control number, be bound, and have consecutively numbered pages. All entries will be in waterproof ink, and any mistakes will be lined out with a single line and initialed by the person making the correction. Whenever a sample is collected or a measurement is made, a detailed description of the sample location and any additional observations will be recorded. The GPS coordinates will be recorded when appropriate. Individual field team members may be responsible for required documentation based on specific tasks assigned by the Field Team Leader or CPM.

All significant observations, measurements, relevant data, and results will be clearly documented in the data log or the field logbook. At a minimum, the following will be recorded:

- A description of the field task.
- Time and date fieldwork started.
- Location and description of the work area including sketches if possible, map references, and references to photographs and/or videos collected.
- Names and titles of field personnel.
- Name, address, and phone number of any field contacts or Site visitors (e.g., Agency representatives, auditors, etc.).
- Meteorological conditions at the beginning of fieldwork and any ensuing changes in the weather conditions.
- Details of the fieldwork performed and the field data sheets used.
- All field measurements made.
- Any field analysis results.
- Personnel and equipment decontamination procedures.
- Deviations from the BRW Phase III QAPP or applicable field SOPs (Appendix A).

For each test pit the following entries will be made:

- Lithologic log of the test pit indicating material types, from and to depths, rock content, color, presence of water, etc.
- Depth intervals from the ground surface for each soil horizon and total depth of the test pit.

- Photograph or video of each test pit with a staff gage or tape measure for scale to document existing conditions. Include Site name ID in photograph or video using a white board or note pad.
- Abnormal occurrences, deviations from the BRW Phase III QAPP or this BRW Biotreatability Study FSP, or other relevant observations.

For any field sampling work the following entries will be made:

- Sample location and ID number.
- Sample type collected.
- Date and time of sample collection.
- Sample location description and designation, soil type and texture (e.g., sand, silt, etc.), grain size, and color (in the field).
- Split samples taken by other parties (Agencies, etc.). Note the type of sample, sample location, time/date, name of individual, individual's company, and any other pertinent information.
- Sampling method, particularly any deviations from the field SOPs (Appendix A).
- Documentation or reference of preparation procedures for reagents or supplies that will become an integral part of the sample (if any used in the field).
- Sample preservation (if used).
- Decontamination procedure (if used).
- Sample custody (where samples are stored/shipped and by whom).

The lithologic information for test pits will be transcribed into a spreadsheet or database that can be used with Strater® or other appropriate lithologic log software.

#### **4.4.4.2 Field Photographs or Video**

Photographs and/or video will be taken of sampling locations and field activities using a digital camera and/or digital video camera. Photographs or video should include a scale in the picture as well as a white board with relevant information (e.g., time, date, location, sample number, etc.). Additional photographs or video documenting Site conditions will be taken, as necessary. Documentation of all photographs or video taken during sampling activities will be recorded in the bound field logbook or appropriate field data sheets (refer to field SOPs in Appendix A), and will specifically include the following for each photograph or video taken:

- Time, date, and location.
- Photograph or video number from the camera or video recorder.
- The identity of the person taking the photograph/video.
- Direction that the photograph was taken and description of the subject photographed.



The digital files will be placed with the electronic project files with copies of supporting documentation from the bound field logbooks.

## **4.5 Sample Handling and Analysis**

### **4.5.1 Documentation and Shipping**

Sample containers and holding times are listed in Table 3. All soil samples will be collected in the proper sample container. The sample ID, date/time, and depth interval of the sample will be written on the sample container with an indelible marker. Samples will be stored, handled, and packaged as described in Table 3. All procedures will strictly follow appropriate protocols and field SOPs in Appendix A. Chain of custody records will be kept with the samples and custody seals will be placed on the sample storage containers (coolers).

As applicable, samples will be either hand delivered or shipped via Federal Express or UPS to the appropriate laboratory under strict EPA chain of custody procedures. Samples will be shipped in appropriate containers that will prevent detrimental effects to the sample. A copy of the chain of custody record will accompany the samples during shipment and will serve as the laboratory request form. The chain of custody form will specify the type of analysis requested for each individual sample. The original form will be maintained with the field notes in the project records.

All samples not submitted to the laboratory will be archived. When it is determined that the samples are no longer needed, they will be disposed of at the Mine Waste Repository.

### **4.5.2 Chain of Custody**

The SOP for chain of custody (SOP-SA-04) is in Appendix A. Maintaining the integrity of the sample from collection through data reporting is critical to the sampling and analytical program. This process includes the ability to trace the possession and handling of samples from the time of collection through analysis and final disposition. This documentation of the sample's history is referred to as chain of custody. A sample is under an individual's custody if it is in that individual's physical possession, in view of the individual after taking possession, or secured by that individual so that no one can tamper with the sample.

The components of the field chain of custody (chain of custody form, labels, and custody seals) and laboratory chain of custody (chain of custody form, custody seals, and laboratory custody) are described in this section.

#### **4.5.2.1 Chain of Custody Form**

A chain of custody form will be completed and will accompany samples as appropriate. A standard form will be provided from each laboratory. The form will include the following information:

- Project code.
- Project name.
- Sampler's signature.
- Sample identification.
- Date sampled.
- Time sampled.
- Analysis requested.
- Remarks.
- Relinquishing signature, date, and time.
- Receiving signature, date, and time.

#### **4.5.2.2 Custody Seals**

Custody seals are used to detect unauthorized tampering with samples following sample collection up to the time of analysis. Custody seals will be applied to the shipping containers when the samples are not in the sampler's custody.

#### **4.5.2.3 Laboratory Custody**

Laboratory custody procedures will conform to procedures established for the EPA Contract Laboratory Program (EPA, 2016). These procedures include the following:

- Designation of sample custodian.
- Correct completion of the chain of custody form, recording of sample identification numbers, and documentation of sample condition upon receipt.
- Laboratory sample tracking and documentation procedures.
- Secure sample storage.

The samples will be delivered to the laboratory for analysis in a timely manner to ensure the requested analyses can be performed within the specified allowable holding times. The sample will be hand delivered or addressed to a person in the laboratory who is authorized to receive samples (laboratory sample custodian).

#### **4.5.3 Laboratory Analysis Methods**

Laboratory analysis of samples collected during the bench-scale biotreatability study will be performed by laboratories with established protocols and quality assurance (QA) procedures that meet or exceed EPA guidelines. Instruments used by the laboratory will be maintained in accordance with the laboratory QA plan requirements and analytical method requirements. All analytical measurement instruments and equipment used by the laboratory will be controlled by a formal calibration and preventive maintenance program. The laboratory will keep maintenance records and make them available for review, if requested. Laboratory preventive maintenance will include routine equipment inspection and calibration at the beginning of each day or each

analytical batch, per the laboratory internal SOPs and method requirements. Standard laboratory turnaround times will be requested.

The bench-scale biotreatability study may consist of up to four parts: an initial characterization of soil, a total oxidant demand analysis, an initial soil slurry analysis, and possibly an enhanced slurry analysis. Composite soil samples will be collected from test pits from the anticipated depths and soil conditions (Table 2) as described in Section 4.4. The samples will be thoroughly mixed per SOP-S-06 (Appendix A) to ensure homogenized, aliquot split samples. Split samples will be sent to Pace for the initial characterization analysis, to Provectus for the total oxidant demand analysis, and to AECOM to complete the soil slurry analyses. The anticipated laboratory analytical methods and procedures for the four parts are detailed below and summarized in Table 3. The planned laboratory analysis approach may be altered by the CPM, in consultation with the Contractor QAO. Agencies will be notified of any significant changes to the laboratory analysis approach.

#### **4.5.3.1 Initial Characterization**

Soil samples collected from the test pits will be sent to Pace for the initial characterization analysis. The initial characterization will include analysis for the following: total metals, hydrocarbon compounds, pH, nutrients, organic matter percentage, and soil moisture.

#### **4.5.3.2 Total Oxidant Demand Analysis**

One soil sample will be sent to Provectus to complete the total oxidant demand analysis. Total oxidant demand analysis is routinely performed by treatability laboratories and technology vendors to provide a starting point on how much oxidant agent will be consumed over a certain period of time (ASTM, 2016 and Haselow et al., 2003).

The sample will be selected to target soil within the preliminary waste removal corridor with the greatest concentration of high molecular weight hydrocarbons based on field screening and data collected from previous site investigations.

Provectus will test varying doses of two to three different oxidant agents to determine whether there are other reduced species (e.g., iron, manganese, organic carbon) in the soil sample that would consume the oxidant agent where *in-situ* chemical oxidation is not practicable as a treatment option. Provectus will set up bench-scale reactors and test their Provect-Ox line of chemical oxidant, activators, and buffers at a range of concentrations. Persulfate, sulfate, ORP, pH, and petroleum hydrocarbons will be measured multiple times during the bench-scale tests to track how the reaction is progressing (Table 3). The results of the total oxidant demand analysis will include total oxidant demand, optimal tested oxidant, and pH adjusting amendment dose (if needed to adjust pH).

At the conclusion of the test, Provectus will send the soil back to Atlantic Richfield. Atlantic Richfield will then submit a portion of the soil to Pace for a post-treatment analysis. The post-treatment analysis will include the following: total metals, hydrocarbon compounds (extractable petroleum hydrocarbon, VPH, and polycyclic aromatic hydrocarbons), and pH.

Based on the results from the total oxidant demand analysis and slurry analysis (described in Section 4.5.3.3), a sample of the post-treatment soil may be sent to the AECOM lab for a slurry analysis.

#### **4.5.3.3 Initial Slurry Analysis**

Soil samples will also be sent to AECOM to complete the soil slurry analyses. The general steps, provided by AECOM, for the soil slurry analyses are detailed below and generally follow published methods used to research the effects of metals toxicity on aerobic biodegradation or organic compounds (Olaniran et al., 2013 and Sobolev and Begonia, 2008.).

Upon receipt of the soil samples, AECOM will prepare a soil slurry for each composite soil sample. These soil slurries will consist of adding laboratory water (i.e., distilled deionized water) to each of the composite soil samples in 0.5-Liter glass media bottles. The target water to soil ratio will be 5:1 on a weight basis in order to promote mixing and increase contact among native bacteria, oxygen, hydrocarbons, and the native carbon and nutrients. Each soil slurry bottle will be capped with a porous foam plug to allow exchange of oxygen and carbon dioxide between the headspace and the room atmosphere.

The soil slurries will be mixed on a stir plate for 24 hours to establish a baseline level of biomass activity. At 24 hours, samples will be collected for measurements and analysis. Oxygen uptake rate (OUR) and total and dissolved adenosine triphosphate (ATP) measurements will be performed to assess the potential for toxicity in soil bacteria. The OUR indicates the rate of biomass respiration which is associated to overall biomass health and activity. The OUR will be measured on an aliquot from the soil slurry using a biological oxygen demand (BOD) bottle and a DO probe. Three OUR measurements will be performed after 24 hours of incubation for quality control (QC).

As it is responsible for transferring energy between electron donors (food source) and electron acceptors (oxygen), ATP is a key molecule for bacteria cell metabolism. The ATP can be measured as total and dissolved ATP. Dissolved ATP is an indication of bacteria cells that underwent lysis (death), and thus it is a measurement of inactive biomass. By measuring both total and dissolved ATP, the ATP measurements related to active biomass can be calculated (Active ATP equals the Total ATP minus Dissolved/Inactive ATP). In addition, a biomass stress index factor can be obtained from these measurements. Both the absolute number of ATP counts (including total, active, or inactive ATP) and the stress index indicate the biomass health and can be used to make relative comparisons among the different soil slurries. The ATP will be measured by taking a liquid sample from each soil slurry and processing it using the LuminUltra reactant kit and a luminometer. For each measurement a duplicate measurement will be taken for QC. Additionally, the ATP standard will be used at the beginning and end of each batch and every 10 measurements to ensure the equipment is operating properly.

Microbial analysis to quantify bacteria populations will be subcontracted by AECOM to Microbial Insights to perform their CENSUS-qPCR method. The method amplifies the DNA gene that encodes for a biomarker target, in this case for total bacteria. The results are reported as

bacteria cells/milliliter (for aqueous samples) or cells/gram (for soil samples). Approximately 10 grams of soil sample will be collected for microbial analysis. In addition to the total bacteria biomarker, functional genes related to the biodegradation of petroleum hydrocarbons will also be analyzed via CENSUS-qPCR. These will include the monooxygenase (almA) and alkane monooxygenase (alkB) genes, which encode for the enzymes responsible for short (C5-C16) and long (C20-C32) chain hydrocarbon compounds. The detection of these functional genes provides a line of evidence for biodegradation of petroleum hydrocarbons and, thus, native bacteria metabolism. Assay calibration, assay positive control, DNA extraction negative control, and assay negative control samples will be run during the analysis for QC.

#### **4.5.3.4 Enhanced Slurry Study**

Based on the findings from the initial microbial analysis, an enhanced analysis may be needed if results from the initial microbial analysis indicate the microbial activity is inadequate to gather the desired information. The enhanced slurry study will stimulate or enhance the microbial activity in an effort to gather better results. If completed, the enhanced slurry study will be performed by AECOM. If performed, the enhanced microbial analysis will be similar to the initial analysis with the following exceptions:

- Nutrients, most likely salts containing nitrogen and phosphorus, and an external carbon source, such as diesel, will be added to the soil slurries when they are prepared.
- The soil slurries will go through a 2-week incubation period prior to selecting samples to submit for microbial analysis. During that 2-week incubation period, AECOM will sample the soil slurries 4 times to measure OUR and ATP.

The CPM in consultation with the Contractor QAO will determine if the enhanced slurry study must be completed.

#### **4.5.4 Quality Assurance/Quality Control Samples**

##### **4.5.4.1 Field Quality Control Samples**

Field QC samples are used to identify any biases from transportation, storage, and field handling processes during sample collection, and to determine sampling precision. The following quality samples only apply to the laboratory samples submitted to Pace for the initial characterization of soils. All field QC samples will be shipped with field samples to Pace per SOP-SA-01 in Appendix A. Brief descriptions of the field QC samples are provided below, along with when and how many are to be collected.

##### ***Field Duplicate***

At least 1 field duplicate will be collected for this sampling event since it is anticipated that there will be less than 20 samples collected for analysis. If more than 20 samples are collected, additional field duplicates will be collected so that a minimum of 1 duplicate is collected for every 20 natural samples. A field duplicate is an identical, second sample collected from the same location, in immediate succession of the primary sample, using identical techniques. The duplicate sample will have its own sample number. Duplicate samples will be sealed, handled,

stored, shipped, and analyzed in the same manner as the primary sample. Both the primary sample and duplicate sample will be analyzed for identical chemical parameters by the laboratory. The analytical results of the primary and duplicate sample will be compared to determine sampling precision.

#### ***Temperature Blank***

A temperature blank is a vial of water that accompanies the samples that will be opened and tested upon arrival at the laboratory to ensure that the temperature of the shipping container was less than 6 °C. One temperature blank is required for each cooler shipped to the laboratory.

#### ***Trip Blank***

One trip blank is required per sampling event when VOC samples are collected. Trip blanks are used to determine if samples were contaminated during storage and/or transportation back to the laboratory. A trip blank is only required for VOC sampling. A trip blank is prepared for field personnel by the contract laboratory staff prior to the sampling event and is shipped and stored in the same cooler with the investigative VOC samples throughout the sampling event. At no time after their preparation are trip blanks to be opened before they reach the laboratory. Trip blanks should be kept on ice in the cooler, along with the VOC samples, during the entire sampling run. They must be stored in an iced cooler from the time of collection, while they are in the sampling vehicle, until they arrive at the laboratory.

#### **4.5.4.2 XRF Quality Control Samples**

The XRF QC samples will be collected and used to assess the accuracy and precision of the XRF data. The XRF QC samples required are described below.

#### ***Energy Calibration Check***

Field personnel will run a preprogrammed energy calibration check on the equipment at the beginning of each working day. If the individual believes that drift is occurring during analysis, that individual will run the energy calibration check. The energy calibration check determines whether the characteristic X-ray lines are shifting, which would indicate drift within the instrument.

#### ***Silicon Dioxide Standard***

The silicon dioxide (SiO<sub>2</sub>) sample, as provided by Niton, is a "clean" quartz or silicon dioxide matrix that contains concentrations of selected analytes near or below the machine's lower limit of detection. These samples are used to monitor for cross contamination. Field personnel will analyze this sample at the beginning of each day, once per every 20 samples, and at the end of each day's analysis. The sample information will be recorded as "SIO2" on XRF field data sheets. This sample will also be analyzed whenever field personnel suspect contamination of the XRF aperture. Any elements with concentrations above the established lower limit of detection will be evaluated for potential contamination. If it is determined that the concentration is higher than that recorded at the start of the day, the probe window and the silicon dioxide sample will be checked for contamination. If it is determined that contamination is not a problem, and the concentration is significantly above the limit of detection, the sample result will be qualified by

the XRF operator as 'J' estimated, and the problem recorded on the XRF field data sheet and in the logbook. If the problem persists, the XRF will be returned to Niton for calibration.

#### ***Calibration Verification Check Samples (Standards)***

Calibration verification check samples help check the accuracy of the XL3 and assess the stability and consistency of the analysis for the analytes of interest. One to 3 (preferably) of the check samples will be analyzed at the start of each day, once per every 20 samples, and as the last analysis. Results for the check sample (standard reference material [SRM]) will be recorded on the individual XRF field data sheet and identified as a check sample. There are 3 Niton-provided SRM check samples: NIST 2709a- Joaquin Soil (2709), USGS SdAR-M2 (SRM created by the U.S. Geological Survey [USGS]), and a Resource Conservation and Recovery Act (RCRA) sample. There are also Niton-provided, machine-specific expected results for several elements for the check samples. Pioneer has refined the range of expected results for each SRM standard for each of the field XRF units in use. The measured values of a standard will be compared to the expected results. If a measured value falls outside this range, then the check sample will be reanalyzed. If the value continues to fall outside the acceptance range, this information will be noted on the XRF log. If any of the check sample results indicate that the XRF is not analyzing accurately, the XRF will be cleaned, turned off, and the energy calibration rerun. This information will be noted in the logbook and on the XRF field data sheet. The batch of samples analyzed prior to the unacceptable calibration verification check samples will be reanalyzed. If 1 standard continues to be outside of the expected range, it may indicate that the standard has been contaminated and needs replacing. If more than 1 standard is falling outside of the expected range, Niton will be contacted, and the machine may be returned for calibration.

#### ***Duplicate Samples***

The XRF duplicate samples will be analyzed to assess reproducibility of field procedures and soil heterogeneity. To run a duplicate sample on the Niton XL3, field personnel will remove the ziplock bag from the analytical stand, knead the ziplock bag once or twice, and replace it in the stand to be analyzed a second time. Duplicate samples will be recorded on the XRF field data form with a D designator in the sample identification number. A duplicate sample will be analyzed at the rate of at least 1 per 20 natural samples.

#### ***Replicate Samples***

Field personnel will analyze a replicate sample at the rate of at least 1 per 20 XRF samples. To run a replicate sample on the Niton XL3, once the primary sample analysis has been completed, the XRF is restarted to analyze the same sample a second time with the same soil in the XRF aperture. Replicate samples help in assessing the stability and consistency of the XRF analysis. Replicate sample results will be recorded on the XRF field data form and designated with an R in the sample identification number.

### **4.5.4.3 Laboratory Quality Control Samples**

Laboratory QC samples are introduced into the measurement process to evaluate laboratory performance and sample measurement bias. Laboratory QC samples can be prepared from environmental samples or generated from standard materials in the laboratory per the internal

laboratory SOPs. The following laboratory QC samples only apply to the laboratory samples submitted to Pace for the initial characterization of soils.

#### ***Method Blank***

One method blank (MB) sample will be prepared and analyzed for this sampling event. The MB is laboratory deionized water that has gone through the applicable sample preparation and analysis procedure. Control limits vary based on the laboratory method performed and are contained in the applicable laboratory method and SOP. Failure will trigger corrective action and the blank will be reanalyzed. All samples will be footnoted with the appropriate flag to document contamination in the blank.

#### ***Laboratory Control Sample***

One laboratory control sample (LCS) will be prepared and analyzed for this sampling event. Control limits vary based on the laboratory method performed and are contained in the applicable laboratory method and SOP. Failure will trigger corrective action and the analysis will be terminated, the problem corrected, and the samples reanalyzed. If reanalysis of the samples fails, the samples will need to be re-digested and reanalyzed.

#### ***Matrix Spike/Matrix Spike Duplicate***

One matrix spike (MS) and matrix spike duplicate (MSD) sample will be prepared and analyzed for this sampling event. The control limits also depend on the method used and are contained in the applicable laboratory method and SOP. If the percent recovery (%R) for the MS and MSD falls outside the control limits, the results are flagged as outside acceptance criteria along with the parent sample. If the relative percent difference (RPD) exceeds the acceptance criteria, the MSD sample and associated parent sample will be flagged.

#### ***Laboratory Duplicate Sample***

One laboratory duplicate sample (LDS) will be prepared and analyzed for this sampling event. A LCS and LCS duplicate (LCSD) pair or an MS and MSD sample pair may be used as the LDS. Control limits will vary based on the QC sample used. Failure will trigger corrective action and a single reanalysis of the respective failing QC sample is allowed. If the reanalysis is outside the acceptance criteria, the analysis must be terminated, the problem corrected, the instrument recalibrated, and the calibration re-verified.

### **5.0 QUALITY ASSURANCE/QUALITY CONTROL**

The BRW Phase III QAPP provides the general QA/QC requirements that apply to this proposed work including general data management procedures (Section 4.12 of the BRW Phase III QAPP) and data validation and usability (Section 8.0 of the BRW Phase III QAPP). The QA/QC requirements in the BRW Phase III QAPP will be followed for this work with one change described in the section below.

#### **5.1 Data Verification and Validation Requirements**

Since this is a bench-scale study to determine the treatability of the hydrocarbon-impacted soils, the data collected from Pace will undergo Stage 2A Validation Electronic and Manual



(S2AVEM) verification and the data collected from AECOM will undergo Stage 1 Validation Manual (S1VM) as defined in *EPA Guidance for Labeling Externally Validated Laboratory Analytical Data for Superfund Use* (EPA, 2009) (Level 2A and Level 1 data validation).

The laboratory will prepare standard data packages for transmittal of results and associated QC information to Atlantic Richfield or its designee within a standard turnaround time, unless otherwise required.

Each data package from Pace will be accompanied by an electronic data deliverable (EDD) prepared by Pace. Additional laboratory QC data can be included in the EDD. The EDDs will be cross checked against corresponding data reports to confirm consistency in results reported in these two separate formats. This cross check will take place as part of the data verification process. AECOM will not provide an EDD as part of the data package.

Stage 1 verification and validation checks include an evaluation of the following, as applicable for each analytical method:

- Completeness of laboratory data package.
- Requested analytical methods performed.

Stage 2A verification and validation checks include an evaluation of the following, as applicable for each analytical method:

- Completeness of laboratory data package.
- Requested analytical methods performed.
- Holding times.
- Reported detection limits.
- Dilution factors.
- Method blanks.
- LCS and LCSD.
- MS samples and MSD samples.
- Laboratory duplicate samples.
- Field blanks.
- Field duplicates.

Stage 2A data validation for each laboratory data package will be documented on the data validation checklists in Appendix C.

## **6.0 ADDITIONAL PROJECT DETAILS**

Additional project details, listed below, are included in the BRW Phase III QAPP:

- Assessment and Oversight:
  - Field Activities Oversight.
  - Corrective Action Procedures.
  - Corrective Action During Data Assessment.
  - QA Reports to Management.
- Health and Safety.
- Project Organization and Responsibilities.

An organizational chart showing the overall organization of the project team is detailed on Figure 4.

## 7.0 REFERENCES

- ASTM, 2016. Standard Test Method for Estimating the Permanganate Natural Oxidant Demand of Soil and Aquifer Solids. D7262-01 (Reapproved 2016). American Society for Testing and Materials. July 2016.
- Atlantic Richfield Company, 2021a. Silver Bow Creek/Butte Area NPL Site Butte Priority Soils Operable Unit Final Revised Butte Reduction Works (BRW) Smelter Area Mine Waste Remediation and Contaminated Groundwater Hydraulic Control Site 2021 Phase III Quality Assurance Project Plan. Prepared by Pioneer Technical Services Inc. April 2021.
- Atlantic Richfield Company, 2021b. Silver Bow Creek/Butte Area NPL Site Butte Priority Soils Operable Unit Draft Final Butte Reduction Works (BRW) Smelter Area Mine Waste Remediation and Contaminated Groundwater Hydraulic Control Site Pre-Design Investigation (PDI) Evaluation Report. Prepared by Pioneer Technical Services Inc. May 14, 2021.
- Atlantic Richfield Company, 2021c. Silver Bow Creek/Butte Area NPL Site Butte Priority Soils Operable Unit Draft Final Preliminary 30% Remedial Design Report for the Butte Reduction Works (BRW) Smelter Area. Prepared by Pioneer Technical Services Inc. May 14, 2021.
- DEQ, 2002. Montana Department of Environmental Quality's Geographic Information System Portal. Information search related to Montana Power Storage Yard - Comprehensive Environmental Cleanup and Responsibility Act (CECRA) Site. Site Summary. September 25, 2002. Available at <https://gis.deq.mt.gov/portal/home/>.
- EPA, 1995. Remedial Design/Remedial Action Handbook, EPA 540/R-95/059. U.S. Environmental Protection Agency June 1995.
- EPA, 2009. U.S. Environmental Protection Agency Guidance for Labeling Externally Validated Laboratory Analytical Data for Superfund Use, January 2009.
- EPA, 2016. Contract Laboratory Program (CLP) Statement of Work for Inorganic Superfund Methods (Multi-Media, Multi-Concentration) ISM02.4. U.S. Environmental Protection Agency, October 2016.
- EPA, 2017. Five-Year Review Report. Fourth Five-Year Review Report for the Montana Pole and Treating Plant Site. Butte, Silver Bow County, Montana. U.S. Environmental Protection Agency, June 30, 2017. Available at <https://semspub.epa.gov/work/08/1818426.pdf>.
- EPA, 2020. Consent Decree for the Butte Priority Soils Operable Unit. Partial Remedial Design/Remedial Action and Operation and Maintenance. U.S. Environmental Protection Agency. February 13, 2020. Available at <https://www.co.silverbow.mt.us/2161/ButtePriority-Soils-Operable-Unit-Conse>.

- GCM Services, Inc., 1991. Cultural Resource Inventory of The Lower Area One Operable Unit of Silver Bow Creek/Butte Area NPL Site and the Montana Pole and Treating Plant NPL Site, December 1991.
- Haselow John S., Siegrist, Robert L., Crimi, Michelle, and Jarosch, Tim, 2003. Estimating the Total Oxidant Demand for In Situ Chemical Oxidation Design. Published online in Wiley Interscience ([www.interscience.wiley.com](http://www.interscience.wiley.com)). DOI: 10.1002/rem.10080. Autumn 2003.
- Munsell, 2009. Munsell Soil Color Book. 2009 Revision.
- Olaniran, Ademola; Balgobind, Adhika; and Pillay, Balakrishna, 2013. Bioavailability of heavy metals in soil: impact on microbial biodegradation of organic compounds and possible improvement strategies. International journal of molecular sciences vol. 14,5 10197-228. 15 May 15, 2013.
- Sanborn, 1943. Map of Survey of Defense Plant Corporation, Domestic Manganese and Development Company and Metals Reserve Tracts and Improvements Theron in the N½ of SW¼ of Section 24 T 3N, R 8W. Silver Bow County, Montana. Surveyed May 4<sup>th</sup> to 31<sup>st</sup>, 1943 by Francis T. Morris, Surveyor.
- Sobolev, Dmitri and Begonia, Maria F.T., 2008. Effects of heavy metal contamination upon soil microbes: lead-induced changes in general and denitrifying microbial communities as evidenced by molecular markers. International journal of environmental research and public health vol. 5,5 (2008): 450-6. December 31, 2008.



## **FIGURES**

Figure 1. Site Location Map

Figure 2. Site Map

Figure 3. Proposed Sample Areas for Biotreatability Test Pits

Figure 4. Project Organizational Chart



DISPLAYED AS: \_\_\_\_\_  
 PROJECTION/ZONE: MSP \_\_\_\_\_  
 DATUM: NAD\_83 \_\_\_\_\_  
 UNITS: INT'L FT \_\_\_\_\_  
 SOURCE: PIONEER/ARCO/BSB \_\_\_\_\_

0 0.375 0.75 1.5  
Miles


**FIGURE 1**

**SITE LOCATION MAP**


**PIONEER**  
TECHNICAL SERVICES, INC.

Date: 4/28/2021





Surface Water Monitoring Points	Slag Walls	Butte-Silver Bow Wastewater Treatment Plant Boundary
BPSOU Subdrain Pump System Alternate Discharge Line	BRW Site Boundary	Abandoned Aqueduct
Hydraulic Control Channel	LAO Boundary	MPTP Site Boundary
BPSOU Subdrain Pump System Primary Force Main		



DISPLAYED AS: \_\_\_\_\_  
 PROJECTION/ZONE: MSP \_\_\_\_\_  
 DATUM: NAD 83  
 UNITS: INTERNATIONAL FEET  
 SOURCE: PIONEER/TREC/QUANTUM 2020


**FIGURE 2**

**SITE MAP**

DATE: 7/1/2021




Notes:  
 (1) Results shown are from the BRW Phase I Site Investigation. Additional data is presented in the Pre-Design Investigation Evaluation Report (Atlantic Richfield, 2021b).  
 (2) Only soil samples which exceeded the appropriate Tier 2 RBSLs (Table 4 from Montana DEQ's RBCA Guidance) are indicated on this figure.  
 (3) Sample location information for each sample area is provided in Table 2.



- ▲ Surface, Sampled and No Results Above RBSLs or DEQ-7 Standards
- Subsurface, Sampled and No Results Above RBSLs or DEQ-7 Standards
- ▲ Surface, Soil Concentrations Above RBSLs
- Subsurface, Soil and/or Groundwater Above RBSL's and/or DEQ-7 Standards
- ▭ Sample Area for Biotreatability Study Test Pit
- ▭ Preliminary Waste Removal Corridor

▲ April 2019 Groundwater Contours (NAVD 88)  
 ▲ Feb. 2019 Groundwater Contours (NAVD 88)

**LABEL KEY**  
 BRW18-PZ10 = Piezometer Name  
 VPH = Organics Above the Appropriate Direct Contact RBSLs  
 EPH = Organics Above the Appropriate Leaching to Groundwater RBSLs  
 VPH = Organics Above DEQ-7 Standards in Groundwater Samples



DISPLAYED AS:  
 PROJECTION/ZONE: MSP  
 DATUM: NAD 83  
 UNITS: INT'L FT  
 SOURCE: PIONEER/QUANTUM 2020

0 75 150 300  
 Feet

**FIGURE 3**

**PROPOSED SAMPLE AREAS FOR BIOTREATABILITY TEST PITS**

DATE: 7/30/2021






Figure 4



Project Organization Chart

## **TABLES**

Table 1. Schedule

Table 2. Sample Location Information


Table 3. Sample Collection, Preservation, and Holding Times

Table 4. Limit of Detection for XRF

Table 5. Applicable and Relevant Standard Operating Procedures

Table 1  
Schedule

ID	Task Name	Duration	Start	Finish	Predecessors	May '21	Jun '21	Jul '21	Aug '21	Sep '21	Oct '21	Nov '21	Dec '21	Jan '22	Feb '22
0	<b>Table 1_Schedule</b>	<b>122 days</b>	<b>Tue 8/3/21</b>	<b>Wed 1/19/22</b>		25	29	16	23	30	6	13	20	27	4
1	<b>Hydrocarbon Biotreatability Study Field Sampling Plan (Phase III QAPP)</b>	<b>63 days</b>	<b>Tue 8/3/21</b>	<b>Thu 10/28/21</b>		25	29	16	23	30	6	13	20	27	4
2	Submit Draft Final to Agencies	1 day	Tue 8/3/21	Tue 8/3/21		25	29	16	23	30	6	13	20	27	4
3	Agency Review/Comment Period	20 days	Wed 8/4/21	Tue 8/31/21	2	25	29	16	23	30	6	13	20	27	4
4	Incorporate Agency Comments	10 days	Wed 9/1/21	Tue 9/14/21	3	25	29	16	23	30	6	13	20	27	4
5	Submit Final to AR for Review/Comment	1 day	Wed 9/15/21	Wed 9/15/21	4	25	29	16	23	30	6	13	20	27	4
6	AR Review/Comment Period	5 days	Thu 9/16/21	Wed 9/22/21	5	25	29	16	23	30	6	13	20	27	4
7	Incorporate AR Comments	10 days	Thu 9/23/21	Wed 10/6/21	6	25	29	16	23	30	6	13	20	27	4
8	Submit Final to Agencies	1 day	Thu 10/7/21	Thu 10/7/21	7	25	29	16	23	30	6	13	20	27	4
9	Agency Review and Approval Period	15 days	Fri 10/8/21	Thu 10/28/21	8	25	29	16	23	30	6	13	20	27	4
10	<b>Hydrocarbon Microbial Sampling</b>	<b>59 days</b>	<b>Fri 10/29/21</b>	<b>Wed 1/19/22</b>		25	29	16	23	30	6	13	20	27	4
11	Sampling	2 days	Fri 10/29/21	Mon 11/1/21	9	25	29	16	23	30	6	13	20	27	4
12	Pace Lab Analysis	4 wks	Tue 11/2/21	Mon 11/29/21	11	25	29	16	23	30	6	13	20	27	4
13	Provectus TOD Analysis	6 wks	Mon 11/1/21	Fri 12/10/21	11	25	29	16	23	30	6	13	20	27	4
14	Initial Slurry Study	29 days	Tue 11/2/21	Fri 12/10/21	11	25	29	16	23	30	6	13	20	27	4
15	Enhanced Slurry Study (Tentative)	28 days	Mon 12/13/21	Wed 1/19/22	14	25	29	16	23	30	6	13	20	27	4



Project: Table 1_Schedule Date: Tue 8/3/21	Summary Progress		Summary		Inactive Summary		Manual Summary		External Milestone	
	Task		Project Summary		Manual Task		Start-only		Deadline	
	Split		Inactive Task		Duration-only		Finish-only		Progress	
	Milestone		Inactive Milestone		Manual Summary Rollup		External Tasks		Manual Progress	

**Table 2. Sample Location Information**

Sampling Area*	Location ID	Anticipated Depth	Anticipated Soil Conditions for Sampling (Soil Type, Hydrocarbon-Compound Concentrations, and/or COC Concentrations)	Justification
<b>Biotreatability Study Test Pits</b>				
#1	BRW21-TP75	10 to 15-feet bgs	Gravel to silty sand, slag. Located at the groundwater table. Groundwater is anticipated to be approximately 10 to 13-feet bgs. PID (10.6 eV lamp) reading near or greater than 500 ppm and PID (9.8 eV lamp) reading near of greater than 100 ppm. COC concentrations above Waste Identification Criteria (EPA, 2020). Anticipated soil conditions are based on lithology logs for piezometers BRW19-HCW37, BRW19-HCW38, BRW18-PZ20, and BRW18-PZ21.	Based on previous site investigation activities at the Site, this location was selected based on hydrocarbon-compound concentrations above DEQ Tier 2 RBSLs (DEQ, 2018) for EPH in piezometer BRW18-PZ21. The exceedances were just at the groundwater table and within a layer of soil that exceeds the Waste Identification Criteria (EPA, 2020). Additionally, this location is along the edge of the Preliminary Waste Removal Corridor boundary. Additional information is needed in this area to help determine Site-specific action levels and help determine the proper treatment/disposal methods if the soil is removed as part of the waste removal or determine proper management methods if the soil is ultimately outside the Preliminary Waste Removal Corridor to protect the remedy.
#2	BRW21-TP76	5 to 10-feet bgs	Sandy silt to silty sand with a hydrocarbon odor. Above a brown, red, orange layer and above groundwater surface. Groundwater is anticipated to be approximately 7-feet bgs. PID (10.6 eV lamp) reading near or greater than 500 ppm and PID (9.8 eV lamp) reading near of greater than 100 ppm. COC concentrations above Waste Identification Criteria (EPA, 2020). Anticipated soil conditions are based on lithology logs for piezometers BRW19-HCW39 and BRW18-PZ18.	Based on previous site investigation activities at the Site, this location was selected based on hydrocarbon-compound concentrations above DEQ Tier 2 RBSLs (DEQ, 2018) for EPH in piezometer BRW18-PZ18. The exceedances were just above the groundwater table and within a layer of soil that exceeds the Waste Identification Criteria (EPA, 2020). Additionally, this location is along the edge of the Preliminary Waste Removal Corridor boundary. Additional information is needed in this area to help determine Site-specific action levels and help determine the proper treatment/disposal methods if the soil is removed as part of the waste removal or determine proper management methods if the soil is ultimately outside the Preliminary Waste Removal Corridor to protect the remedy.
#3	BRW21-TP77	10 to 15-feet bgs	Soft, wet, silty clay with a hydrocarbon odor. Soil most likely located just below groundwater table. Groundwater is anticipated to be approximately 10-feet bgs. PID (10.6 eV lamp) reading near or greater than 500 ppm and PID (9.8 eV lamp) reading near of greater than 100 ppm. COC concentrations above Waste Identification Criteria (EPA, 2020). Anticipated soil conditions area based on lithology logs for borehole BRW18-BH11, piezometer BRW19-HCW34, and test pit BRW19-HCTP32.	Based on previous site investigation activities at the Site, this location was selected based on hydrocarbon-compound concentrations above DEQ Tier 2 RBSLs (DEQ, 2018) for VPH, EPH, and PAH in borehole BRW18-BH11 and for EPH in test pit BRW19-HCTP32. Additionally, this location is along the edge of the Preliminary Waste Removal Corridor boundary. Additional information is needed in this area to help determine Site-specific action levels and help determine the proper treatment/disposal methods if the soil is removed as part of the waste removal or determine proper management methods if the soil is ultimately outside the Preliminary Waste Removal Corridor to protect the remedy.
#4	BRW21-TP78	0 to 1-foot bgs	Surface soils with visible staining, hydrocarbon odors, and detectable concentrations of hydrocarbons with Hanby Field Soil Kit.	Based on previous site investigation activities at the Site, multiple surface sample locations within this area were above DEQ's Tier 2 RBSLs (DEQ, 2018) for EPH, specifically the heavier hydrocarbon chains. This area is within the Preliminary Waste Removal Corridor. Additional information is needed in this area to help determine Site-specific action levels and help determine the proper treatment/disposal methods if the soil is removed as part of the waste removal.
#5	BRW21-TP79	1 to 5-feet bgs	Silty sand and gravel. No detectable hydrocarbons. Generally low COC concentrations, no COC concentrations above Waste Identification Criteria (EPA, 2020). Groundwater is anticipated to be approximately 5-feet bgs. Anticipated soil type is based on well log for monitoring well BPS11-05A1 since piezometers BRW18-PZ14 and BRW18-PZ15 were potholed to 8-feet bgs. There are multiple utilities in the area and the final test pit location will be adjusted based on the location of those utilities.	Based on previous site investigation activities at the Site, this location is the most likely area within the Site where a background sample (i.e., generally lower COC concentrations and no detectable hydrocarbons) could be collected.

\*Sampling area locations are shown on Figure 3.

Acronyms

ppm = parts per million  
 bgs = below ground surface  
 COC = contaminant of concern  
 PID = Photoionization Detector  
 eV = electron volt  
 DEQ = Montana Department of Environmental Quality  
 RBSL = Risk-Based Screening Level

References:

EPA, 2020. Consent Decree for the Butte Priority Soils Operable Unit. Partial Remedial Design/Remedial Action and Operation and Maintenance. U.S. Environmental Protection Agency. February 13, 2020. Available at <https://www.co.silverbow.mt.us/2161/ButtePriority-Soils-Operable-Unit-Conse>.  
 DEQ, 2018. Montana Risk-Based Corrective Action Guidance for Petroleum Releases, Montana Department of Environmental Quality, May 2018. Available at this site [http://deq.mt.gov/Land/statesuperfund/rbca\\_guide](http://deq.mt.gov/Land/statesuperfund/rbca_guide).

**Table 3. Sample Collection, Preservation, and Holding Times**

Analytical Lab/Company <sup>1</sup>	Analyte	Analytical Method	Lab Reporting Limit (RQL for Data Validation Purposes)	Lab Method Detection Limit <sup>2</sup>	Holding Time	Container Size	Preservation <sup>3</sup>	Justification		
Pioneer	pH	NA	NA	NA	NA	NA	NA	Determine general parameters of groundwater encountered during test pit excavation, if feasible.		
	Specific Conductance (SC)									
	Oxidation Reduction Potential (ORP)									
	Dissolved Oxygen (DO)									
Pioneer XRF	Arsenic (As)	NA	NA	NA	NA	NA	NA	Field screening to confirm preferred soil conditions are present for bioremediation study.		
	Cadmium (Cd)									
	Copper (Cu)									
	Lead (Pb)									
	Zinc (Zn)									
	Mercury (Hg)									
Pioneer PIDs	Volatile Organic Compounds	NA	NA	NA	NA	NA	NA			
	MainIRAE (PID MR) - 10.6 eV lamp UltraIRAE (PID UR) - 9.8 eV lamp	BTEX (Benzene, Toluene, Ethylbenzene, and Xylenes)								
Hanby Field Soil Kit	BTEX (Benzene, Toluene, Ethylbenzene, and Xylenes) Semi-volatile Organic Compounds Polycyclic Aromatic Hydrocarbons	NA	NA	NA	NA	NA	NA			
Pace Analytical Services, LLC General Parameters	pH	EPA 9045C	0.1 S.U.	0.1 S.U.	15 Minutes <sup>4</sup>	2-4 oz. amber glass jars	None	Determine general chemistry soil samples. Data will also help inform possible hydrocarbon management strategies.		
	SC	EPA 120.1	10 umhos/cm	10 umhos/cm	28 Days					
	Percent Moisture	SM 2540G	0.100 %	0.100 %	6 months					
	Total Organic Carbon	Walkley Black	100 mg/kg	25.5 mg/kg	28 Days					
	Total Alkalinity (Reported as Carbonate Alkalinity)	SM 2320B Modified	100 mg/kg	100 mg/kg	14 Days					
	Total Nitrogen, Calculation	Calculation	0.10 mg/kg	NA	28 Days					
	TKN, Nitrogen	EPA 351.2	20 mg/kg	4.48 mg/kg	28 Days					
	Nitrate	EPA 9056A	10 mg/kg	0.557 mg/kg	28 Days					
	Sulfate	EPA 9056A	50 mg/kg	12.9 mg/kg	28 Days					
	Ammonia	EPA 250.1	10 mg/kg	7 mg/kg	28 Days					
	Sulfur (S)	EPA 6010 (ICP/AES)	25mg/kg	4.61 mg/kg	180 Days					
	Arsenic (As)	EPA 6020 (ICP/MS)	0.50 mg/kg	0.109 mg/kg	180 Days	4-oz. amber glass container	None		Determine metals concentrations in soils to help evaluate metal toxicity to microbial activity.	
	Cadmium (Cd)		0.08 mg/kg	0.0214 mg/kg						
	Copper (Cu)		1.0 mg/kg	0.242 mg/kg						
	Iron (Fe)		50 mg/kg	10 mg/kg						
	Lead (Pb)		0.20 mg/kg	0.0294 mg/kg						
	Manganese (Mn)		0.50 mg/kg	0.245 mg/kg						
	Zinc (Zn)		5.0 mg/kg	0.899 mg/kg						
	Mercury (Hg)	EPA 7471B	0.02 mg/kg	0.00668 mg/kg	28 Days		None			
	Hydrocarbon Compounds	Volatile Petroleum Hydrocarbons (VPH)	MTVPH			7 Days	4-oz. amber glass container		None	Establish baseline concentrations to help determine breakdown of petroleum components. Laboratory to perform silica gel cleanup to remove potential interferences to diesel range organics (DRO).
		Extractable Petroleum Hydrocarbons (EPH) Fractionation	MTEPH			14 Days	4-oz. amber glass container		None	
		Polycyclic Aromatic Hydrocarbons (PAHs)	EPA 8270S/M	Analyte Specific - Meets DEQ Risk-Based Screening Level <sup>5</sup> where applicable.		7 days	8-oz. amber glass container		None	
		SPLP	EPA 1312 for SPLP Extraction Solids to be analyzed for VPH, EPH, and PAHs prior to SPLP Extraction. Leachate to be analyzed for VPH, EPH, and PAHs.							
	Provetus Environmental Products <sup>6</sup>	Persulfate	Visual Persulfate CHEMets Test Kit (Ferriic Thiocyanate)	7 mg/L	0.35 mg/L	NA	25 mL sample cup with <5 mL sample required		None	Provetus will set up bench-scale reactors and test their Provet-Ox line of chemical oxidant, activators, and buffers at a range of concentrations. Provetus will test varying doses of two to three different oxidant agents to determine whether there are other reduced species (e.g., iron, manganese, organic carbon) in the soil sample that would consume the oxidant agent where in-situ chemical oxidation is not practicable as a treatment option. Persulfate, sulfate, ORP, pH and petroleum hydrocarbons will be measured multiple times during the bench-scale tests to track how the reaction is progressing.
		Sulfate	EPA 9056A, modified.	0.0033 mg/L	0.0033 mg/L	21 days (4°C)	25 mL plastic		None	
		ORP	Standard Methods 2580, Electrode.	NA	0.1 mV (-199.9 to 199.9); 1 mV (-199.9 and >199.9)	NA	NA		None	
pH		EPA 9045C	0.1 S.U.	0.1 S.U.	15 minutes/ ASAP	NA	None			
Total Petroleum Hydrocarbons (TPH) as Gasoline Range Organics (GRO)		EPA 8015	1.6 mg/kg	1.6 mg/kg	14 Days	4-oz. amber glass container	None			
TPH as Diesel Range Organics (DRO)/Residual Range Organics (RRO)/Oil Range Organics (ORO)		EPA 8015	20 mg/kg	20 mg/kg	14 Days	4-oz. amber glass container	None			
AECOM <sup>7</sup>	Oxygen Uptake Rate (OUR)	OUR will be measured on an aliquot from the soil slurry using a biological oxygen demand (BOD) bottle and a dissolved oxygen (DO) probe.	N/A	N/A	N/A	300 mL	None, performed in real-time.	OUR indicates the rate of biomass respiration which is associated to overall biomass health and activity.		
	Adenosine Triphosphate (ATP)	ATP will be measured by taking a liquid sample from each soil slurry and processing using the LumitUltra reagent kit and a luminometer.	5 pg ATP/mL	5 pg ATP/mL	7 days	15 mL	Proprietary preservative.	ATP can be measured as total and dissolved ATP. Dissolved ATP is an indication of bacteria cells that underwent lysis (death), and thus it is a measurement of inactive biomass. By measuring both total and dissolved ATP, the ATP measurements related to active biomass can be calculated. In addition, a biomass stress index factor can be obtained from these measurements. Both the absolute number of ATP counts and the stress index indicate the biomass health and can be used to make relative comparisons among the different soil slurries.		
Microbial Insights	Microbial Analysis (Microbial Insights)	CENSUS-qPCR Method	500 to 5,000 cells/sample	100 cells/sample	1-2 days	10 grams of soil	Temperature 4°C	The concentrations of specific microorganisms and functional genes provide a line of evidence for biodegradation of petroleum hydrocarbons, and thus, native bacteria metabolism.		

<sup>1</sup>Atlantic Richfield may choose to use a different laboratory based on project needs. Regardless of the laboratory chosen, Atlantic Richfield will ensure the necessary reporting limits, required methodology, and the specified quality assurance/quality control and data validation requirements are followed as detailed in the Phase II QA/QP. Agencies will be informed of any changes in the reporting limits, methodology, or the quality assurance/quality control and data validation procedures.

<sup>2</sup>Pace Analytical Services, LLC will report results to the method detection limit. The analytical lab's reporting limits and detection limits are subject to change as these values are updated periodically to reflect analytical sensitivity and capability. Atlantic Richfield will ensure that any updates to the reporting limits or detection limits do not affect the ability for the Data Quality Objectives to be met and the updates will be specified in the Phase III Data Summary Report.

<sup>3</sup>In addition to the preservation listed, all samples will be cooled to <5 °C. Not all analyses require this but because multiple containers will be collected at most sites, all samples will be cooled.

<sup>4</sup>DEQ, 2018. Montana Risk-Based Corrective Action Guidance for Petroleum Releases, Montana Department of Environmental Quality, May 2018.

<sup>5</sup>Pioneer will supply AECOM with a minimum of 5 kilograms of soil (approximately 2 gallon Ziplock bags) for each sample to complete the identified analyses. All samples will be packed in a cooler with ice to preserve organic compounds at a temperature < 6 °C and shipped to AECOM.

<sup>6</sup>The holding time of 15 minutes is a goal and starts once the sample has been prepared. The method states as soon as possible.

<sup>7</sup>Pioneer will supply Provetus with two 1-gallon Ziplock bags to complete the identified analyses. The sample will be selected based on the greatest concentration of high molecular weight hydrocarbons from all test pits. The sample will be packed in a cooler with ice to preserve organic compounds at a temperature < 6 °C and shipped to Provetus.

Units: S.U. - Standard Unit  
umhos/cm or µS/cm - microsiemens per centimeter  
mg/kg - milligram per kilogram  
mL - milliliter

**Table 4. Limit of Detection for XRF**

<b>Metals</b>	<b>EPA Method 6200 (mg/kg)</b>	<b>Niton XL3* (mg/kg)</b>
Arsenic (As)	40	3
Cadmium (Cd)	100	7
Calcium (Ca)	70	26
Copper (Cu)	50	14
Chromium (Cr)	150	9
Iron (Fe)	60	28
Mercury (Hg)	30	10
Lead (Pb)	20	4
Manganese (Mn)	70	30
Silver (Ag)	70	12
Zinc (Zn)	50	7

\*Niton XL3 limit of detection is based on acquisition time of 120 seconds analyzing a quartz-sand matrix. Actual in-field detection limits are typically higher due to soil matrix effects.  
mg/kg: milligrams per kilogram.

**Table 5. Applicable and Relevant Standard Operating Procedures**

SOP Number	Title	Version
<b>PIONEER TECHNICAL SERVICES, INC. STANDARD OPERATING PROCEDURES</b>		
SOP-DE-01	PERSONAL DECONTAMINATION PROCEDURES	12/03/2014
SOP-DE-02	EQUIPMENT DECONTAMINATION	09/08/2020
SOP-DE-03	INVESTIGATION DERIVED WASTE HANDLING	12/02/2014
SOP-S-01	SURFACE SOIL SAMPLING	12/11/2014
SOP-S-02	SUBSURFACE SOIL SAMPLING	12/11/2014
SOP-S-06	TEST PIT SSAMPLING	11/20/2020
SOP-SA-01	SOIL AND WATER SAMPLE PACKAGING AND SHIPPING	12/11/2014
SOP-SA-04	CHAIN OF CUSTODY FORMS FOR ENVIRONMENTAL SAMPLES	11/12/2020
SOP-SA-05	PROJECT DOCUMENTATION	12/17/2014
SOP-SFM-02	OPERATING XL3 X-RAY FLUORESCENCE ANALYZER	06/05/2015
SOP-SURVEY-01	STAKING AND SURVEYING	10/24/2016
SOP-WFM-01	FIELD MEASUREMENT OF pH IN WATER	09/29/2020
SOP-WFM-02	FIELD MEASUREMENT OF OXIDATION REDUCTION POTENTIAL IN WATER	12/17/2014
SOP-WFM-03	FIELD MEASUREMENT OF SPECIFIC CONDUCTANCE	12/17/2014

# **Appendix A.**

## **Standard Operating Procedures**





**SOP-DE-01;  
PERSONAL DECONTAMINATION  
PROCEDURES**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 1 of 6

<b>PURPOSE</b>	To provide standard instructions for decontamination of all personnel leaving a contaminated area.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

<b>TASK</b>	<b>INSTRUCTIONS</b>
1. Wash/ Remove outer contaminated items.	<p>Remove nitrile or latex gloves by grasping the outside of the opposite glove near the wrist. Pull and peel the glove away from the hand, turning the glove inside out with the contaminated side now on the inside. Hold the removed glove in the opposite gloved hand. Slide one or two fingers of the ungloved hand under the wrist of the remaining glove. Peel glove off from the inside, creating a bag for both gloves.</p> <p>If wearing protective coveralls such as Tyvec suites, brush built up material off the suit, only if in designated decontamination zone. Unzip the coverall and begin rolling that outwards, rolling it down over your shoulders. Place both hands behind your back and pull down each arm until completely removed. Sit down and remove each shoe then roll the coveralls down (ensuring the contaminated side is not touched or comes into contact with clothing) over your knees until completely removed.</p> <p>If there is not a designated decontamination zone, remove personal protective equipment (PPE) carefully to contain material and place it in the appropriate disposal container.</p> <p>For instructions to remove additional PPE not described in this document, refer to the project's HASP.</p> <p>Wash with soap (nonphosphate) and tap water the outer, more heavily contaminated items, such as boots. Rinse the items in tap water.</p>
2. Wash inner contaminated items.	If necessary, wash with soap (nonphosphate) and tap water the inner, less contaminated items. Rinse the items in tap water.
3. Store/ transport items.	Store/transport contaminated items in a separate designated area to prevent cross contamination prior to disposal.



**SOP-DE-01;  
PERSONAL DECONTAMINATION  
PROCEDURES**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE 2 of 6**

4. Dispose of contaminated items.	Dispose of contaminated clothing and equipment in accordance with site/project, client, and/or federal and state requirements.
5. Contact the Safety and Health Manager.	For contaminants other than those found typically at uncontrolled hazardous waste sites, such as asbestos, PCB, PCE, etc. see the Safety and Health Manager.
<b>Information about Emergency Decontamination</b>	
1. During life-saving process.	If the decontamination procedure is essential to the life-saving process, decontamination must be performed immediately.
2. During heat-related illness.	If heat-related illness develops, protective clothing should be removed as soon as possible. Wash, rinse, and/or cut off protective clothing/equipment.
3. When medical treatment is needed.	<p>If medical treatment is required to save a life, decontamination should be delayed until the victim is stabilized. Wrap the victim to reduce contamination of others.</p> <p>Alert medical personnel to the emergency and instruct them about potential contamination. Instruct medical personnel about specific decontamination procedures.</p>



**SOP-DE-01;  
PERSONAL DECONTAMINATION  
PROCEDURES**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 3 of 6

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated items and resulting water from decontamination procedures.	Sites.	Inadvertent exposure to contaminated items and water resulting from decontamination procedures could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Employees will follow decontamination procedures as described above. Employees will wear nitrile gloves and safety glasses when handling contaminated items.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Not applicable.			
<b>GRAVITY</b>	Slips and falls.	Areas designated for decontamination procedures.	Slips and falls could occur while performing decontamination procedures due to slippery surfaces resulting in bruises, scrapes, or broken bones.	Workers will wear work boots with good traction and ankle support. Keep work area as dry as possible. Wear muck boots as necessary.
<b>WEATHER</b>	Cold/heat stress.  Hypothermia/frost bite.	Sites.  Sites where air temperature is 35.6°F (2°C) or	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.  Workers whose clothing becomes wet	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Employees will remain hydrated and will have sufficient caloric intakes during the day.  Employees will change clothing, if it becomes wet.



**SOP-DE-01;  
PERSONAL DECONTAMINATION  
PROCEDURES**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 4 of 6

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

	Lightning.	less.  Outdoor sites.	during decontamination procedures may be exposed to hypothermia and/or frostbite.  Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Employees will follow the 30/30 rule during lightning storms.
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Employees could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Employees will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Employees should wear sunscreen, if necessary.
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Employees with allergies will notify their supervisor.
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.



**SOP-DE-01;  
PERSONAL DECONTAMINATION  
PROCEDURES**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 5 of 6

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

			effects and/or property damage.	
<b>SIMOPS</b>	Not applicable.			

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.
<b>APPLICABLE SDS</b>	Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/ WORK PLANS</b>	
<b>TOOLS</b>	In general, the following items will be needed: soap, tap water, tarps, decontamination tubs, brushes, and sprayers. The Sampling and Analysis Plan (SAP) or Quality Assurance Project Plan (QAPP) will describe additional items needed for decontamination.
<b>FORMS/CHECKLIST</b>	





**SOP-DE-01;  
PERSONAL DECONTAMINATION  
PROCEDURES**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 6 of 6

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>12/03/2014</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>12/03/2014</b>

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>



<b>PURPOSE</b>	To provide standard instructions for equipment decontamination.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.
<b>NOTES</b>	<p>All equipment leaving the contaminated area of a site must be decontaminated. Decontamination methods include removal of contaminants through physical, chemical, or a combination of both methods. Decontamination procedures are to be performed in the same level of protection used in the contaminated area of a site. In some cases, decontamination personnel may be sufficiently protected by wearing one level lower protection. The information for site specific equipment decontamination and personnel protection levels, as detailed in the Sampling and Analysis Plan (SAP), work plan (WP), and Site-Specific Health and Safety Plan (SSHASP), should be followed.</p> <p>The following decontamination procedures are for typical uncontrolled hazardous waste sites. For a specific or unusual contaminant, such as dioxins, see the SSHASP and consult with the Safety and Health Manager. Decontamination procedures should be used in conjunction with methods to prevent contamination of sampling and monitoring equipment. If practical, particularly with organic contaminants, one-time-use equipment should be used, and disposed of in accordance with the SAP, work plan, and SSHASP.</p> <p>This SOP covers all equipment decontamination EXCEPT for submersible pumps. Decontamination of pumps is detailed in SOP-DE-02A – Equipment Decontamination - Pumps for Well Sampling.</p>

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

<b>TASK</b>	<b>INSTRUCTIONS</b>
1. Setup decontamination station.	<p>Review the SAP or WP and determine if decontamination fluids need to be contained. If the fluids require containment, set up the decontamination station so that it is located within a small plastic swimming pool or on plastic sheeting with turned up edges to contain water that may slop over during the decontamination process.</p> <p>If pressurized or gravity flow water is available, attach a hose or piping to reach the decontamination area. If no water is available, four 5-gallon buckets can be used for cleaning most equipment. Label the buckets: gross wash; soap wash; DI rinse; final rinse. Lay out plastic or foil to place the cleaned equipment on to air dry.</p>



	Pour approximately 2 ½ to 3 gallons of de-ionized (DI) water into each bucket. Add a few (1-3 drops) of Liquinox <sup>®</sup> soap to the bucket marked: soap wash.
2. Remove gross contamination.	Remove gross contamination using pressurized or gravity flow tap water, if available. If not, equipment will be scrubbed in the 5-gallon bucket of DI water marked: gross wash and a stiff brush (dedicated to the gross wash step).
3. Wash equipment.	Move the equipment to the 5-gallon bucket marked: soap wash. Wash equipment with a stiff brush (dedicated to the soap wash step).
4. Triple rinse equipment.	Triple rinse the equipment with DI water to remove any soap residue in the bucket marked: DI rinse.
5. Second Rinse with DI Water	Triple rinse the equipment again in the bucket marked: Final rinse.
6. Rinse equipment with chemicals.	<p>In many cases, the tap water and de-ionized water rinses will be sufficient. If specified in the SAP, work plan, or SSHASP, chemical rinses of the equipment may be required. For inorganic contaminants, a mixture of 10:1 nitric acid in distilled water (10 parts water to 1 part nitric acid) is commonly used. A Methanol rinse may be required for some organic contaminants, such as hydrocarbons.</p> <p>Spray bottles, clearly marked with the appropriate chemical name, are an acceptable means of rinsing most equipment. To perform the chemical rinse, hold the equipment over a collection container (5-gallon bucket or bowl) spray the piece of equipment inside and out starting at the top and working down to the bottom. Make sure that all workers and vehicles are upwind of the spray. Dispose of the contained chemicals as described in the SAP, WP or SSHASP. The Safety and Health Manager and/or Project Manager must approve the disposal method used.</p> <p>If a chemical rinse is used, rinse the equipment again with DI water in a 5th bucket of DI water. This water will need to be retained (i.e., do not dispose of this water on site), tested, and disposed of according to federal and state requirements for the chemical used. The Safety and Health Manager and/or Project Manager must approve the disposal method used.</p>
7. Air dry equipment.	Place equipment on plastic sheeting or foil to air dry.
8. Transport/ store equipment.	Wrap equipment in foil or plastic wrap to transport or store.
9. Triple rinse decontamination equipment.	Triple rinse equipment (i.e., brushes, buckets, tubs, etc.) used in the decontamination process with water, preferably pressurized.
10. Wash	Agitate the equipment used in the decontamination process in the soap/DI water





**SOP-DE-02;  
EQUIPMENT DECONTAMINATION**

**DATE ISSUED: 06/05/2015  
REVISION: 0  
PAGE 3 of 8**

decontamination equipment.	solution.
11. Triple rinse decontamination equipment.	Triple rinse equipment with DI-water.
12. Store and label decontamination equipment.	Place equipment in appropriate areas, so they are used only for decontamination purposes. Label the equipment, if necessary.
13. Dispose of decontamination solutions.	<p>When contaminants have been identified, either in the solutions or elsewhere on the site, solutions should be disposed of appropriately as discussed in the SAP, work plan, or SSHASP. If they are hazardous (e.g., characteristic, listed, etc.), dispose of them according to federal and state requirements. The Safety and Health Manager and/or Project Manager must approve the disposal method used.</p> <p><u>Note:</u> when using other than the above mentioned solutions, check with the Safety and Health Manager and the Project Manager.</p>
14. Measure effectiveness of procedures.	Effectiveness of the decontamination procedures will be measured using field equipment rinsate blanks (see the Site-Specific Quality Assurance Project Plan).



**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated items and resulting water from decontamination procedures.	Sites.	Inadvertent exposure to contaminated items and water resulting from decontamination procedures could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Employees will follow decontamination procedures as described above. Employees will wear nitrile gloves and safety glasses when handling contaminated items.
	Chemical rinse (e.g., dilute nitric acid, methanol, and hexane).	Sites.	Employees could be exposed to chemicals via ingestion and skin/eye contact when decontaminating equipment. Exposure could cause irritation of skin/eye and adverse health effects.	Check and follow safety procedures as outlined in the chemical-specific Safety Data Sheets. Employees will prevent skin/eye contact with chemicals and they will wear nitrile gloves and eye protection when handling chemicals. Employees will practice proper personal hygiene – wash hands prior to eating/drinking, after decontaminating equipment, and when leaving the site. All workers and vehicles will stand upwind when spraying equipment with chemicals. Refer to the Chemical Flushing Guidelines available inside vehicle’s first aid kit for first-aid procedures in case of contact with chemicals.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Improper lifting.	Sites.	Back injuries and muscle/back strains could result when using	Personnel will use proper lifting techniques – get a good grip, keep the load close to the body, lift with legs and not



**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

			improper techniques to lift and carry 5-gallon containers.	with back, and avoid lifting loads above shoulder's height. Two people will lift awkward/heavy tools and equipment.
<b>GRAVITY</b>	Falls from slips and trips.	Areas designated for decontamination procedures.	Slips and falls could occur while performing decontamination procedures due to slippery surfaces resulting in bruises, scrapes, or broken bones.	Workers will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. Keep work areas as dry as possible. Wear muck boots, as necessary.
<b>WEATHER</b>	Cold/heat stress.	Sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Employees will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.
	Hypothermia/frost bite.	Sites where air temperature is 35.6°F (2°C) or less.	Workers whose clothing becomes wet during decontamination procedures may be exposed to hypothermia and/or frostbite.	Employees will change clothing, if it becomes wet.
	Lightning.	Outdoor sites.	Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Employees will follow the 30/30 rule during lightning storms.



**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Employees could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Employees will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Employees should wear sunscreen, if necessary.
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Employees with allergies will notify their supervisor.
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Contact with hot surfaces.	Foil and decontamination equipment.	If foil and decontamination equipment are placed directly in the sun, they could get hot. Contact with hot surfaces could result in personal injury.	Personnel will prevent setting decontamination stations directly in the sun.
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.
<b>SIMOPS</b>	Not applicable.			



**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.
<b>APPLICABLE SDS</b>	Safety Data Sheets (SDSs) for corresponding chemicals used during chemical rinse. Additional SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/ WORK PLANS</b>	
<b>TOOLS</b>	Five 5-gallon buckets, tap water, stiff brushes, soap, de-ionized or distilled water, chemicals for chemical rinse (if required), plastic sheeting or foil, tarps, and sprayers (if available). If additional items for decontamination are needed, they will be listed on the SAP.
<b>FORMS/CHECKLIST</b>	





**SOP-DE-02;  
EQUIPMENT DECONTAMINATION**

**DATE ISSUED: 06/05/2015  
REVISION: 0  
PAGE 8 of 8**

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>06/05/2015</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>06/05/2015</b>

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>



**SOP-DE-03;  
INVESTIGATION DERIVED WASTE  
HANDLING**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 1 of 7

<b>PURPOSE</b>	To provide standard instructions for handling investigation-derived waste in accordance with the US Environmental Protection Agency (EPA) protocols and Department of Environmental Quality (DEQ) guidance. Investigation-derived waste may be generated during a Site Assessment (SA), Site Investigation (SI), or Remedial Investigation (RI).
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

<b>TASK</b>	<b>INSTRUCTIONS</b>
1. Collect and dispose of decontamination fluids.	<p>Collect and dispose of decontamination fluids by using one of the following methods:</p> <ul style="list-style-type: none"> <li>- Send fluids to a Treatment, Storage, and Disposal (TSD) facility.</li> <li>- Evaporate fluids.</li> <li>- Tread fluids using an activated carbon or air sparging unit.</li> <li>- Temporarily store fluids until determined if they are contaminated.</li> </ul> <p>Dispose of decontamination fluids, generated from cleaning equipment used in background sampling or for sampling in areas where past results indicate that contaminants are below standards, to the ground surface.</p>
2. Discharge groundwater from developing and purging wells.	If past monitoring results and laboratory analysis indicate that all contaminants are below groundwater standards, discharge groundwater generated from developing and purging monitoring wells to the ground surface.
3. Collect/label/store contaminated groundwater from developing and purging wells.	<p>If past monitoring results indicate that one or more contaminants are above groundwater standards, collect the purged water and potentially contaminated water.</p> <p>There may be instances (e.g., inclement weather) where purge water and/or decontamination water will be temporarily stored in drums or tanks to be treated on site with granulated activated carbon or air sparging. If the water is determined by laboratory analysis to contain contaminants above groundwater standards and cannot be treated on site, store the water on site until shipping/disposal arrangements can be made.</p> <p>If the water is visibly contaminated, drum, label, and store the water on site until</p>



**SOP-DE-03;  
INVESTIGATION DERIVED WASTE  
HANDLING**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE 2 of 7**

	shipping/disposal arrangements are made. Label all containers stored on site with the following information: date, time, contents, any corresponding analytical data, collection location, contact person, and contact agency, etc.
4. Return soils back to borehole.	Unless it is visibly contaminated, place soil and/or cuttings from monitoring well installation back in the borehole.
5. Collect/label/store contaminated soils from installing wells.	<p>If the soil is visibly contaminated, drum, label, and store the soil/cuttings on site until shipping/disposal arrangements are made.</p> <p>Drum and label soils from borings/well installations located in previously sampled areas that are known to be contaminated. Leave these soils on site until shipping/disposal arrangements are made.</p>
6. Pack and dispose of one-time use equipment and PPE.	<p>Pack disposable equipment intended for one-time use and personal protective equipment (PPE) materials for appropriate disposal. Double bag the disposable equipment and PPE utilized for sampling and dispose of it as a solid waste in the local landfill.</p> <p>Package, drum, and label disposable equipment and PPE utilized for sampling visibly contaminated sites or sites known to be contaminated from previous monitoring. Leave equipment and PPE on site until shipping/disposal arrangements are made.</p>
7. Dispose of samples not used for analysis.	<p>Laboratories will dispose of the portions of the samples submitted, but not used for analysis.</p> <p>If samples are retained and not sent for analysis, they need to be returned to the site prior to remediation or disposed of according to federal and state regulations.</p>





**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>SOURCE</b>	<b>HAZARDS</b>	<b>WHERE</b>	<b>HOW, WHEN, RESULT</b>	<b>CONTROLS</b>
<b>CHEMICAL</b>	Potential contact with contaminated soils and resulting water from decontamination procedures.	Sites.	Inadvertent exposure to contaminated soils and water resulting from decontamination procedures could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Employees will follow decontamination procedures as described above. Employees will wear nitrile gloves and safety glasses when handling contaminated items.
	Nitric acid.	Sites.	Employees could be exposed to nitric acid via ingestion and skin/eye contact when decontaminating equipment. Exposure could cause irritation of skin/eye and adverse health effects.	Employees will prevent skin/eye contact with nitric acid and they will wear nitrile gloves and eye protection when handling nitric acid. Employees will practice proper personal hygiene – wash hands prior to eating/drinking, after decontaminating equipment, and when leaving the site. Refer to the Chemical Flushing Guidelines available inside vehicle’s first aid kit for first-aid procedures in case of contact with nitric acid.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Improper shoveling techniques.	Sites.	Personnel could be injured if using improper shoveling techniques to store contaminated soils/cuttings in drums, causing back injuries and muscle/back strains.	Personnel will use proper shoveling techniques: keep feet wide apart, place front foot close to shovel, put weight on front foot, use leg to push shovel, shift weight to rear foot, keep load close to body, and turn feet in direction of throw.



**SOP-DE-03;  
INVESTIGATION DERIVED WASTE  
HANDLING**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 4 of 7

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

	Improper lifting.	Sites.	Back injuries and muscle/back strains could result when using improper techniques to lift and carry 5-gallon containers of tap water.	Personnel will use proper lifting techniques – get a good grip, keep the load close to the body, lift with legs and not with back, and avoid lifting loads above shoulder’s height.
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick/muddy/wet surfaces and steep slopes.	Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in falls and injuries.	Workers will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. Keep work areas as dry as possible. Wear muck boots, as necessary.
<b>WEATHER</b>	Cold/heat stress.	Sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Employees will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.
	Hypothermia/frost bite.	Sites where air temperature is 35.6°F (2°C) or less.	Workers whose clothing becomes wet during decontamination procedures may be exposed to hypothermia and/or frostbite.	Employees will change clothing, if it becomes wet.
	Lightning.	Outdoor sites.	Electrocution, injury, death, or equipment damage could be	Employees will follow the 30/30 rule during lightning storms.



**SOP-DE-03;  
INVESTIGATION DERIVED WASTE  
HANDLING**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 5 of 7

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

			caused by lightning strike.	
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Employees could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Employees will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Employees should wear sunscreen, if necessary.
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Employees with allergies will notify their supervisor.
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.
<b>SIMOPS</b>	Not applicable.			

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.
---------------------	---



**SOP-DE-03;  
INVESTIGATION DERIVED WASTE  
HANDLING**

**DATE ISSUED:**  
12/03/2014  
**REVISION:** 0  
**PAGE** 6 of 7

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>APPLICABLE SDS</b>	Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.  Nitric acid.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/ WORK PLANS</b>	SOP-DE-02 Equipment Decontamination.
<b>TOOLS</b>	Five 5-gallon buckets, tap water, stiff brushes, soap, de-ionized or distilled water, nitric acid (if required), plastic sheeting or foil, tarps, decontamination tubs and buckets, sprayers, storage containers, labels, and shovels.
<b>FORMS/CHECKLIST</b>	





**SOP-DE-03;  
INVESTIGATION DERIVED WASTE  
HANDLING**

**DATE ISSUED:  
12/03/2014  
REVISION: 0  
PAGE 7 of 7**

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>12/03/2014</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>12/03/2014</b>

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>



**SOP-S-01;  
SURFACE SOIL SAMPLING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE** 1 of 10

<b>PURPOSE</b>	To provide standard instructions for surface soil sampling.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.
<b>DEFINITIONS</b>	<u>Surface Sample</u> : a surface sample is defined as a mineral soil sample collected from immediately beneath the vegetative mat. It generally includes some interval from the upper six inches of soil. Surface sampling under biased conditions may be selected after considering factors such as type of contaminant, length of time the area has been contaminated, the type of soil, and the past use of the area.
<b>WORK INSTRUCTIONS</b>	
The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).	
<b>TASK</b>	<b>INSTRUCTIONS</b>
<b>Grab Sample</b>	
Note	Sample collection devices include stainless steel scoops or trowels, and disposable Teflon trowels. For inorganic contaminants, disposable plastic scoops will be used. The following procedure is designed to collect a surface soil sample from the 0-2 inch horizon. These procedures may be modified in the field based on field and site conditions after appropriate annotations have been made in the field log book. These procedures are <b>not to</b> be used when sampling for volatile organic compounds. The procedures for collecting volatile organic samples are described in the following sections of this SOP.
1. Identify site-specific hazards and verify utility locates.	<p>Perform utility locates or verify utility locates have been performed.</p> <p>Walk through the site and determine any site-specific hazards associated with the sampling area. Discuss findings with sampling crew and note in the field logbook.</p> <p>Verify the utility locate information by identifying where natural gas pipes or other utilities enter any structures on the property or if yard lights or street lights are present with no overhead lines. Determine if an underground sprinkling system is present, where applicable. If sample locations have not been assigned in the Sampling Analysis Plan (SAP), note the already marked and/or probable locations of underground utilities and try to avoid those areas when choosing sample locations. Also, note the location of overhead lines and overhead hazards and avoid those areas, if possible.</p> <p>If sample locations are identified in the SAP, use the appropriate survey method to</p>



**SOP-S-01;  
SURFACE SOIL SAMPLING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE 2 of 10**

	locate and mark the sample locations.
2. Dig a 6 to 12-inch square pit.	<p>Dig a 6 to 12-inch square pit to a depth of approximately 6 inches. The size and depth of the sample pit required depends on the amount of material needed for sample analysis and the interval to be sampled.</p> <p>If a sod mat is present, separate the sod mat from the mineral soil surface with the chosen sampling tool. Shake and scrape the removed sod mat over the sample collection bowl to dislodge any mineral soil particles. Place all dislodged particles in the sample. If the surface material is coarse-grained material, free of intermixed materials (i.e., graveled driveway), collect the sample from the appropriate layer below the protective barrier. However, if the graveled driveway, alley or lot contains soil/dust material on the surface, collect the sample from the appropriate interval. If the sample area is unvegetated, collect the sample material from the designated interval inches below ground surface.</p>
3. Measure and mark the interval to be sampled.	Measure the interval to be sampled (e.g., 0-2 inches or 0-6 inches) with a stainless steel tape measure or a ruler and mark the appropriate interval.
4. Scrape the walls of the sample pit.	Scrape the walls of the sample pit within the marked interval with a decontaminated stainless steel trowel or scoop, a Teflon scoop, or a disposable plastic scoop to expose a clean surface.
5. Collect the sample.	Once the wall of the test pit has been cleaned, collect the sample by scraping the appropriate interval on the cleaned face of the pit with the sampling tool and placing the material in a decontaminated stainless steel bowl, or a new cleaned foil pan.
6. Remove coarse fragments from the bowl.	Remove all coarse fragments greater than 0.5 inches from the bowl. Mix the remaining material in the bowl with the sampling tool.
7. Pack the samples.	<p>Transfer the soil sample directly into the appropriate sample container according to SOP-SA-01 Soil and Water Sample Packaging and Shipping and store in a cooler at 4°C or less.</p> <p>Any remaining sample material will be returned to the sample holes. A sufficient quantity of soil will be collected in each sample container to provide for analysis with additional soil left over to be archived.</p>
8. Record sampling information.	Record appropriate information about the sample collection in the field logbook.
9. Return all the removed dirt	Return all the removed dirt into the hole and return the sample area to pre-sampling conditions.



into the hole.	
10. Decontaminate the equipment.	Decontaminate sampling tools according to procedures outlined in SOP-DE-02 Equipment Decontamination.
<b>Composite Sampling</b>	
Note	<p>In many situations, a composite sample is more appropriate for sample collection than a grab sample. Several types of composite samples can be collected. A sampler can collect a biased composite sample by identifying specific spots within the sample area that appear to be contaminated or not contaminated and digging sample pits in those locations. Composite samples can also be collected randomly as defined in a SAP.</p> <p>Sub samples are often collected in a five-point (star) pattern. At each point, a sub sample of a predetermined depth is collected. The diagonal distance between points is commonly ten feet, depending on the area of soil homogeneity. Sub samples can also be collected in a three-point (triangular) pattern. At each point, a subsample of predetermined depth is collected. The diagonal distance between the points is commonly ten feet, depending on the area of soil homogeneity. The precise method for compositing the sample will be discussed in the SAP. Each sub sample test hole will be prepared and sampled in the manner discussed above under the Grab Sample section.</p>
1. Collect composite samples.	<p>Composite samples will consist of discrete aliquots of equal amounts of soil from each subsample location. The soil aliquots will be collected into a stainless steel bowl and thoroughly mixed.</p> <p>An alternative method of compositing soil sub samples is with a large disposable plastic or canvas sheet. The subsamples are mixed in the center of the sheet. Each corner is pulled up and toward the diagonally opposite corner. This process is done from each corner. After the soil is mixed, it is again spread out on the cloth into a relatively flat pile. The pile is quartered. A small scoop is used to collect small samples from each quarter until the desired amount of soil is acquired.</p> <p><u>Note:</u> high concentrations of organic chemicals in soils can react with the plastic sheet. The sampler may also “eyeball” an equal amount of sample material from each hole into a resealable plastic bag (i.e., Ziploc®). The sample material would be thoroughly mixed between each sub sample pit and prior to placing in the appropriate sample containers.</p>
2. Remove coarse fragments.	Remove all coarse fragments greater than 0.5 inches from the bowl. Mix the remaining material in the bowl with the sampling tool.
3. Pack the samples.	Transfer the soil sample directly into the appropriate sample container according to SOP-SA-01 Soil and Water Sample Packaging and Shipping, label the samples, and





**SOP-S-01;  
SURFACE SOIL SAMPLING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE 4 of 10**

	<p>store in a cooler at 4°C or less.</p> <p>Any remaining sample material will be returned to the sample holes. A sufficient quantity of soil will be collected in each sample container to provide for analysis with additional soil left over to be archived.</p>
4. Record sampling information.	Record appropriate information about the sample collection in the field logbook.
5. Return all the removed dirt into the hole.	Return all the removed dirt into the hole and return the sample area to pre-sampling conditions.
6. Decontaminate the equipment.	Decontaminate sampling tools according to procedures outlined in SOP-DE-02 Equipment Decontamination.
<b>Volatile Organic Sampling</b>	
1. Identify site-specific hazards and verify utility locates.	<p>Perform utility locate or verify utility locates have been performed.</p> <p>Walk through the site and determine any site-specific hazards associated with the sampling area. Discuss findings with sampling crew and note in the field logbook.</p> <p>Verify the utility locate information by identifying where natural gas pipes or other utilities enter any structures on the property or if yard lights or street lights are present with no overhead lines. If sample locations have not been assigned in the SAP, note the already marked and/or probable locations of underground utilities and try to avoid those areas when choosing sample locations. Also, note the location of overhead lines and overhead hazards and avoid those areas, if possible.</p> <p>If sample locations are identified in the SAP use the appropriate survey method to locate.</p>
2. Dig a 6 to 12-inch square pit.	<p>Dig a 6 to 12-inch square pit to a depth of approximately 6 inches. The size and depth of the sample pit required would depend on the amount of material needed for sample analysis and the interval being sampled.</p> <p>If a sod mat is present, separate the sod mat from the mineral soil surface with the chosen sampling tool. Shake and scrape the removed sod mat over the sample collection bottle to dislodge any mineral soil particles. Place all dislodged particles in the sample. If the surface material is coarse-grained material, free of intermixed materials (i.e., graveled driveway), collect the sample from the appropriate layer below the protective barrier. However, if the graveled driveway, alley or lot contains soil/dust material on the surface, collect the sample from the appropriate interval. If the sample area is unvegetated, collect the sample material from the appropriate depth below ground surface.</p>



**SOP-S-01;  
SURFACE SOIL SAMPLING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE 5 of 10**

3. Measure and mark the interval to be sampled.	Measure the interval to be sampled (e.g., 0-2 inches or 0-6 inches) with a stainless steel tape measure or a ruler and mark the appropriate interval.
4. Scrape the walls of the sample pit.	Scrape the walls of the sample pit within the marked interval with a decontaminated stainless steel trowel or scoop, a Teflon scoop, or a disposable plastic scoop to expose a clean surface.
5. Collect the sample.	<p>After the face of the test pit has been cleaned, immediately place the sampling container into the sample pit and collect the sample by scraping the appropriate interval of mineral soil directly into the sample container.</p> <p>Pack in the material as tightly as feasible and try to avoid getting large particles in the jar. The sampling container should be filled to the top with little to no headspace, and the lid placed on the container as soon as the jar is full. Place the sample immediately in a cooler at 4°C or less.</p>
6. Record sampling information.	Record appropriate information about the sample collection in the field logbook.
7. Return all the removed dirt into the hole.	Return all the removed dirt into the hole and return the sample area to pre-sampling conditions.
8. Decontaminate the equipment.	Decontaminate sampling tools according to procedures outlined in SOP-DE-02 Equipment Decontamination.



**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	<p>Potential contact with contaminated soils.</p> <p>Chemical reaction.</p>	<p>Sites.</p> <p>Sampling sites with organic contaminants. During the alternative method to collect composite soil sub samples using a large disposable plastic or canvas sheet.</p>	<p>Inadvertent exposure to contaminated soils could lead to adverse health effects.</p> <p>Adverse health effects could result from high concentrations of organic chemicals in soils, or reactions with the plastic sheet.</p>	<p>Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Employees will wear nitrile gloves and safety glasses when collecting and handling samples.</p> <p>Employees will wear Level D PPE when using this method. If sampling sites with organic contaminants, be aware of the level of exposure by using PIDs. If PID reads high levels, stop work and reassess the sampling procedures.</p>
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Contact with underground utilities.	Testing sites.	Injury, death or property damage could occur from contact with underground utilities during soil sampling.	Personnel will follow Pioneer's underground and overhead utilities corporate program and established procedures. When possible, personnel will avoid areas with underground utilities hazards.
<b>BODY MECHANICS</b>	Improper shoveling techniques.	Sites.	Personnel could be injured if using improper shoveling techniques to dig and refill the test pits causing back injuries and muscle/back strains.	Personnel will use proper shoveling techniques: keep feet wide apart, place front foot close to shovel, put weight on front foot, use leg to push shovel, shift weight to rear foot, keep load close to body, and turn feet in direction of throw.

	Improper lifting.  Bending, squatting, and kneeling.	Testing sites.  During sample collection.	Back injuries and muscle/back strains could result when using improper techniques to lift and carry tools and equipment.  Bending, squatting, and kneeling during sample collection could result in muscle/back strains or other injuries.	Personnel will use proper lifting techniques – get a good grip, keep the load close to the body, lift with legs and not with back, and avoid lifting loads above shoulder’s height. Two employees will lift objects, if necessary.  Employees should stretch prior to starting work and they will take breaks when necessary.
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick/muddy/wet surfaces and steep slopes.	Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in falls and injuries.	Workers will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. Keep work areas as dry as possible. Wear muck boots, as necessary.
<b>WEATHER</b>	Cold/heat stress.  Lightning.	Sites.  Outdoor sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.  Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Employees will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.  Employees will follow the 30/30 rule during lightning storms.



**SOP-S-01;  
SURFACE SOIL SAMPLING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE** 8 of 10

<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Employees could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Employees will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Employees should wear sunscreen, if necessary.
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Employees with allergies will notify their supervisor.
<b>MECHANICAL</b>	Pinch points and cuts.  Struck by shovel and pry bar.	Test pits.  Loading/unloading and mobilizing to the test site.	Employees could cut their fingers if the soil samples contain debris and/or sharp objects (e.g., glass, steel, etc.).  Personal injury could result if employee is struck by shovel and pry bar.	Employees will wear nitrile gloves (work gloves, if necessary) when sampling and handling soil. Workers will visually inspect the soil samples and remove any debris and/or sharp objects.  Employees will not follow too close to the person carrying the equipment. The person loading the truck must be aware of others around the trucks.
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.



**SOP-S-01;  
SURFACE SOIL SAMPLING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE 9 of 10**

<b>SIMOPS</b>	Struck by and/or caught in between heavy equipment or vehicles.	Sites.	Personnel could be injured if struck by and/or caught in between heavy equipment or vehicles while collecting samples.	Employees will communicate with the contractors on site. Personnel will avoid working near heavy equipment/vehicles, when possible. Personnel will wear high visibility clothing. When possible, personnel will park field vehicles or use traffic cones to prevent third party vehicles from coming into the work area.
---------------	---	--------	--	--

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, nitrile gloves, and leather gloves.
<b>APPLICABLE SDS</b>	Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	Map with site location and sample locations.
<b>RELATED SOPs/PROCEDURES/WORK PLANS</b>	SOP-SA-01 Soil and Water Sample Packaging and Shipping and SOP-DE-02 Equipment Decontamination.
<b>TOOLS</b>	<p>Sampling tools: stainless steel scoops or trowels, disposable Teflon trowels, disposable plastic scoops (for inorganic contaminants), stainless steel tape measure or a ruler, decontaminated stainless steel bowl or cleaned foil pan, one-quart plastic bag, sampling containers, and cooler.</p> <p>For the alternative method of compositing soil sub samples: large disposable plastic or canvas sheet, small scoop, and resealable plastic bags.</p> <p>Field logbook.</p>
<b>FORMS/CHECKLIST</b>	





**SOP-S-01;  
SURFACE SOIL SAMPLING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE** 10 of 10

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>12/11/2014</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>12/11/2014</b>

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>





**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE** 1 of 10

<b>PURPOSE</b>	To provide standard instructions for collecting subsurface soil samples.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.
<b>DEFINITIONS</b>	<p><u>Subsurface Soil Sample</u>: it is defined as a mineral soil sample collected from 6 inches to 25 feet below ground surface. The need for biased sampling of subsurface soils should be evaluated by considering factors such as the precipitation, the type of soil and the length of time the site has been contaminated. If precipitation has moved contaminants into lower soil horizons, subsurface sampling may be appropriate.</p> <p>Several techniques can be used to collect samples from 6 inches to four or five feet below ground surface (bgs). A shovel and pry bar can be used to collect samples from 6 inches to 2 feet bgs. A hand auger may be used to collect subsurface samples up to four or five feet in depth. Because the auger is twisted into the soil the soil's cohesive structure and stratigraphic character are destroyed. An in situ soil recovery auger may also be used to collect subsurface samples up to five feet. The auger accommodates a liner and provides fast cutting of the soil with very little soil disturbance. In particularly rocky or hard soils a back hoe may be needed to excavate even shallow test pits. It is important to evaluate site conditions prior to choosing a subsurface sampling method. Each method of sampling will be discussed below.</p>

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SDS will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

TASK	INSTRUCTIONS
<b>Hang Dug Test Pits</b>	
1. Coordinate utility locates.	Prior to site entry have a utility locate performed.
2. Locate sample site.	Locate the site as directed in the appropriate Sampling and Analysis Plan (SAP).
3. Conduct site walk.	Conduct a site walk through and determine any site-specific hazards associated with the sampling area. Discuss these with the sampling crew and note in the field logbook. During the site walk through note possible locations for underground utilities. For example, identify where natural gas pipes enter any structures on the property or if yard lights or street lights are present with no overhead lines. If sample locations have not been assigned in the SAP, note the probable locations of



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE 2 of 10**

	underground utilities and try to avoid those areas when choosing sample locations. If sample locations are identified in the SAP use the appropriate survey method to locate.
4. Dig test pit.	Dig a 6 to 12-inch square pit to the depth specified in the SAP plus an additional 3 to 4 inches.
5. Identify sample intervals.	Measure the interval to be sampled with a stainless steel tape measure or a ruler and mark the appropriate interval.
6. Prepare sample location.	Scrape the walls of the sample pit within the marked interval with a decontaminated stainless steel trowel or scoop, a Teflon scoop, or a disposable plastic scoop to expose a clean surface.
7. Collect samples.	Place a stainless steel bowl or a clean decontaminated disposable foil pan adjacent to or in the sample pit and collect the sample by scraping the appropriate interval on the cleaned face of the pit with the sampling tool. If more than one interval is to be collected from the hole, collect the bottom or deepest interval first. If sampling for volatile organic compounds, the soil must be placed directly into the sample container with no head space and placed into a cooler with ice immediately.
8. Remove unnecessary material from sample.	Remove all coarse fragments greater than 0.5 inches from the bowl. Mix the remaining material in the bowl with the sampling tool.
9. Transfer sample to sample container.	Transfer the soil sample directly into the appropriate sample container according to SOP-SA-01 Soil and Water Sample Packaging and Shipping. Store samples in a cooler at 4°C or less.
10. Document sample information.	Record appropriate information about the sample and collection in the field logbook.
11. Decontaminate sampling tools.	Decontaminate sampling tools according to procedures outlined in SOP-DE-02 Equipment Decontamination.
<b>Hand Auger Sampling</b>	
1. Coordinate utility locates.	Prior to site entry have a utility locate performed.
2. Locate sample site.	Locate the site as directed in the appropriate Sampling and Analysis Plan (SAP).
3. Conduct site	Conduct a site walk through and determine any site-specific hazards associated with



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE** 3 of 10

walk.	the sampling area. Discuss with the sampling crew and note in the field logbook. During the site walk through note possible locations for underground utilities. For example identify where natural gas pipes enter any structures on the property or if yard lights or street lights are present with no overhead lines. If sample locations have not been assigned in the SAP, note the probable locations of underground utilities and try to avoid those areas when choosing sample locations. If sample locations are identified in the SAP use the appropriate survey method to locate. Note the locations of overhead lines and overhead hazards and avoid those areas if possible.
4. Auger sample hole.	Place a large piece of plastic adjacent to the sample location. Choose the appropriate auger head for the soil type at the sample site (i.e., sand, mud, normal). Measure the length of the auger head to determine the advancement depth for each full auger. Place the auger at the sample location and begin turning, when the head is full remove the auger from the hole and empty the head onto the plastic. Measure the hole depth to determine the number of auger heads needed to reach the sample interval. Keep auguring and emptying the soil onto the plastic sheet until the top of the sampling interval is reached. The soil can be placed on the sheet in the order of removal for a general soil profile.
5. Collect sample.	Place a stainless steel bowl or a clean decontaminated disposable foil pan near the sample pit (preferably on a clean portion of the plastic) and collect the sample by emptying the auger head into the bowl or pan. Continue auguring and emptying the auger head into the sampling container throughout the entire sampling interval. If sampling for volatile organic compounds, the soil must be placed directly into the sample container with no head space and placed into a cooler with ice immediately.
6. Remove unnecessary material from sample.	Remove all coarse fragments greater than 0.5 inches from the bowl. Mix the remaining material in the bowl with the sampling tool.
7. Transfer sample to sample container.	Transfer the soil sample directly into the appropriate sample container according to SOP-SA-01 Soil and Water Sample Packaging and Shipping. Store samples in a cooler at 4°C or less.
8. Document sample information.	Record appropriate information about the sample and collection in the field logbook.
9. Decontaminate sample tools.	Decontaminate sampling tools according to procedures outlined in SOP-DE-02 Equipment Decontamination.



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE** 4 of 10

<p><b>In-Situ Soil Recovery at Depths Greater than Five Feet</b> A direct push soil recovery rig mounted on a truck or trailer is the most common method for the In-Situ Soil Recovery at Depths Greater than Five Feet and can be used to sample up to 75 feet or more in depth. There are also several types of hand augers with liner tubes that can be used for sampling up to 5 feet depending on soil type. The steps described in this section are for sampling from the liner tube.</p>	
1. Coordinate utility locates.	Prior to site entry have a utility locate performed.
2. Locate sample site.	Locate the site as directed in the appropriate Sampling and Analysis Plan (SAP).
3. Conduct site walk.	Walk through the site and determine any site-specific hazards associated with the sampling area. Discuss these with the sampling crew and note in the field logbook. During the site walk through note possible locations for underground utilities, for example identify where natural gas pipes enter any structures on the property or if yard lights or street lights are present with no overhead lines. If sample locations have not been assigned in the SAP, note the probable locations of underground utilities and try to avoid those areas when choosing sample locations. If sample locations are identified in the SAP, use the appropriate survey method to locate.
4. Probing or augering the sample hole.	Actual augering or drilling of the sampling holes will be conducted following the subcontractor's SOPs and safety protocols.
5. Collect sample.	As the plastic, Teflon or stainless steel liner is removed from the drill rod, make sure that the "top" of the liner, which represents the upper intervals is identified. If entire liner is being submitted for analysis seal both ends and mark the liner with the appropriate sample number and information. Place in a cooler and store at 4°C or less. If individual sample containers need to be collected or a composite sample over several intervals is to be collected place the liner on a work surface (portable table or plastic tarp on the ground). Cut the liner tube along its length. Label the top and bottom of the liner with the appropriate depths, index cards or pieces of paper placed at the top and bottom are acceptable. Photograph the core. Measure the amount of material present in the liner and if specified in the site-specific sampling plan log the core.
6. Prepare sample.	<p>Place a stainless steel bowl or a clean decontaminated disposable foil pan near the liner. Using a decontaminated stainless steel trowel or scoop, a Teflon scoop, or a disposable plastic scoop remove the appropriate interval from the liner and put it in the bowl/pan.</p> <p>If sampling for volatile organic compounds, place the soil directly into the appropriate sampling container, fill the container so that there is no head space, seal and place in a cooler with ice immediately.</p> <p>For all other analyses remove all coarse fragments greater than 0.5 inches from the bowl. Mix the remaining material in the bowl with the sampling tool.</p>



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:  
05/22/2015  
REVISION: 0  
PAGE 5 of 10**

7. Transfer sample to sample container.	Transfer the soil sample directly into the appropriate sample container according to SOP-SA-01 Soil and Water Sample Packaging and Shipping. Store samples in a cooler at 4°C or less.
8. Document sample information.	Record appropriate information about the sample and collection in the field logbook.
9. Decontaminate sample tools.	Decontaminate sampling tools according to procedures outlined in SOP-DE-02 Equipment Decontamination.



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE** 6 of 10

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated soils.	Sample collection sites.	Inadvertent exposure to contaminated soils could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating and when leaving the site. Work will be suspended during high wind conditions that may produce large amounts of visible dust. Personnel will wear nitrile gloves and safety glasses when sampling and handling soil.
<b>NOISE</b>	Elevated noise levels.	Mechanized probing rig.	Personnel collecting soil samples can be exposed to elevated noise levels from the mechanized probing rig resulting in hearing damage.	Personnel collecting soil samples will set up the sampling station 25 feet away from the rig. The rig operator or helper will bring the plastic liner to the sampling station.
<b>ELECTRICAL</b>	Contact with underground utilities.  Contact with overhead utilities.	Testing sites.  Testing sites.	Serious injury could result from contact with a live buried utility.  Walking near low hanging overhead utilities and generators on site could result in electrocution, shock, and burn due to contact or flashover.	Established ground disturbance procedures, as outlined in the Pioneer Corporate HASP will be followed.  Visually inspect the sample location/yard prior to accessing. If overhead hazards are present, established overhead utility procedures will be followed. When possible, employees will avoid areas with overhead hazards.
<b>BODY MECHANICS</b>	Bending, squatting and kneeling.	During sample collection.	Bending, squatting and kneeling during sample collection and handling could result in	Personnel should stretch prior to starting work and they will take breaks when necessary. Personnel will use a foam pad or knee pads, if necessary.



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE** 7 of 10

	Lifting and carrying tools, equipment, and/or samples.	Testing sites.	muscle/back strains or other injuries. Kneeling on gravel can result in bruises and knee injuries.  Improper lifting and carrying tools, equipment, and/or samples could result in back injuries and muscle/back strains.	Personnel will use proper lifting techniques – get a good grip, keep the load close to the body, lift with legs and not with back, and avoid lifting loads above shoulder’s height. Two people will lift, if necessary.
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick surfaces and steep slopes.	Workers could get injured if they fall causing bruises, scrapes, or broken bones.	Workers will wear work boots with good traction and ankle support. Workers will plan their path and walk cautiously. Access areas will be established, if necessary.
<b>WEATHER</b>	Cold/heat stress.  Lightning.	Sites.  Testing sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.  Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Training on signs and symptoms of cold/heat stress. Personnel will wear appropriate clothing when working outdoors. Personnel will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.  Employees will follow the 30/30 rule during lightning storms.
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Employees could be exposed to UV radiation during summer months causing sun	Employees will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Employees should wear sunscreen, if necessary.





**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE** 8 of 10

			burns, skin damage, and eye damage.	
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Employees with allergies will notify their supervisor.
<b>MECHANICAL</b>	Pinch points.	Test pits.	Employees could cut their fingers if debris (e.g., glass, steel) is present in test pits. Personal injury to the hands could occur when using sampling equipment/tools.	Employees will wear nitrile gloves when sampling and handling soil. Employees will wear leather gloves while using sampling tools.
	Struck by shovel or auger.	Carrying tools.	Personnel can strike other workers or objects when carrying shovels and augers to/from sampling stations resulting in bodily injuries and/or property damage.	Personnel will be aware of their surroundings and, if needed, use a spotter. When carrying tools, maintain a safe distance (e.g., 4 feet or more depending on side of tool) from other workers.
	Hand injuries.	Liner cutter.	Employees could be exposed to hand injuries such as lacerations, punctures, and cuts when using the liner cutter and handling the cut liner.	Employees will wear work gloves when using the liner cutter. Be cautious of sharp edges when handling plastic core liners after they have been cut open.  Workers will be trained on how to properly use the liner cutter. Two employees will cut liners,



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:**  
05/22/2015  
**REVISION:** 0  
**PAGE** 9 of 10

				if needed.
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.
	Public entering the work area.	Sites.	Third party members of the public could enter the work area resulting in an unsafe work environment.	Stop work if members of the public enter the work area.
<b>SIMOPS</b>	Not applicable.			

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, nitrile gloves, and leather gloves.
<b>APPLICABLE SDS</b>	Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.



<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	Map with site location and sample locations.
<b>RELATED SOPs/PROCEDURES/</b>	SOP-SA-01 Soil and Water Sample Packaging and Shipping and SOP-DE-02 Equipment Decontamination.



**SOP-S-02;  
SUBSURFACE SOIL  
SAMPLING**

**DATE ISSUED:  
05/22/2015  
REVISION: 0  
PAGE 10 of 10**

<b>WORK PLANS</b>	
<b>TOOLS</b>	Sampling tools (e.g., shovel, breaker bar, ruler, hand auger, plastic sheeting, trowel, sample containers, liner cutter, bowls, and camera) and field logbook. Decontamination equipment and fluids.
<b>FORMS/CHECKLIST</b>	

<b>APPROVALS/CONCURRENCE</b>	
By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.	
<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>05/22/2015</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>05/22/2015</b>

**Revisions:**

Revision	Description	Date



**SOP-S-06  
TEST PIT SAMPLING**

**AUTHORIZED  
VERSION:**  
11/20/2020  
**PAGE 1 of 16**

<b>PURPOSE</b>	To provide standard instructions for mechanically excavated test pit sampling.
<b>SCOPE</b>	Pioneer Technical Services, Inc. (Pioneer) prepared this practice for the workforce and this Standard Operating Procedure (SOP) applies to all work performed by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent (as defined by OSHA) in the risk-assessed procedure described below before performing the work.
<b>DEFINITIONS</b>	<b>Test Pit Sampling:</b> a backhoe or excavator can be used effectively to sample soil from 0 to 25 feet or more below ground surface (bgs). Particularly in rocky or hard soil, a backhoe may be the most effective means of sampling shallow depths. Test pit sampling can be classified as either shallow test pit sampling or deep test pit sampling.
<b>WORK INSTRUCTIONS</b>	
The following instructions provide guidance to perform the task in a safe, accurate, and reliable manner. If these instructions present information that is inaccurate or unsafe, personnel must notify the Project Manager, Safety Manager, and the SOP Technical Author to initiate appropriate revisions. Personnel will perform all work under this SOP in a manner that is consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plans (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).	
<b>TASK</b>	<b>INSTRUCTIONS</b>
<b>Shallow Test Pit Sampling – 0 to 4 feet, Inorganic Sampling</b>	
<b>Definition</b>	Shallow test pits are defined as those excavated pits that are less than 4 feet deep.
<b>Notes</b>	Most excavation companies have their own SOPs for excavations. Pioneer SOPs and safety requirements should be communicated and understood by all parties prior to site entry and the sampling protocols adjusted accordingly. Prior to beginning excavation, on-site safety protocol for excavation and sampling will be reviewed by the excavator operator and sampling crew.
<b>1. Verify utility locates.</b>	Confirm that the excavation subcontractor has placed a utility locate ticket that covers the area to be sampled. Confirmation number needs to be provided to Pioneer and put on the Job Risk Assessment or corresponding safety or permit form. Utility locates need to be called in a minimum of 48 business hours prior to the planned excavation.
<b>2. Conduct site walk.</b>	Conduct a site walk-through and determine any site-specific hazards associated with the sampling area. Discuss these with the sampling crew and note them in the field logbook and Job Risk Assessment or corresponding safety form.  As part of the site hazard assessment, identify possible locations for unidentified, privately installed underground utilities. For example, identify where natural gas pipes enter any structures on the property and confirm that gas lines from the street/alley



	<p>have been marked. Check on yard lights or streetlights that are present with no overhead lines, underground wiring from a residence to outbuildings, or a possible gas line to a grill or outdoor kitchen.</p>
<p><b>3. Identify potential sample sites.</b></p>	<p>Verify that the ground has been marked with the location of underground utilities listed on the locate ticket from the excavation subcontractor. Locate potential sample sites as directed in the appropriate Sampling and Analysis Plan (SAP) or Work Plan (WP). Use an appropriate survey method to locate and mark the sample locations if required. If sample locations are not specifically identified in the SAP, follow the guidance in the SAP and chose and mark sample locations.</p> <p>If needed, adjust sample locations based on identified or potential utility locations. Refer to the Trenching, Excavation, and Ground Disturbance Program information in Pioneer’s Corporate HASP to identify safe distances for digging when adjacent to specific buried utilities.</p>
<p><b>4. Excavate test pit.</b></p>	<p>The decontaminated backhoe or excavator (refer to <b>Decontaminate sampling tools and excavator</b> on page 3) will excavate the test pit to the desired depth, or to a maximum of 4 feet. The excavated material should be layered adjacent to the test pit in the sequence in which it is removed. Topsoil should be separated from the underlying layers. Removed soil should be placed a minimum of 3 feet from the final edge of the test pit. If the total depth of the test pit is less than 4 feet, the test pit should have 1 vertical smooth wall for sample collection and 1 sloping or stepped wall for entrance into the test pit. The OSHA-defined competent person will examine the test pit and determine if the test pit is safe prior to entering. The competent person will examine test pit wall stability, check for the presence of water, and check that there is a means of exit provided into and out of the test pit.</p>
<p><b>5. Identify sample intervals.</b></p>	<p>Using a shovel, scrape the walls of the test pit to clean off smear associated with the digging. Determine an area(s) for sampling. If the soil types and layering is fairly homogeneous on all walls of the test pit, choose a representative wall to sample. If soil types or layering is not similar on all walls, choose representative areas to include in the sample intervals.</p> <p>Sample collection will take place in the test pit at intervals specified in the site-specific SAP. Measure and mark the intervals in the area(s) selected for sampling: pin flags, nails, or a measuring stick placed vertically on the sampling wall can be used to identify the intervals. Measurement for sample intervals should begin just below the sod or root mass, where soil is first available.</p>
<p><b>6. Collect soil samples.</b></p>	<p>The deepest sample interval should be scrapped with a decontaminated stainless-steel trowel or scoop, a Teflon scoop, or a new disposable plastic scoop to expose a clean surface.</p> <p>Once a new face is exposed, scrape the cleaned interval with the sampling tool and place the soil in a stainless-steel bowl, a new disposable foil pan, or a resealable plastic bag. Make sure that the collection container is compatible (will not affect) with any analytes for which the sample will be analyzed. Take care to avoid material from above falling into the collected sample, sample bowl, or onto the sampling tool. If</p>



**SOP-S-06  
TEST PIT SAMPLING**

**AUTHORIZED  
VERSION:**  
11/20/2020  
**PAGE 3 of 16**

	more than one area was identified as representative for this interval, equal aliquots of soil should be collected from each location and placed in the sample collection container.
<b>7. Remove unnecessary material from sample.</b>	Remove all coarse fragments greater than 0.5 inches from the bowl. Thoroughly mix the remaining soil in the bowl/pan with the sampling tool or by kneading in the bag.
<b>8. Transfer sample to sample container.</b>	<p>Label all sample containers following the requirements in the associated SAP/WP. Using the sampling tool, fill all required sample containers. Place a sufficient quantity of soil in each sample container to provide for analysis with additional soil left over to be archived. Return any remaining sample material to the test pit.</p> <p>Immediately place the soil samples directly into the designated storage container (generally a cooler). If samples are required to be stored at 4 degrees Celsius (°C) or less by the SAP/WP or analytical method, add ice to the cooler. Samples should be kept under chain of custody protocols until transport to the laboratory, as described in SOP-SA-01 Soil and Water Sample Packaging and Shipping.</p>
<b>9. Document sample information.</b>	Record appropriate information about the sample collection (sample numbers and associated depth interval, time, date, sample containers, etc.) in the field logbook as discussed in SOP-SA-05 Project Documentation. Record additional information such as soil type and rock content if required by the SAP/WP.
<b>10. Sample remaining depth intervals.</b>	If additional sample intervals need to be collected, working from the bottom or deepest interval to the top interval, complete Steps 6-9, above, for each sample interval.
<b>11. Log the test pit stratigraphy.</b>	<p>If required by the SAP/WP, examine and log the soil and material in the wall of the test pit. If samples were collected from more than one area, make notes on the differences in soil types from one area to another. Check the project-specific documents for the amount of detail or type of information required for the test pit log. Pioneer has developed several different field data sheets to aid in collecting the correct information during test pit logging.</p> <p>If required by the SAP/WP, photograph the sampled wall of the test pit with the sample interval markers in place or the measuring stick for scale. Take close-up pictures of any areas of interest. Take a photograph of the marked location stake or pin flag prior to photographing the test pit to aid identification of photographs later.</p>
<b>12. Backfill test pit.</b>	Once sampling and logging are complete, the test pit should be back filled by the equipment operator. Soil should be placed in the test pit in the geologic sequence in which it was removed. Topsoil should always be placed last and smoothed out to match the surrounding terrain as closely as possible.
<b>13. Decontaminate sampling tools and excavator.</b>	Decontaminate sampling tools (shovel, trowels, bowls) according to procedures outlined in SOP-DE-02 Equipment Decontamination. If the SAP/WP requires the



	<p>backhoe or excavator bucket to be cleaned between holes, have the operator decontaminate the bucket as defined in their SOPs.</p> <p>If decontamination is not required but there is a large amount of material remaining on the excavator bucket due to muddy or clay soil, use a shovel, broom, and buckets of water to rinse the excavator bucket prior to moving to a new excavation location.</p>
<p><b>Test Pit Sampling Below 4 Feet, Inorganic Sampling</b></p>	
<p><b>Note</b></p>	<p><b>Personnel will not enter test pits that are over 4 feet in depth at Remediation Management (RM) sites and 5 feet for non-RM sites.</b></p> <p>Sample material from test pits over 4 feet in depth (4 feet at RM sites, 5 feet at non-RM sites) can be collected from soil piles removed and placed by the equipment. If necessary, samples will be collected from the equipment bucket once it has been placed on the ground and the equipment powered down.</p> <p>Most excavation companies have their own SOPs for excavations. Pioneer SOPs and safety requirements should be communicated and understood by all parties prior to site entry and the sampling protocols adjusted accordingly. Prior to beginning excavation, on-site safety protocols for excavation and sampling will be reviewed by the excavator operator and sampling crew.</p>
<p><b>1. Sample test pit to 4 feet.</b></p>	<p>For test pits up to 4 feet in depth, follow Steps 1-11 above, under <b>Shallow Test Pit Sampling – 0 to 4 feet, Inorganic Sampling</b>, to collect samples.</p>
<p><b>2. Sample test pit over 4 feet: Excavate test pit.</b></p>	<p>To sample test pits deeper than 4 feet, the sampling crew must move a safe distance from the machine. Once the sampling crew is at a safe distance, the machine operator will continue excavating the test pit to the desired depth. The excavated material should be layered adjacent to the test pit in the sequence in which it is removed (spoils piles). Removed soil should be placed a minimum of 3 feet from the final edge of the test pit. Samplers should observe carefully where material from each interval is placed. To ask questions on depth or examine material in the bucket or spoils piles, first signal the machine operator to stop digging. Once the bucket is safely on the ground, ask questions or examine material in the bucket or spoils piles.</p>
<p><b>3. Measure depth of test pit.</b></p>	<p>Use a cloth reel type tape measure to safely measure total depth and depth to respective sample intervals. Either the sampler or the machine operator can throw the end of the tape measure over the edge of the test pit and a sampler on the other side can indicate when the end is at the bottom, the base of a specific layer or interval, or depth to groundwater. While not necessarily precise, this will give you an idea of the total depth and potential sample intervals. This method must be used whenever a test pit is greater than 6 feet deep or the sides of a shallower test pit have cracks or are caving. Both samplers need to stand at least 6 feet away from their respective edges and further if the sides of the pit appear unstable.</p>
<p><b>4. Collect soil samples.</b></p>	<p>Collect samples from the test pit at intervals specified in the site-specific SAP.</p>





**SOP-S-06  
TEST PIT SAMPLING**

**AUTHORIZED  
VERSION:**  
11/20/2020  
**PAGE 5 of 16**

	<p>To collect samples using the backhoe or excavator as a sampling tool, one member of the sampling team needs to carefully observe the excavation process and indicate to the equipment operator which buckets of soil should be placed aside for subsequent sampling. The decision on what soil to sample will be based on information in the SAP, which may require samples based on depths, color, or lithologic changes. If sampling based on depth is required, the above method for measuring depths can be performed several times during excavation to identify what spoils piles will need to be sampled. If required, the machine operator can place soil from a specific interval in a separate location for sampling.</p> <p>Once test pit excavation is complete and the equipment has powered down, collect the samples from the placed piles of soil. Use a decontaminated stainless-steel trowel or scoop, a Teflon scoop, or a new disposable plastic scoop to clean the surface of the pile to be sampled if it appears to have soil other than the designated interval on the surface. Take care to get soil from the appropriate interval.</p> <p>To collect smaller amounts, place the soil in a stainless-steel bowl, a clean decontaminated disposable foil pan, or in a resealable plastic bag. Soil from several different places in the pile can be collected to provide a more representative sample of the interval. If a large amount of soil is needed for analysis, such as for a proctor analysis, use a clean shovel to place soil directly into a sample container.</p>
<p><b>5. Remove unnecessary material from sample.</b></p>	<p>Remove all coarse fragments greater than 0.5 inches from the bowl. Thoroughly mix the remaining soil in the bowl/pan with the sampling tool or by kneading in the bag.</p>
<p><b>6. Transfer sample to sample container.</b></p>	<p>Label all sample containers following the requirements in the associated SAP/WP. Using the sampling tool, fill all required sample containers. Place a sufficient quantity of soil into each sample container to provide for analysis with additional soil left over to be archived. Return any remaining material to the test pit.</p> <p>Immediately place the soil samples directly into the designated storage container (generally a cooler). If the SAP/WP or analytical method requires that samples be stored at 4 °C or less, add ice to the cooler. Samples should be kept under chain of custody protocols until transport to the laboratory as described in SOP-SA-01 Soil and Water Sample Packaging and Shipping.</p>
<p><b>7. Collect remaining sample intervals.</b></p>	<p>If more than 1 sample interval is to be sampled, use new or decontaminated sampling tools for each sample interval. Repeat Steps 4-6 above to collect all required samples from their respective spoils pile.</p>
<p><b>8. Document sample information.</b></p>	<p>Record appropriate information about the sample collection (sample numbers and associated depth interval, time, date, sample containers, etc.) in the field logbook as discussed in SOP-SA-05 Project Documentation. Record additional information such as soil type or rock content if required by the SAP/WP. Record appropriate information about the sample collection in the field logbook.</p>



<p><b>9. Log the test pit stratigraphy.</b></p>	<p>If required by the SAP/WP, examine the soil and material in the spoils piles from the test pit and log the observations. Measure the intervals associated with each spoils pile in the test pit following the directions in Step 3. Measure the depth of the test pit. Check the project-specific documents for the amount of detail or type of information required for the test pit log. Pioneer has developed several different field data sheets to aid in collecting the correct information during test pit logging.</p> <p>If required by the SAP/WP, photograph the test pit, with the tape measure still draped on the wall for scale. Take close-up pictures of any areas of interest. Take a photograph of the marked location stake or pin flag prior to photographing the test pit to aid identification of photographs later.</p>
<p><b>10. Backfill test pit.</b></p>	<p>Once sampling and logging are complete, the test pit should be back filled by the equipment operator. Soil should be placed in the test pit in the geologic sequence in which it was removed. Topsoil should always be placed last and smoothed out to match the surrounding terrain as closely as possible.</p>
<p><b>11. Decontaminate sampling tools and excavator.</b></p>	<p>Decontaminate sampling tools (shovel, trowels, bowls) and excavator according to procedures outlined in SOP-DE-02 Equipment Decontamination. If the SAP/WP requires the backhoe or excavator bucket to be cleaned between holes, have the operator decontaminate the bucket as defined in their SOPs.</p> <p>If decontamination is not required but there is a large amount of material remaining on the excavator bucket due to muddy or clay soil, use a shovel, broom, and buckets of water to rinse the excavator bucket prior to moving to a new excavation location.</p>
<p><b>Sampling Test Pits for Volatile Organic Compounds</b></p>	
<p><b>1. Identify site-specific hazards and verify utility locates.</b></p>	<p>Following Steps 1-3 under <b>Shallow Test Pit Sampling – 0 to 4 feet, Inorganic Sampling</b>, prepare to sample site.</p>
<p><b>2. Prepare the sample containers.</b></p>	<p>Based on information provided in the SAP/WP, prepare and label the appropriate sample containers. If organic samples are required, sample intervals may have been assigned in the SAP/WP, or samples may be collected based on photoionization detector (PID) or headspace readings or the presence of odor or staining. You must understand sample collection protocol before digging. This is particularly important when collecting samples to analyze volatile organic compounds (VOCs), volatile petroleum hydrocarbon (VPH), and/or extractable petroleum hydrocarbon (EPH). Ensure required sampling supplies are close at hand prior to starting to dig.</p>
<p><b>3. Excavate through to first sample interval.</b></p>	<p>Be aware of wind direction and, if possible, have the operator position the machine so that exhaust from the machine is blowing away from the test pit.</p> <p>If the sample intervals are defined in the SAP/WP, have the excavator dig to the base of the first sample interval. If sample collection is dependent on PID readings, staining, or odors, have the operator dig 1 foot. The excavated material should be</p>



**SOP-S-06  
TEST PIT SAMPLING**

**AUTHORIZED  
VERSION:**  
11/20/2020  
**PAGE 7 of 16**

	layered adjacent to the test pit in the sequence in which it is removed. Topsoil should be separated from the underlying layers. Removed soil should be placed a minimum of 3 feet from the final edge of the test pit.
<b>4. Clean wall of test pit.</b>	Using a shovel, scrape the walls of the test pit to clean off smear associated with the digging.
<b>5. Conduct PID readings if required.</b>	<p><b>All samples to be analyzed for VOCs and VPH must be collected as quickly as possible after exposing the soil to the air.</b> If specified in the SAP/WP, use a PID to take readings of the test pit walls, refer to SOP-FM-01 Field Headspace Analysis and VOC Measurements with PID.</p> <p>Exhaust may influence the PID readings. If positioning the machine so that the exhaust is blowing away from the test pit is not possible, record background readings for the test pit prior to entering and measuring each interval.</p>
<b>6. Determine sample interval.</b>	<p>If samples are to be collected based on PID measurements or the presence of staining or odors in the test pit walls, use professional judgement about digging deeper prior to collecting samples. It may be necessary to have the operator dig the next foot, prior to making a sampling decision. If the previously exposed area is included in the sample, that area needs to be recleaned and scraped to ensure a fresh surface is included in the sample.</p> <p>Mark sample intervals in the area(s) selected for sampling using pin flags, nails, or a measuring stick placed vertically on the sampling wall. Measurement for sample intervals should begin just below the sod or root mass, where soil is first available.</p>
<b>7. Collect soil samples for VOC/VPH/ EPH.</b>	<p>Collect the samples to be analyzed for VOC, VPH, and EPH using a stainless-steel trowel or scoop or a new disposable plastic scoop. Make sure to scrape the wall with the sampling tool to reveal a fresh surface prior to sampling. If the entire sample interval is represented in the test pit wall, place a representative aliquot of the soil from the wall directly into the sample container and fill the jar to the top allowing no head space (or as the laboratory directs). Pack the material as tightly as feasible and try to avoid getting large particles in the jar. Place the lid on the container as soon as the jar is full.</p> <p>Immediately place the filled sample container in a cooler with ice. Keep samples at 4 °C or less and under chain of custody protocols until they can be transported to the laboratory for analysis as described in SOP-SA-01 Soil and Water Sample Packaging and Shipping.</p> <p><b>Sampling for non-organic constituents can be completed later once VOC sampling is completed.</b></p>
<b>8. Continue sampling to 4 feet bgs.</b>	Continue excavating foot by foot until the test pit reaches 4 feet bgs. Continue PID screening and required sampling as each foot is uncovered. This is done to limit the amount of time soil is exposed to air prior to PID measurements and sample collection.



**SOP-S-06  
TEST PIT SAMPLING**

**AUTHORIZED  
VERSION:**  
11/20/2020

**PAGE 8 of 16**

	<p>Additionally, use the PID to monitor the breathing zone in the test pit to ensure that the air present during sampling (particularly at the 3- and 4-foot intervals) is safe enough to complete sampling. If PID concentrations show it is not safe to sample those intervals from the test pit, collect samples from the appropriate spoils piles.</p>
<p><b>9. Record PID readings and VOC sample information in logbook.</b></p>	<p>When using a PID, record the results of the screening in the field documentation (project logbook or field data sheets), including the highest reading from the sample interval.</p> <p>Record the sample information in the logbook and include sample number, associated depth interval, time, date, and type of containers collected, as discussed in SOP-SA-05 Project Documentation.</p>
<p><b>10. Collect inorganic samples.</b></p>	<p>Following Steps 5-11 under <b>Shallow Test Pit Sampling – 0 to 4 feet, Inorganic Sampling</b>, collect the inorganic samples, log and photograph the test pit if required, and record inorganic sample information.</p>
<p><b>11. Excavate test pit below 4 feet bgs.</b></p>	<p>Once samples to the 4-foot depth have been collected and logged and the sampling crew has moved a safe distance from the machine, the machine operator can continue excavating the test pit in 1- to 2-foot intervals. The excavated material should be layered adjacent to the test pit in the sequence in which it is removed (spoils piles). Removed soil should be placed a minimum of 3 feet from the final edge of the test pit. Samplers should observe carefully where material from each interval is placed.</p>
<p><b>12. Conduct PID readings if required.</b></p>	<p><b>All samples to be analyzed for VOCs and VPH must be collected as quickly as possible after exposing the soil to the air.</b> If specified in the SAP/WP, use a PID to take readings of the spoils pile. You can also take the PID readings from soil in the machine bucket; <b>make sure that the operator places the bucket on the ground, powers down the equipment, and signals you prior to approaching the bucket.</b> Refer to SOP-FM-01 Field Headspace Analysis and VOC Measurements with PID.</p> <p>Exhaust may influence the PID readings. If positioning the machine so that the exhaust is blowing away from the test pit is not possible, record background readings for the test pit prior to measuring each interval.</p>
<p><b>13. Collect soil samples.</b></p>	<p>Collect samples from the spoils pile or machine bucket at intervals specified in the SAP. The decision on what soil to sample will be based on information in the SAP, which may require samples based on PID measurements, depths, staining, odor, color, or lithologic changes.</p> <p>To collect samples using the backhoe or excavator as a sampling tool, one member of the sampling team must carefully observe the excavation process and indicate to the equipment operator which buckets of soil should be placed aside for PID measurements and subsequent sampling. If sampling based on depth is required, follow the method for measuring depths described in Step 3 - <b>Test Pit Sampling Below 4 Feet, Inorganic Sampling</b>; this can be performed several times during excavation to identify what spoils piles will need to be sampled.</p>



	<p>Excavating and collecting samples to be analyzed for VOCs should be completed 1 to 2 feet at a time. Once the appropriate interval has been excavated and the equipment has powered down, collect the samples from the placed piles of soil. Use a decontaminated stainless-steel trowel or scoop, a Teflon scoop, or a new disposable plastic scoop to clean the surface of the pile to be sampled. Take care to collect soil from the appropriate interval.</p> <p>Collect the required samples for VOC, VPH, and EPH analysis using a stainless-steel trowel or scoop or a new disposable plastic scoop. Make sure to scrape the spoils pile with the sampling tool to reveal a fresh surface prior to sampling. Place the representative soil directly into the sample container and fill the jar to the top allowing no head space (or as the laboratory directs). Pack the material as tightly as feasible and try to avoid getting large particles in the jar. Place the lid on the container as soon as the jar is full.</p> <p>Immediately place the filled sample containers in a cooler with ice. Keep samples at 4 °C or less and under chain of custody protocols until they can be transported to the laboratory for analysis, as described in SOP-SA-01 Soil and Water Sample Packaging and Shipping.</p> <p>Sampling for non-organic constituents can be completed later, once VOC sampling is completed.</p>
<p><b>14. Continue sampling to 4 feet bgs.</b></p>	<p>Continue excavating foot by foot until the test pit reaches the required depth. Continue PID screening and required sampling as each interval is uncovered. This is done to limit the amount of time soil is exposed to air prior to PID measurements and sample collection.</p>
<p><b>15. Record PID readings and VOC sample information in logbook.</b></p>	<p>When using a PID, record the results of the screening in the field documentation (project logbook or field data sheets), including the highest reading from the sample interval.</p> <p>Record the sample information in the logbook and include sample number, associated depth interval, time, date, and type of containers collected as discussed in SOP-SA-05 Project Documentation.</p>
<p><b>16. Collect inorganic samples.</b></p>	<p>Following Steps 4-9, <b>Test Pit Sampling Below 4 Feet, Inorganic Sampling</b>, collect the inorganic samples, log and photograph the test pit if required, and record inorganic sample information.</p>
<p><b>17. Backfill test pit.</b></p>	<p>Once sampling and logging are complete, the test pit should be back filled by the equipment operator. Soil should be placed in the test pit in the geologic sequence in which it was removed. Topsoil should always be placed last and smoothed out to match the surrounding terrain as closely as possible.</p>
<p><b>18. Decontaminate sampling tools and excavator.</b></p>	<p>Decontaminate sampling tools (shovel, trowels, bowls) and excavator according to procedures outlined in SOP-DE-02 Equipment Decontamination. If the SAP/WP requires the backhoe or excavator bucket to be cleaned between holes, have the operator decontaminate the bucket as defined in their SOPs.</p>



**SOP-S-06**  
**TEST PIT SAMPLING**

**AUTHORIZED**  
**VERSION:**  
11/20/2020

**PAGE 10 of 16**

If decontamination is not required but there is a large amount of material remaining on the excavator bucket due to muddy or clay soil, use a shovel, broom, and buckets of water to rinse the excavator bucket prior to moving to a new excavation location.



**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>SOURCE</b>	<b>HAZARDS</b>	<b>WHERE</b>	<b>HOW, WHEN, RESULT</b>	<b>CONTROLS</b>
<b>CHEMICAL</b>	Potential contact with contaminated soil.	Sites.	Adverse health effects could result from ingesting and/or inhaling contaminated soil.	Personnel will practice proper personal hygiene – wash hands prior to eating and when leaving the site. Work will be suspended during high wind conditions that may produce large amounts of visible dust. Personnel will wear nitrile gloves and safety glasses when sampling and handling soil.
	Carbon Monoxide (CO).	Vehicle, equipment, and test pit.	Potential exposure to CO when working around idling vehicles/equipment could result in irritated eyes, headache, nausea, weakness and dizziness. The CO from idling excavator could also end up in the test pits.	Personnel will minimize the time sitting in idling vehicles and will open a window to increase ventilation. Personnel will avoid working around idling vehicles/equipment and stay upwind of said vehicles/equipment. Operator will turn the engine off when the excavator is not needed to prevent accumulation of CO in test pits.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Contact with underground and/or overhead utilities.	Testing sites.	Injury, death or property damage could occur from contact with underground and/or overhead utilities while digging test pits.	Personnel will follow Pioneer’s underground and overhead utilities corporate program and established procedures. When possible, personnel will avoid areas with underground and overhead utility hazards.





**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>BODY MECHANICS</b>	Slips and trips.	Uneven terrain, slick/muddy surfaces and/or steep slopes.	Personal injury such as sprains and muscle/back strains could result from slips and trips.	Personnel will wear work boots with good traction and ankle support. Personnel will plan their path and walk cautiously. Backhoe/excavator will slope or step one side of the test pit that will be entered to make access and egress easier.
	Bending, squatting, and kneeling.	During sample collection.	Bending, squatting, and kneeling during sample collection and handling could result in muscle/back strains or other injuries.	Personnel should stretch prior to starting work and take breaks when necessary.
	Lifting and carrying tools, equipment, and/or samples.	Testing sites.	Improper lifting and carrying tools, equipment, and/or samples could result in back injuries and muscle/back strains.	Personnel will use proper lifting techniques – get a good grip, keep the load close to the body, lift with legs and not with back, and avoid lifting loads above shoulder height. Two people will lift, if necessary.
	Struck by and/or caught in between heavy equipment.	Testing sites.	Personnel could be injured if struck by and/or caught in between the excavator or heavy equipment.	Personnel will communicate and establish eye contact with the operator before approaching the excavator or heavy equipment. The operator will stop the machine before ground personnel approach. Personnel will wear high-visibility clothing.



**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>SOURCE</b>	<b>HAZARDS</b>	<b>WHERE</b>	<b>HOW, WHEN, RESULT</b>	<b>CONTROLS</b>
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick surfaces, steep slopes, and edge of test pit.	Personnel could get injured if they fall causing bruises, scrapes, or broken bones.	Personnel will wear work boots with good traction and ankle support. Personnel will plan their path and walk cautiously. Access areas will be established, if necessary. Personnel will stand at least 2 feet away from the edge of the test pit.
	Falling rocks, debris and cave-ins.	Test pit.	Personal injuries could occur when collecting samples in test pits.	Personnel will wear Level D personnel protective equipment (PPE). Sloping techniques will be used, if necessary. Competent person (as defined by OSHA) will examine test pits before entry and large rocks will be removed from above sampling locations, or sample location will be moved to avoid the potential of falling materials.
<b>WEATHER</b>	Cold/heat stress.	Sites.	Exposure to cold temperatures may result in cold burns, frostbite, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors (e.g., layers and loose clothing). Personnel will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.
	Lightning.	Testing sites.	Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Personnel will follow the 30/30 rule during lightning storms.



**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>SOURCE</b>	<b>HAZARDS</b>	<b>WHERE</b>	<b>HOW, WHEN, RESULT</b>	<b>CONTROLS</b>
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Personnel could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Personnel will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Personnel should wear sunscreen, if necessary.
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Personnel with allergies will notify their supervisor.
<b>MECHANICAL</b>	Pinch points.	Test pits.	Personnel could cut their fingers if debris (e.g., glass, steel) is present in test pits.	Personnel will wear nitrile gloves when sampling and handling soil. Personnel will wear work gloves, if necessary.
<b>PRESSURE</b>	Pressurized hydraulic hoses.	Working around heavy equipment.	Hydraulic hoses could burst/rupture resulting in inadvertent contact with hydraulic fluid or personal injury due to being struck by hoses.	Personnel will maintain a 20-foot buffer zone around equipment when equipment is operating.
<b>THERMAL</b>	Not applicable.			



**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i>SOURCE</i>	<i>HAZARDS</i>	<i>WHERE</i>	<i>HOW, WHEN, RESULT</i>	<i>CONTROLS</i>
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained personnel.	Sites.	Inexperienced personnel and improper training could cause incidents resulting in adverse health effects and/or property damage.	Personnel will be properly trained in this procedure and other applicable procedures. Personnel will implement stop work procedures, if necessary.
<b>SIMOPS (Simultaneous Operations)</b>	Not applicable.			

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	<b>PPE:</b> Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, nitrile gloves, and leather gloves.
<b>APPLICABLE SDSs</b>	<b>Safety Data Sheets (SDSs):</b> Carbon Monoxide.  Safety Data Sheets are available to Pioneer personnel at the link below: <a href="https://pioneertechnicalservices.sharepoint.com/Safety/SafetyDataSheets">https://pioneertechnicalservices.sharepoint.com/Safety/SafetyDataSheets</a>
<b>REQUIRED PERMITS/ FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>DRAWINGS</b>	Map with site location and sample locations.
<b>RELATED SOPs/ PROCEDURES/ WORK PLANS</b>	SOP-SA-01 Soil and Water Sample Packaging and Shipping SOP-DE-02 Equipment Decontamination SOP-SA-05 Project Documentation SOP-FM-01 Field Headspace Analysis and VOC Measurements with PID



**SOP-S-06  
TEST PIT SAMPLING**

**AUTHORIZED  
VERSION:**  
11/20/2020  
**PAGE 16 of 16**

<p><b>TOOLS/ EQUIPMENT</b></p>	<p>Shovel, reel type tape measure, pin flags, measuring stick, sampling tools (stainless-steel trowels or scoops or new disposable plastic scoops, screwdrivers), sample collection containers (stainless-steel bowl, new disposable foil pans, or resealable plastic bags), camera, field logbook, sample bottles, sample storage container (cooler with ice if needed), PID (if needed), and decontamination supplies per SOP-DE-02 or broom and buckets of water.</p>
<p><b>FORMS/ CHECKLIST</b></p>	<p>Field data sheets (optional), Ground Disturbance Permit, Construction Checklist for Trenching (when applicable), Trench Safety Daily Field Report (when applicable).</p>

<p align="center"><b>APPROVALS/CONCURRENCE</b></p>	
<p align="center">By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.</p>	
<p><b>SOP TECHNICAL AUTHOR</b></p>	<p><b>DATE</b></p>
<p><i>Julie Flammang</i> <b>Julie Flammang</b></p>	<p><b>11/20/2020</b></p>
<p><b>SAFETY AND HEALTH MANAGER</b></p>	<p><b>DATE</b></p>
<p><i>Tara Schleeman</i> <b>Tara Schleeman</b></p>	<p><b>11/20/2020</b></p>



**SOP-SA-01;  
SOIL AND WATER SAMPLE  
PACKAGING AND SHIPPING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE** 1 of 5

<b>PURPOSE</b>	To provide standard instructions for soil and water sample packaging and shipping.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

<b>TASK</b>	<b>INSTRUCTIONS</b>
1. Preserve the samples.	Water samples will be preserved, if required, according to SOP-SA-02 Sample Preservation and Containerization for Aqueous Samples, and SOP-SA-02B Sample Preservation and Containerization for Aqueous Samples for VOAs.
2. Place the sample containers in Ziploc bags.	Based on the analytes requested (e.g., low level mercury, low level chromium, etc.), it may be necessary to place each filled sample container in separate Ziploc bags to prevent cross contamination, keep the container clean, dry, and isolated, and protect the sample label. In most cases, all sample containers collected from a specific sample location are placed in a large Ziploc bag and shipped together.
3. Package the samples.	Place samples in a cooler, which has been previously lined with a plastic bag. Surround the samples with non-contaminating packaging materials to reduce movement and absorb any leakage. Double bag the ice and place it in the cooler. Seal the plastic bag in the cooler to contain the samples, packing material, and ice.
4. Review and sign COC forms.	The Field Team Leader or their designated representative will double check the chain-of-custody (COC) forms to assure those samples recorded on the COC forms are in the cooler. The Field Team Leader or the designated representative will then sign the chain-of-custody form to relinquish custody.  One copy of the signed COC form will remain with the Field Team Leader. Make a photocopy of the completed forms, if there are no carbon copies available.
5. Tape paper work to cooler.	Place paper work in a sealed Ziploc bag and tape it to the inside of the cooler lid.
6. Bag samples for separate analytical batches.	If the shipping cooler contains more samples than can be analyzed in one analytical batch, the laboratory may request that the samples in the cooler be bagged for separate analytical batches. This may be necessary so that the appropriate Quality Control/Quality Assurance samples are included in each analytical batch. In this case, fill out separate COC forms for each batch and include the forms in the



**SOP-SA-01;  
SOIL AND WATER SAMPLE  
PACKAGING AND SHIPPING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE 2 of 5**

	<p>appropriate plastic bags. Place the COC forms for each batch in a sealed Ziploc bag. The COC forms for each batch should be placed at the top of the plastic bag so that they are clearly visible to laboratory personnel when they open the plastic bags.</p>
7. Label the cooler.	<p>Label the cooler with the appropriate labels to describe the content of the cooler (e.g., NOS, flammable liquids, flammable solids, this side up, fragile, etc.).</p> <p>Close the cooler and place the appropriate shipping labels (e.g., overnight shipping from Federal Express, UPS, or the United States Postal Service or equivalent) on the lid of the cooler.</p>
8. Sign COC seals.	<p>The Field Team Leader or the designated representative will sign COC seals and place the signed seals over the opening edge of the cooler.</p>
9. Tape the cooler.	<p>Place tape over the custody seals and around the cooler.</p>
10. Transport the cooler.	<p>Transport the cooler(s) to a secure storage, to the shipping agent, or directly to the laboratory.</p> <p>If shipping the cooler, follow established federal and state regulations depending on cooler content.</p>
Notes	<p>Bagging of samples and lining of coolers is not necessary, if samplers transport the samples directly to the laboratory.</p>





**SOP-SA-01;  
SOIL AND WATER SAMPLE  
PACKAGING AND SHIPPING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE** 3 of 5

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i>SOURCE</i>	<i>HAZARDS</i>	<i>WHERE</i>	<i>HOW, WHEN, RESULT</i>	<i>CONTROLS</i>
<b>CHEMICAL</b>	<p>Potential contact with contaminated soil and water samples.</p> <p>Preservatives (HCL, HNO<sub>3</sub>, H<sub>2</sub>SO<sub>4</sub>, Zinc, Acetate, NaOH).</p>	<p>Sites.</p> <p>In bottles or added to bottles through sampling process.</p>	<p>Inadvertent exposure to contaminated soil and water samples could lead to adverse health effects.</p> <p>Inadvertent exposure to preservatives could lead to adverse health effects.</p>	<p>Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Employees will wear nitrile gloves and safety glasses when handling sample containers.</p> <p>Safety Data Sheets for each preservative chemical are available to all employees on the Pioneer company web site. Personnel will wear nitrile gloves and safety glasses when adding preservatives to samples bottles and when handling the bottles. Refer to the Chemical Flushing Guidelines available inside vehicle's first aid kit for first-aid procedures in case of contact with preservatives.</p>
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	<p>Bending, squatting, and kneeling.</p> <p>Improper lifting.</p>	<p>During sample packaging.</p> <p>Sites.</p>	<p>Bending, squatting, and could result in muscle/back strains or other injuries.</p> <p>Back injuries and muscle/back strains could result when using improper techniques to lift and carry coolers with samples.</p>	<p>Employees should stretch prior to starting work and they will take breaks when necessary.</p> <p>Personnel will use proper lifting techniques – get a good grip, keep the load close to the body, lift with legs and not with back, and avoid lifting loads above shoulder's height. Two workers will lift/carry the coolers, if needed.</p>



**SOP-SA-01;  
SOIL AND WATER SAMPLE  
PACKAGING AND SHIPPING**

**DATE ISSUED:**  
12/11/2014  
**REVISION:** 0  
**PAGE** 4 of 5

<b>GRAVITY</b>	Not applicable.			
<b>WEATHER</b>	Not applicable.			
<b>RADIATION</b>	Not applicable.			
<b>BIOLOGICAL</b>	Not applicable.			
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.
<b>SIMOPS</b>	Not applicable.			

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Sampling site: hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.  Off site: nitrile gloves.
<b>APPLICABLE SDS</b>	HCL, HNO <sub>3</sub> , H <sub>2</sub> SO <sub>4</sub> , Zinc, Acetate, and NaOH. Additional Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.



**SOP-SA-01;**  
**SOIL AND WATER SAMPLE**  
**PACKAGING AND SHIPPING**

**DATE ISSUED:**  
 12/11/2014  
**REVISION: 0**  
**PAGE 5 of 5**



**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/WORK PLANS</b>	SOP-SA-02 Sample Preservation and Containerization for Aqueous Samples and SOP-SA-02B Sample Preservation and Containerization for Aqueous Samples for VOAs.
<b>TOOLS</b>	Plastic bags, Ziploc bags, non-contaminating packaging materials, tape, COC seals, ice, and cooler.
<b>FORMS/CHECKLIST</b>	Chain-of-custody (COC) forms.

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>12/11/2014</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>12/11/2014</b>

**Revisions:**

Revision	Description	Date



**SOP-SA-04;  
CHAIN OF CUSTODY FORMS  
FOR ENVIRONMENTAL  
SAMPLES**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 1 of 6

<b>PURPOSE</b>	This SOP establishes the requirements for documenting and maintaining environmental sample chain of custody from point of origin to receipt of sample at the analytical laboratory. This procedure shall apply to all types of air, soil, water, sediment, biological, and/or core samples collected in environmental investigations by Pioneer Technical Services, Inc. (Pioneer). It is applicable from the time of sample acquisition until custody of the sample is transferred to an analytical laboratory.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.
<b>DEFINITIONS</b>	<p><u>Chain of Custody</u>: is an unbroken trail of accountability that ensures the physical security of samples, data, and records. Custody refers to the physical responsibility for sample integrity, handling, and/or transportation. Custody responsibilities are effectively met, if the samples are:</p> <ul style="list-style-type: none"> <li>• In the responsible individual's physical possession;</li> <li>• In the responsible individual's visual range after having taken possession;</li> <li>• Secured by the responsible individual so that no tampering can occur; or</li> <li>• Secured or locked by the responsible individual in an area in which access is restricted to authorized personnel only.</li> </ul>

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

TASK	INSTRUCTIONS
<b>Project Manager's Responsibilities</b>	The Project Manager is responsible for overall management of environmental sampling activities, designating sampling responsibilities to qualified personnel, and reviewing any changes to the sampling plan.
<b>Field Team Leader's Responsibilities</b>	<p>The Project Manager may act as the Field Team Leader or may choose to appoint a Field Team Leader.</p> <p>The Field Team Leader is responsible for general supervision of field sampling activities and ensuring proper storage/transportation of samples from the field to the analytical laboratory.</p> <p>Chain of Custody forms will be reviewed for accuracy and completeness to preserve sample integrity from collection to receipt by an analytical lab by the Field Team Leader. The review of Chain of Custody forms may be delegated to qualified personnel.</p>



**SOP-SA-04;  
CHAIN OF CUSTODY FORMS  
FOR ENVIRONMENTAL  
SAMPLES**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 2 of 6

	<p>The Field Team Leader is responsible for sample custody until the sample has been properly relinquished as documented on the chain of custody form.</p>
<p><b>Field Sampler's Responsibilities</b></p>	<p>The Field Sampler is responsible for sample acquisition in compliance with technical procedures, initiating the Chain of Custody, and checking sample integrity and documentation prior to transfer.</p> <p>Field samplers are also responsible for initial transfer of samples consisting of physical transfer of samples directly to the internal laboratory or transferred to a shipping carrier, (e.g., United Parcel Service or Federal Express) for delivery.</p>
<p><b>Laboratory Technician's Responsibilities</b></p>	<p>The receiving Laboratory Technician is responsible for inspection of transferred samples to ensure proper labeling and satisfactory sample condition.</p> <p>Unacceptable samples will be identified and segregated. The Laboratory Project Manager will be notified.</p> <p>The Laboratory Technician will review the Chain of Custody for completeness and file as part of the project's permanent record.</p>
<p><b>Samples Handling and Chain of Custody Forms</b></p>	<p>All samples shall be collected and handled in accordance with SOP-SA-01 Soil and Water Sample Packaging and Shipping and SOP-SA-02 Sample Preservation and Containerization for Aqueous Samples, or methods described in the Sampling and Analysis Plan (SAP) or work plan (WP). Samples will be transported in insulated coolers with ice ('blue ice' is acceptable) as necessary to maintain temperature at 4 °C +/- 2 °C until receipt by the analytical laboratory.</p> <p>The Field Team Leader or designated Field Sampler shall initiate the Chain of Custody form for the initial transfer of samples.</p> <p>A Chain of Custody form will be completed and accompany every sample. The form includes the following information:</p> <ul style="list-style-type: none"> <li>• Project code;</li> <li>• Project name;</li> <li>• Samplers signature;</li> <li>• Sample identification;</li> <li>• Date sampled;</li> <li>• Time sampled;</li> <li>• Analysis requested;</li> <li>• Remarks;</li> <li>• Relinquishing signature, data, and time; and</li> <li>• Receiving signature, date, and time.</li> </ul> <p>The Field Sampler relinquishing custody and the responsible individual accepting custody shall sign, date, and note the time of transfer on the Chain of Custody form.</p>



**SOP-SA-04;  
CHAIN OF CUSTODY FORMS  
FOR ENVIRONMENTAL  
SAMPLES**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 3 of 6

Note: if the transporter is not an employee of Pioneer, the Field Sampler may identify the carrier and reference the bill of lading number in lieu of the transporter's signature.

One copy of the Chain of Custody form shall be filed as a temporary record of sample transfer by the Field Sampler. The original form shall accompany the samples and shall be returned to Pioneer as part of the contracted laboratory Quality Assurance/Quality Control (QA/QC) requirements. The original form will be filed as part of the project's permanent records.

The Project Manager (or designee) shall track the Chain of Custody to ensure timely receipt of samples by an analytical laboratory.



**SOP-SA-04;  
CHAIN OF CUSTODY FORMS  
FOR ENVIRONMENTAL  
SAMPLES**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 4 of 6

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated water/soil samples.  Preservatives (HCL, HNO <sub>3</sub> , H <sub>2</sub> SO <sub>4</sub> , Zinc, Acetate, and NaOH).	Outside of bottles.  Outside of bottles.	Inadvertent exposure to contaminated water/soil samples could lead to adverse health effects.  Inadvertent exposure to preservatives could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Employees will wear nitrile gloves and safety glasses when handling sample containers.  Safety Data Sheets for each preservative chemical are available to all employees on the Pioneer company web site. Personnel will wear nitrile gloves and safety glasses when handling the bottles. Refer to the Chemical Flushing Guidelines available inside vehicle's first aid kit for first-aid procedures in case of contact with preservatives.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Improper lifting.	Sites.	Back injuries and muscle/back strains could result when using improper techniques to lift and carry packaged samples and coolers.	Personnel will use proper lifting techniques – get a good grip, keep the load close to the body, lift with legs and not with back, and avoid lifting loads above shoulder's height. Two workers will lift/carry packaged samples and coolers, if needed.
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick/muddy/wet surfaces and steep slopes.	Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in	Workers will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. Keep work areas as dry as possible.





**SOP-SA-04;  
CHAIN OF CUSTODY FORMS  
FOR ENVIRONMENTAL  
SAMPLES**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 5 of 6

			falls and injuries.	
<b>WEATHER</b>	Not applicable.			
<b>RADIATION</b>	Not applicable.			
<b>BIOLOGICAL</b>	Not applicable.			
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.
<b>SIMOPS</b>	Not applicable.			
<b>ADDITIONAL HSSE CONSIDERATIONS</b>				
This section to be completed with concurrence from the Safety and Health Manager.				
<b>REQUIRED PPE</b>	Safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.			
<b>APPLICABLE SDS</b>	HCL, HNO <sub>3</sub> , H <sub>2</sub> SO <sub>4</sub> , Zinc, Acetate, and NaOH. Additional Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.			
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.			
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.			



**SOP-SA-04;  
CHAIN OF CUSTODY FORMS  
FOR ENVIRONMENTAL  
SAMPLES**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 6 of 6



**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/WORK PLANS</b>	SOP-SA-01 Soil and Water Sample Packaging and Shipping and SOP-SA-02 Sample Preservation and Containerization for Aqueous Samples.
<b>TOOLS</b>	Seals and labels; chain of custody forms; chain of custody seals (provided by contracted laboratory); packing and shipping materials; and cooler and ice.
<b>FORMS/CHECKLIST</b>	Chain of Custody Forms.

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>12/17/2014</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>12/17/2014</b>

**Revisions:**

Revision	Description	Date



<b>PURPOSE</b>	This SOP establishes the requirements for documenting and maintaining field logbooks and photographs. These procedures shall apply to all types of air, soil, water, sediment, biological, and/or core samples collected in environmental investigation by Pioneer Technical Services, Inc. (Pioneer). These procedures apply from the time field work begins until site activities are completed.
----------------	--

<b>SCOPE</b>	This practice has been prepared for the Pioneer workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.
--------------	--

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

<b>TASK</b>	<b>INSTRUCTIONS</b>
-------------	---------------------

1. Logbooks.	<p>A designated field logbook will be used for each field project. If requested by the Project Manager, use a separate field logbook for each field task within a larger project. Label each logbook with the project name, dates that it covers, and logbook number. Use a waterproof marker, such as a Sharpie<sup>®</sup>, to write down the information. The logbooks will be bound and have consecutively numbered pages.</p> <p>The information recorded in these logbooks shall be written in ink. Begin a new page for each days notes. Write on every line of the logbook. If a blank space is necessary for clarity, such as a change of subject, skip one line before beginning the new subject. Do not skip any pages or parts of pages unless a day's activity ends in the middle of a page. Draw a diagonal line on any blank spaces of four lines or more to prevent unauthorized entries. The author will initial and date entries at the end of each day. All corrections will consist of a single line-out deletion in ink, followed by the author's initials and the date. Information not related to the project should not be entered in the logbook. The language used in the logbook should be factual and objective.</p> <p>These bound logbooks shall include the following entries:</p> <ol style="list-style-type: none"> <li>1. A description of the field task.</li> <li>2. Time and date fieldwork started.</li> <li>3. Location and/or a description of the work areas including sketches, if needed, any maps or references needed to identify locations, and sketches of construction activities. If the location has been documented in the logbook during/prior visits, only changes in conditions should be noted.</li> <li>4. Names and company affiliations of field personnel.</li> </ol>
--------------	--



	<ol style="list-style-type: none"> <li>5. Name, company affiliation or address, and phone number of any field contacts or official site visitors.</li> <li>6. Meteorological conditions at the beginning of fieldwork and any ensuing changes in these conditions.</li> <li>7. Details of the fieldwork performed and reference to field data sheets, if used.</li> <li>8. Deviation from the task-specific Sampling and Analysis Plan (SAP), Work Plan (WP), or Standard Operating Procedures (SOP).</li> <li>9. All field measurements made.</li> <li>10. Any field laboratory analytical results.</li> <li>11. Personnel and equipment decontamination procedures, if appropriate.</li> </ol> <p>For any field sampling work, the following entries should be made:</p> <ol style="list-style-type: none"> <li>1. Sample location and number.</li> <li>2. Sample type and amount collected.</li> <li>3. Date and time of sample collection.</li> <li>4. Type of sample preservation.</li> <li>5. Split samples taken by other parties. Note the type of sample, sample location, time/date, name of person for whom the split was collected, that person's company, and any other pertinent information.</li> <li>6. Sampling method, particularly any deviations from the SOP.</li> <li>7. Documentation or reference of preparation procedures for reagents or supplies that will become an integral part of the sample, if available. This information may not be available for water or soil sampling bottles that come preserved from the laboratory or for preservatives provided by the laboratory. Bottle blanks will need to be used to evaluate the provided reagents.</li> <li>8. The laboratory where the samples will be sent.</li> </ol> <p>No bound field logbooks will be destroyed or thrown away even if they are illegible or contain inaccuracies that require a replacement document.</p>
<p>2. Photographs.</p>	<p>Take photographs of field activities using a digital camera. Photographs should include a scale in the picture when practical. Telephoto or wide-angle shots will not be used, since they cannot be used in enforcement meetings. The following items shall be recorded in the bound field logbook or on a field data sheet for each</p>



photograph taken:

1. The photographer's name, the date, the time of the photograph, and the general direction faced.
2. A brief description of the subject and the fieldwork portrayed in the picture.
3. Sequential number of the photograph.

An electronic copy and/or a hard copy of the photographs shall be placed in task files in the field office after each day of field activities. Supporting documentation from the bound field logbooks or field data sheets shall be photocopied and placed in the task files to accompany the photographs once the field activities are complete.



**HSSE CONSIDERATIONS**  
 This section to be completed with concurrence from the Safety and Health Manager.

<i>SOURCE</i>	<i>HAZARDS</i>	<i>WHERE</i>	<i>HOW, WHEN, RESULT</i>	<i>CONTROLS</i>
<b>CHEMICAL</b>	Not applicable.			
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Not applicable.			
<b>GRAVITY</b>	Not applicable.			
<b>WEATHER</b>	Not applicable.			
<b>RADIATION</b>	Not applicable.			
<b>BIOLOGICAL</b>	Not applicable.			
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Not applicable.			
<b>SIMOPS</b>	Not applicable.			

**ADDITIONAL HSSE CONSIDERATIONS**  
 This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	
<b>APPLICABLE SDS</b>	Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.



**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/WORK PLANS</b>	
<b>TOOLS</b>	Field logbook, Sharpie©, black pen, digital camera, and field data sheets.
<b>FORMS/CHECKLIST</b>	

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
<i>Julie Flammang</i> <b>Julie Flammang</b>	<b>12/17/2014</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
<i>Tara Schleeman</i> <b>Tara Schleeman</b>	<b>12/17/2014</b>

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>





**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:**  
06/05/2015  
**REVISION:** 0  
**PAGE** 1 of 8

<b>PURPOSE</b>	To provide standard instructions for operating XL3 X-Ray Fluorescence (XRF) analyzer.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

<b>TASK</b>	<b>INSTRUCTIONS</b>
1. Assemble XRF stand.	<ul style="list-style-type: none"> <li>a. Open the case containing the stand and insert 4 legs into base of stand.</li> <li>b. Place stand on a solid, level surface.</li> </ul>
2. Prep XRF sample for analysis.	<ul style="list-style-type: none"> <li>a. Wearing latex or nitrile gloves, remove any large aggregate from the sample and place in a separate bag for disposal. For gravel or rocky soils, a sieve can be used to remove the large aggregates. If a sieve is used, it needs to be decontaminated between samples. Refer to SOP-DE-02 Equipment Decontamination for instructions.</li> <li>b. Consolidate the sample into the bottom of the baggie.</li> <li>c. Open the lid to the XRF stand and place sample inside, making sure that sample is flush against the opening on the inside of the XRF stand.</li> <li>d. Close the lid to the XRF stand.</li> </ul>
3. Turn on XRF analyzer.	<ul style="list-style-type: none"> <li>a. Open the XRF case and remove XRF gun from case.</li> <li>b. Slide XRF battery onto bottom of XRF gun handle.</li> <li>c. Press and hold power button (⏻) until XRF gun turns on and wait for system to start.</li> <li>d. Press where it says 'press to logon.' A warning message appears asking to verify that the user is aware of the radiation source in the XRF unit.</li> <li>e. Press 'Yes' to continue.</li> </ul>
4. Log in and calibrate detector.	<ul style="list-style-type: none"> <li>a. Type password (1234) when prompted.</li> <li>b. Click 'E' to log in. After logging in, a screen appears with 7 icons appears, this is the Main Menu screen.</li> <li>c. Tap the 'System Check' icon.</li> <li>d. Tap 'Yes.'</li> <li>e. The XRF unit will then go through an internal calibration.</li> <li>f. When the calibration is done, tap 'CLOSE' on the XRF gun to return to the Main Menu screen.</li> </ul> <p style="text-align: center;"><b>The detector should be calibrated at the start of each day of operation.</b></p>



**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:**  
06/05/2015  
**REVISION:** 0  
**PAGE** 2 of 8

<p>5. Set up XRF run test.</p>	<ol style="list-style-type: none"> <li>a. Set parameters (e.g., analysis types, time, and analytes) required for the analysis as detailed in the XL3 user’s manual, Sampling and Analysis Plan (SAP), or Work Plan (WP).</li> <li>b. Once logged into XRF system, tap the ‘Analyze’ icon on XRF screen. A screen appears.</li> <li>c. On the next screen tap ‘Soils.’</li> <li>d. On the next screen tap ‘Data Entry.’ A Data Entry screen appears showing several options (Sample Name, Sampler, Date, etc.).</li> <li>e. In the upper right hand corner, next to the ‘Sample Name’ icon, click the symbol that looks like a miniature keyboard to display a keyboard on the screen.</li> <li>f. Type in the sample name (do not press return yet).</li> <li>g. Insert XRF gun into the bottom of the XRF stand with the XRF gun handle pointing away from you. Be sure that the XRF gun is securely in place in the bottom of the stand.</li> <li>h. Press ‘return’ in the lower right corner of the keyboard screen.</li> <li>i. To activate the unit, pull the trigger on the gun handle. The analysis will take approximately 2 minutes to complete.</li> </ol>
<p>6. Record data.</p>	<ol style="list-style-type: none"> <li>a. After the XRF analysis is complete, results from the analysis will appear on the screen.</li> <li>b. Record the results and Test Number displayed on the screen; use the up and down arrows on the XRF gun to scroll through data.</li> <li>c. Open the lid on the XRF stand and remove the sample.</li> <li>d. Mark the sample baggie as “RAN” so that sample does not get analyzed twice. Place ran samples in a labeled box for storage and record keeping.</li> </ol>
<p>7. Run additional samples.</p>	<ol style="list-style-type: none"> <li>a. With the XRF gun still in the XRF stand, press the return button (↩) on the XRF gun. This will display the ‘Data Entry’ screen.</li> <li>b. On the Data Entry Screen, press the keyboard symbol located to the right of ‘Sample Name’ to display the keyboard.</li> <li>c. Type the next sample name (do not press return yet).</li> <li>d. Place the sample into the XRF stand and close the lid to the stand (as discussed in Task 2).</li> <li>e. Repeat the steps in Task 5 to activate the XRF unit.</li> <li>f. Repeat Tasks 6 and 7 until all samples are analyzed.</li> </ol>
<p>8. Turn off XRF.</p>	<ol style="list-style-type: none"> <li>a. After all samples have been analyzed, remove the XRF gun from the bottom of the stand (press and hold buttons on the side of the stand to allow XRF gun to be removed from stand).</li> <li>b. Press the return button (↩) on the XRF gun until the Main Menu screen appears.</li> <li>c. Press and hold the power button (⏻) until the XRF turns off.</li> <li>d. Remove the battery from the gun and place these items back into the appropriate case.</li> <li>e. Disassemble the XRF stand and place back into the appropriate case.</li> </ol>



**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:  
06/05/2015  
REVISION: 0  
PAGE 3 of 8**

Quality  
Assurance/Quality  
Control (QA/QC)  
Requirements.

Required QA/QC tasks:

1. Run the Niton-supplied XRF blanks and NIST standards at the start of each day.
2. Record the results in the field logbook or on the XRF field datasheet or equivalents. If the results are not within the ranges supplied by NITON in the user manual, initiate troubleshooting tasks on the analyzer (refer to the user's manual).
3. Run the blank and one standard QA/QC samples during sample analysis at the rate of 1 for every 20 samples analyzed. QA/QC includes analyzing a replicate sample every 20 samples and a duplicate sample (see the steps below).

**Analyze a replicate sample (1 for every 20 samples analyzed)**

1. After recording the initial reading for a sample, DO NOT remove the sample from the holder.
2. Restart the XRF gun and rerun the sample.
3. Record the information on the field data form or logbook as a replicate (or R sample). Replicates samples help track the precision of the XRF.

**Analyze a duplicate sample (after every 20 samples analyzed)**

1. After every 20 samples, analyze a duplicate sample by recording the results of the 20<sup>th</sup> sample.
2. Remove the sample bag from the XRF stand, remix the sample, and replace it in the XRF stand.
3. Reanalyze the sample.
4. Record the results as a duplicate (or D sample). Duplicates help to determine the precision of the XRF analysis as well as the homogeneity of the sample matrix.
5. Run a NITON-supplied blank or NIST standard after the replicate/duplicate QA/QC samples to monitor the accuracy of the XRF results.



**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:**  
06/05/2015  
**REVISION:** 0  
**PAGE** 4 of 8

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated soil.	Reclamation sites and within samples.	Inadvertent exposure to contaminated soil via ingestion could result in adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and handling soil samples. Workers will wear nitrile gloves and safety glasses when handling samples to prevent exposure.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Improper lifting.  Repetitive motion.	Sites.  From removing rocks from sample bags or filling sample cups.	Back injuries and muscle/back strains could result when using improper lifting techniques to lift/carry XRF analyzer.  Repetitive motion can result in hand cramps and fatigue.	Personnel will use proper lifting techniques: get a good grip, keep the load close to the body, lift with legs and not with back, and avoid lifting loads above shoulder's height. Take breaks if necessary. Personnel will ensure they are fit for duty, avoid staying in one position for long periods of time, and set up work area to minimize ergonomic risks.  Personnel will take breaks, if necessary. Use appropriate tools (e.g., plastic spoon or tamper) to pack sample cups. Use a sieve to remove rocks from samples prior to bagging, if needed.
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick/muddy/wet surfaces and steep slopes.	Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in falls and injuries.	Personnel will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. If conditions are wet or muddy, wear muck boots.



**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:**  
06/05/2015  
**REVISION:** 0  
**PAGE** 5 of 8

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

	Dropping the XRF analyzer.	Sites.	Personnel could be injured if the XRF analyzer is dropped on their feet.	Personnel will wear steel-toe boots. Personnel will ensure the XRF analyzer is set up on a solid surface and is not moved until sampling is complete.
<b>WEATHER</b>	Cold/heat stress.	Outdoor sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Personnel will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.
	Lightning.	Outdoor sites.	Electrocution, injury, death, or equipment damage could result from lightning strike.	Employees will follow the 30/30 rule during lightning storms.
<b>RADIATION</b>	Radiation from x-ray tube.	X-ray tube.	Exposure to radiation could lead to serious adverse health effects.	Radiation from the x-ray tube is fully contained within the device when not in use and allowed to escape through the measurement window only while the user is analyzing a sample. Radiation emission is controlled by a shutter. Personnel will keep hands and all body parts away from the front end of the analyzer when the shutter is open to minimize exposure. Personnel will not hold the analyzer near the measurement window during testing. Never point the analyzer at yourself or anyone else when the shutter is open. Never hold samples during analysis or look into the path of the primary beam.



**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:**  
06/05/2015  
**REVISION:** 0  
**PAGE** 6 of 8

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

	Ultraviolet (UV) radiation.	Outdoor sites.	Employees could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Employees will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Employees should wear sunscreen, if necessary.
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Outdoors.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Employees with allergies will notify their supervisor.
<b>MECHANICAL</b>	Pinch points.	Transport case, XRF lid, and setting up work table.	Hand/finger injuries from pinching fingers in transport case/ XRF lid and when setting up the work table.	Personnel will wear work gloves to prevent injuries from pinch points.
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in the procedure described above and other applicable procedures. Employees will follow the stop work policy, if there are any issues.
<b>SIMOPS</b>	Not applicable.			



**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:**  
06/05/2015  
**REVISION:** 0  
**PAGE** 7 of 8

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, nitrile or latex gloves, and work gloves.
<b>APPLICABLE SDS</b>	Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/ WORK PLANS</b>	SOP-DE-02 Equipment Decontamination.
<b>TOOLS</b>	XRF and hand tools.
<b>FORMS/CHECKLIST</b>	







**SOP-SFM-02;  
OPERATING XL3 X-RAY  
FLUORESCENCE ANALYZER**

**DATE ISSUED:**  
06/05/2015  
**REVISION:** 0  
**PAGE** 8 of 8

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>06/05/2015</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>06/05/2015</b>

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>



**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:**  
10/24/2016  
**REVISION:** 4  
**PAGE** 1 of 11

<b>PURPOSE</b>	To provide standard instructions for operating survey equipment, staking, flagging and painting survey marks, and recording of field work performed.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work will be trained and competent in the risk-assessed work described below.
<p><b>WORK INSTRUCTIONS</b></p> <p>The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work performed under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&amp;M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).</p>	
<b>TASK</b>	<b>INSTRUCTIONS</b>
1. Storing survey equipment.	Store survey equipment in a secure, climate-controlled weatherproof area when not in use.
2. Charging Global Positioning System (GPS), robot, and data collector batteries.	<p>Charge batteries used in survey equipment in a climate-controlled weatherproof area. The use of a surge protector (power strip) to supply power to the battery chargers is recommended.</p> <p>Only use manufacturer's approved batteries and chargers.</p>
3. Transporting survey equipment in vehicles.	<p>Transport survey equipment in a weatherproof area of a vehicle to prevent unnecessary exposure to elements that could adversely affect the calibration of various survey instruments and their accessories.</p> <p>Secure equipment in the vehicle during transportation so that it does not become a projectile in the case of an accident or other sudden maneuver.</p>
4. Setting stakes/lath and hubs.	Setting of survey stakes and hubs often requires the use of a 3-to 4-pound engineer or drilling hammer (hand held) (refer to Figure 1) or a 8- to 12-pound sledgehammer, and a gad (frost pin) (refer to Figure 2) manufactured and/or distributed by Red Top or Lo-Ink, designed to mushroom and not splinter when struck, to create a pilot hole in various soil surfaces in order to set the stake or hub.



Figure 1 – Drilling Hammer



Figure 2 – Gad (Frost Pin)

The gad (frost pin) will be from an authorized survey supply company. Any type of gad (frost pin) that is made of a material that can create shrapnel (i.e., jack hammer bits) or from an unauthorized survey supply company will not be used. When hammering stakes/hubs into surface, care will be taken to avoid splintering of stake/hub.

Set the hubs and stakes/lath in the following manner:

- After determining the position of the hub/stake/lath, determine the soil condition.
- If soil is loose or non-compacted, simply drive the hub/stake/lath into the ground until the hub/stake/lath is stable.

If soil is hard packed or compacted, use the following steps:

- Make a pilot hole using a gad.
- Grip the gad in your non-dominant hand halfway up the length of the gad and place the point of the gad at the desired position of the survey point.
- Using the drilling hammer in your dominant hand, strike the top of the gad a sufficient number of times to make a pilot hole of the desired depth.
- To remove the gad from the pilot hole, strike the sides of the gad with the drilling hammer in opposing horizontal directions to loosen the gad.
- Remove the gad from the pilot hole and insert the hub/stake/lath into the ground until the hub/stake/lath is stable.

5. Setting rebar.

Setting of rebar is necessary to establish control points and property corners. The use of a rebar driver (refer to Figure 3) manufactured and/or distributed by Surv-Kap or Lo-Ink, designed to mushroom and not splinter when struck, will be utilized to prevent mushrooming of the rebar and to allow for a larger striking surface. The proper sized driver for the proper sized rebar will be used (i.e., 1/2 inch for #4 rebar, 5/8 inch for #5 rebar, etc.).




Figure 3 – Rebar Driver

Set rebar in the following manner:

- After determining the desired position of the property corner or control point, select a section of 5/8-inch rebar (12-inch length for control points, 24-inch length for property corners).
- Inspect the section of rebar and ensure that it is straight and free of burrs at the ends.
- Place one end of the rebar at the desired position and hold it with your non-dominant hand.
- Place the rebar driver over the end of the rebar. Using the drilling hammer (held in your dominant hand), strike the rebar driver until the bottom of the rebar driver contacts the surface that the rebar is being driven into. This will leave the rebar exposed approximately 2½ inches, allowing either a plastic or aluminum survey cap to be placed on the exposed end of the rebar.
- Drive the rebar and cap flush with the surface by placing a “cap driver” (sold by Surv-Kap) over the cap and striking the “cap driver” to set the cap flush to the surface.
- In the event that a control point or property corner needs to be set in a paved surface, a pilot hole will be drilled first with a hammer drill and the correct sized bit.

6. Checking points daily.

Check points will be performed daily (per job) to verify the following:

- Base point and height of base are correct.
- Survey coordinate system and datum are correct.
- Control remains within project specifications.

7. Using point ranges.

The following point ranges will be used on all jobs:


- 1-299 Project Control (found or set).
- 300-499 Found Monuments.
- 500-999 Calculated Monuments.
- 1000-2999 Calculated Design.
- 3000-Infinity Topo and staking store points.



**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:  
10/24/2016  
REVISION: 4  
PAGE 4 of 11**

<p>8. Booking of survey activities.</p>	<p>Record surveying activities on a daily basis (per job) in a field book to facilitate the ease of record keeping and the ability at a later date to recall the activity performed. The following will be the minimum data recorded in the field book:</p> <ul style="list-style-type: none"><li>• Job name, location, coordinate system, and vertical datum used (header page) along with a brief description of the survey activities performed.</li><li>• Date of field work and initials of all crew members.</li><li>• Base point used along with height and type of measure up (fixed height, slant height, center bumper height, bottom of antenna mount, etc.).</li><li>• Check point(s) used with <math>\Delta</math> Northing, <math>\Delta</math> Easting, and <math>\Delta</math> Elevation differences written along with “Stored As” point (i.e., CK7-5 would be the 5th check point on CP7).</li><li>• Any new control points or bench marks set (or found) along with their description.</li><li>• Description of property corners set or found (e.g., type of rebar/cap, found stone, pipe, etc.) along with ties to any accessories (e.g., fence corners, bearing trees, road intersections, etc.).</li><li>• Point ranges stored and a brief description (e.g., 3001-4063 – topo of road and ditches from xxx intersection to xxx intersection).</li><li>• Type of alignments staked and the point range that staked points were stored in.</li><li>• Occupy and backsight points for conventional survey work (gun work) along with backsight check and points staked – per set up.</li><li>• Any changes in rod height and the associated point ranges.</li><li>• Leveling bench marks, foresights, backsights, and side shots will be recorded (when leveling is performed).</li><li>• Any pertinent sketches deemed necessary.</li><li>• Any issues with equipment, land owners, contractors, etc. that arise.</li><li>• Any other information deemed pertinent by the individual performing the survey.</li></ul> <p>Field books will be numbered in the following manner:</p> <ul style="list-style-type: none"><li>• Volume by county using the Montana County numbers (i.e., Silver Bow is 1, Deer Lodge is 30, Lewis and Clark is 5, etc.).</li><li>• Book by series (e.g., B1, B2, B3, etc.).</li><li>• County name.</li><li>• All of the above will be marked on the front outside cover and the side binding of the field book.</li><li>• The title page at the beginning of the book will be filled out with the office information/address that the surveyor performing the work is based out of.<ul style="list-style-type: none"><li>○ An example of field book number is: V1-B4 Silver Bow (i.e., Volume 1 – Book 4 of Silver Bow County).</li><li>○ Each individual page will be numbered as such (i.e., V1-B4-1, V1-B4-2, etc.) in the upper right hand corner of each page. One page is considered to be both the left and right page of any given field book when in an open position.</li></ul></li></ul>
---	---

	<ul style="list-style-type: none"> <li>○ Once a field book is filled, the index at the front of the book will be filled in to aid in future tracking of field work already performed.</li> </ul> <p>The preferred type of field book is a Rite in the Rain All-Weather Transit No.300 series.</p> <p><b>Note: all of the above is necessary to provide for an accurate means of recalling activities performed.</b></p>
<p>9. Painting and flagging of survey marks.</p>	<div style="text-align: center;">  <p>Figure 4 – Spray Paint</p> </div> <p>Use the following steps when painting and flagging survey marks:</p> <ul style="list-style-type: none"> <li>• Stand upwind of survey marks to be painted.</li> <li>• Invert spray can, aim nozzle at survey mark, and depress nozzle spraying paint in a sweeping motion.</li> <li>• After desired amount of paint has been dispensed, point nozzle straight up and depress nozzle on quick time to prevent clogging.</li> <li>• Flagging will be tied securely to the mark or stake as necessary.</li> </ul> <p><b>Note: per the Mine Safety and Health Administration regulations, spray paint will not be stored in the cab of any vehicle. If it is necessary to warm cold paint cans up, do not leave cans unattended in the vehicle, and do not place them directly over heat vents.</b></p>
<p>10. Placing control points.</p>	<p>Locations of control points, especially those that may be used for a GPS base point or Total Station, will be placed in a safe location away from overhead and underground utilities and out of the lanes of traffic.</p> <p>The GPS control will be in an area that is obstruction free in order to have the best view of satellites in the sky. A minimum of three control points per project will be established, preferably intervisible. The preferred primary control type is a #5 rebar (12 inches long) with a 2 inch aluminum control cap marked with the Control Point Number and the year it was set stamped into it. Secondary control (i.e., any control that will not be used for longer than one month) can be a 60D nail and flagging, RR spike, hub and tack, or other acceptable “temporary” style of control.</p>



**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:**  
10/24/2016  
**REVISION:** 4  
**PAGE** 6 of 11

**HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated soils and dust.	Reclamation sites.	Adverse health effects could result from ingesting and/or inhaling contaminated soils/dust.	Personnel will practice proper personal hygiene: wash hands prior to eating/drinking and when leaving the site. Work will be suspended during high wind conditions that may produce large amounts of visible dust. Personnel will wear nitrile gloves, if contact with contaminated soil is possible.
	Fumes from marking paint.	Survey marks.	Inhalation of paint fumes when placing survey marks could result in adverse health effects such as headaches/dizziness.	Personnel will stay upwind from the paint being sprayed.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Equipment contact with overhead utilities.	Sites with overhead utilities.	Injury, death or property damage could occur from survey equipment (i.e., survey rod) contact with overhead utilities.	Personnel will follow the procedures outlined in the Pioneer Overhead Utilities Program. When possible, personnel will avoid areas with overhead utility hazards.
	Equipment contact with underground utilities.	Sites.	Injury, death or property damage could occur from survey equipment (i.e., gad, stake, and rebar) contact with underground utilities.	Personnel will follow the procedures outlined in the Pioneer Trenching, Excavation, and Ground Disturbance Program.





**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:**  
10/24/2016  
**REVISION:** 4  
**PAGE** 7 of 11

<b>BODY MECHANICS</b>	<p>Repetitive motion.</p>           <p>Lifting and carrying tools and equipment.</p>	<p>Body.</p>           <p>Sites.</p>	<p>Repetitive motion when reaching and positioning while using tools and survey equipment could result in injuries such as muscle strains.</p>           <p>Improper lifting and carrying tools and equipment could result in back injuries and muscle/back strains.</p>	<p>Personnel will maintain a balanced position when reaching and positioning survey equipment. They will bend at knees while keeping back straight and upright to paint, place or pound in survey markers. Personnel should also stretch before starting work and will take breaks when necessary.</p>           <p>Personnel will use proper lifting techniques: get a good grip, keep the load close to your body, lift with legs and not with back, and avoid lifting loads above shoulder height. Two people will lift heavy objects, if necessary.</p>
<b>GRAVITY</b>	<p>Uneven terrain, slick surfaces, and steep slopes.</p>	<p>Sites.</p>	<p>Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in falls and injuries.</p>	<p>Personnel will wear work boots with good traction and ankle support, be aware of working/walking surfaces and choose a path to avoid hazards, keep work areas as dry as possible, and wear muck boots as necessary.</p>
<b>WEATHER</b>	<p>Cold/hot temperatures.</p>	<p>Outdoor sites.</p>	<p>Exposure to cold climates may result in cold burns, frostbite, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.</p>	<p>Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors (e.g., layers and loose clothing), remain hydrated, and have sufficient caloric intakes during the day. Personnel will use their field vehicle to take breaks, when needed. Personnel will also follow the procedures outlined in the Pioneer Heat/Cold Stress Program.</p>



**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:**  
10/24/2016  
**REVISION:** 4  
**PAGE** 8 of 11

<b>WEATHER (cont.)</b>	Lightning.	Outdoor sites.	Electrocution, injury, death or equipment damage could be caused by lightning strike.	Personnel will follow the 30/30 rule during lightning storms.
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoor sites.	Exposure to UV radiation during summer months can cause sun burns, skin damage, and eye damage.	Personnel will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Personnel should wear sunscreen, if necessary.
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Outdoor sites.	Exposure to plants, insects, and animals may cause rashes, blisters, redness, swelling, and other injuries.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Personnel will avoid contact with plants, insects, and animals. First aid kits will be available on the site. Personnel with allergies will notify their supervisor.
<b>MECHANICAL</b>	Driving.  Unsecured equipment.	Sites.  Vehicle.	Interaction with light and heavy equipment could result in vehicle incidents. Driving on uneven/muddy/slick terrain could also result in vehicle incidents.  Injury could result from being struck by an unsecured piece of equipment while driving.	Personnel will maintain communication with equipment operators and other site personnel, yield to haul traffic, and use defensive driving techniques. Personnel will not approach active heavy equipment with vehicle. If site conditions are not safe, postpone work or access the site using another means or route.  Personnel will secure equipment to vehicle.



**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:**  
10/24/2016  
**REVISION:** 4  
**PAGE** 9 of 11

<b>MECHANICAL (cont.)</b>	Contact with engineer or drilling hammer.	Setting survey stakes and hubs.	Injuries to hands, foot, and knees could result when using an engineer or drilling hammer to set survey stakes and hubs.	Personnel will wear work gloves and steel-toed boots. Personnel will also keep knees away from the survey gad while creating a pilot hole. Be aware of finger/hand placement and do not put fingers/hands between objects. Inspect tools prior to each use.
	Flying debris.	Setting survey stakes, hubs, and rebar.	Survey gad, stakes, hubs, and rebar could splinter and/or break while being struck with hammer and flying pieces could cause eye injuries.	Personnel will wear safety glasses. Personnel will use survey gad designed to mushroom and not splinter when struck. When establishing control points/property corners, personnel will use a rebar driver to set up rebar. Personnel will also inspect survey gad, stakes, hubs, and rebar prior to installing them.
	Pinch points.	Hand tools and equipment.	Exposure to pinch points when using hand tools and equipment could result in personal injuries.	Personnel will wear work gloves to protect against pinch-point injuries. Inspect all tool and equipment prior to each use.
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained personnel.	Sites.	Inexperienced personnel and improper training could cause incidents resulting in injuries and/or property damage.	Personnel will be trained in this procedure and other applicable procedures. Personnel will implement stop work procedures, if necessary.
<b>SIMOPS</b>	Not applicable.			



**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:**  
10/24/2016  
**REVISION:** 4  
**PAGE** 10 of 11

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	Long-sleeved work shirt, high-visibility vest/outwear, long pants, safety glasses, hard hat, work globes, and steel-toed boots.
<b>APPLICABLE SDS</b>	Survey Marking Paint. Additional Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	
<b>RELATED SOPs/PROCEDURES/WORK PLANS</b>	
<b>TOOLS</b>	Hand-held GPS, survey rod, engineer or drilling hammer, sledgehammer, survey gad, stakes, lath, rebar, rebar driver, survey cap, cap driver, paint cans, and field book.
<b>FORMS/CHECKLIST</b>	

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
Mike Newhouse	08/16/2016
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
Tara Schleeman	10/24/2016



**SOP-SURVEY-01;  
STAKING AND SURVEYING**

**DATE ISSUED:**  
10/24/2016  
**REVISION: 4**  
**PAGE 11 of 11**

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>



**SOP-WFM-01**  
**FIELD MEASUREMENT**  
**OF pH IN WATER**

**AUTHORIZED**  
**VERSION:**  
 09/29/2020  
 PAGE 1 of 7

<b>PURPOSE</b>	To provide standard instructions for field measurement of pH in water.
<b>SCOPE</b>	Pioneer Technical Services, Inc. (Pioneer) prepared this practice for the workforce and this Standard Operating Procedure (SOP) applies to all work performed by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent (as defined by OSHA) in the risk-assessed procedure described below before performing the work.
<b>WORK INSTRUCTIONS</b>	
<p>The following instructions provide guidance to perform the task in a safe, accurate, and reliable manner. If these instructions present information that is inaccurate or unsafe, personnel must notify the Project Manager, Safety Manager, and the SOP Technical Author to initiate appropriate revisions. Personnel will perform all work under this SOP in a manner that is consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&amp;M) Plan (where applicable), appropriate Site-Specific Health and Safety Plans (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).</p>	
<b>TASK</b>	<b>INSTRUCTIONS</b>
<b>1. Prepare the pH meter.</b>	<p>Pioneer owns and operates different brands and models of pH field measurement meters. All units, in general, have automatic temperature correction (ATC) capabilities. Prior to using a pH meter, verify that it has the ATC function. User manuals for each meter are available and the specific directions for calibrating and measuring pH with that meter should be followed.</p> <p>Calibrate pH meter in the field at the beginning of each day and if a standard check is out of calibration. Record the calibration information in the field logbook.</p> <ol style="list-style-type: none"> <li>1. For a new probe, prepare the pH probe according to the directions in the electrode user guide.</li> <li>2. Connect the probe to the appropriate connection on the meter.</li> <li>3. Turn the meter on and make sure it is in the pH measurement mode. Calibrate instrument as described in the meter-specific operating manual.</li> </ol>
<b>2. Calibrate the meter.</b>	<p>The following is a general summary for instrument calibration:</p> <ol style="list-style-type: none"> <li>1. Rinse the ATC pH probe in deionized water.</li> <li>2. Turn on meter and immerse the ATC pH probe in a pH 7 buffer solution. Calibrate meter to pH 7 allowing enough time for meter to stabilize.</li> <li>3. Rinse ATC pH probe with deionized water.</li> <li>4. Immerse ATC pH probe in a pH 4 buffer solution. Calibrate meter to pH 4 allowing enough time for meter to stabilize.</li> </ol>



**SOP-WFM-01**  
**FIELD MEASUREMENT**  
**OF pH IN WATER**

**AUTHORIZED**  
**VERSION:**  
 09/29/2020  
 PAGE 2 of 7

	<ol style="list-style-type: none"> <li>5. Rinse pH and temperature probe with deionized water.</li> <li>6. Immerse ATC pH probe in a pH 10 buffer solution. Calibrate meter to pH 10 allowing enough time for meter to stabilize.</li> <li>7. Record the slope reading in the field logbook.</li> <li>8. Recheck meter calibrations with the pH 4, pH 7, and pH 10 calibration solutions. Repeat the calibration process (steps 2-6) if a value for any final pH check is outside the manufacturer's stated accuracy as stated in the user's manual</li> </ol>
<p><b>3. Take field measurements.</b></p>	<p>The following is a general summary for field measurement of pH:</p> <ol style="list-style-type: none"> <li>1. Rinse beaker with sample water 3 times.</li> <li>2. Rinse ATC pH probe with deionized water.</li> <li>3. Fill beaker with sample water.</li> <li>4. Turn on meter and immerse ATC pH probe in sample water. Stir sample for thorough mixing. Read and record pH to the nearest 0.01 unit once pH reading has stabilized.</li> <li>5. Rinse electrodes with deionized water and store in carrying case.</li> </ol> <p><u>Note:</u> pH may also be measured by placing the probe directly into the water body being tested. The probe must be moved slowly in a circular motion when measuring stagnant water.</p>
<p><b>Important information about meter.</b></p>	<ol style="list-style-type: none"> <li>1. Store meter in case during transport.</li> <li>2. Check batteries before taking meter into the field. Carry spare batteries and deionized water for rinsing probe.</li> <li>3. Inspect probe for damage or dirt.</li> <li>4. Dust and wipe the meter with a damp cloth. If necessary, warm water or mild water-based detergent can be used to clean the case. Immediately remove any spilled substance from the meter using the proper cleaning procedure for the type of spill.</li> <li>5. If meter readings are erratic, replace the probe. If readings continue to be erratic, return the meter to factory for repair.</li> </ol>





**SOP-WFM-01  
FIELD MEASUREMENT  
OF pH IN WATER**

**AUTHORIZED  
VERSION:  
09/29/2020  
PAGE 3 of 7**

**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated water.	Testing sites, during pH measurements.	Inadvertent exposure to contaminated water could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Personnel will wear nitrile gloves and safety glasses when taking measurements.
	Potential contact with pH buffer solutions.	Equipment calibration.	Inadvertent exposure to pH buffer solutions could lead to adverse health effects (e.g., irritation of eye, skin, and/or respiratory tract).	Personnel will practice proper personal hygiene – wash hands prior to eating and after calibrating equipment. Personnel will wear nitrile gloves and safety glasses when handling pH buffer solutions.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Bending, squatting, and kneeling.	During pH measurements.	Bending, squatting, and kneeling during pH measurements could result in muscle/back strains or other injuries.	Personnel should stretch prior to starting work and they will take breaks when necessary.
	Drowning and/or entrapment hazards.	Bodies of water, during pH measurements.	If personnel need to stand in bodies of water to take measurements, they could be exposed to drowning and/or entrapment hazards from soft soils and/or sudden changes in depth of water.	If necessary, personnel will use rods to test soil stability and/or depth of water as they walk to sample locations. Additionally, personnel may be required to wear life vests when crossing deeper bodies of water. When possible, personnel will not enter the water body and take measurements from the bank.



**SOP-WFM-01  
FIELD MEASUREMENT  
OF pH IN WATER**

**AUTHORIZED  
VERSION:  
09/29/2020  
PAGE 4 of 7**

**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick/muddy/wet surfaces and steep slopes.	Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in falls and injuries.	Personnel will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. Keep work areas as dry as possible. Wear muck boots, as necessary.
<b>WEATHER</b>	Cold/heat stress.	Sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Personnel will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.
	Hypothermia/frostbite.	Sites where air temperature is 35.6 °F (2 °C) or less.	Personnel who become immersed in water or whose clothing becomes wet may be exposed to hypothermia and/or frostbite.	Personnel will change clothing if it becomes wet. When applicable, Personnel will wear waders to prevent clothing from getting wet.
	Lightning.	Outdoor sites.	Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Personnel will follow the 30/30 rule during lightning storms.
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Personnel could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Personnel will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Personnel should wear sunscreen, if necessary.



**SOP-WFM-01  
FIELD MEASUREMENT  
OF pH IN WATER**

**AUTHORIZED  
VERSION:**  
09/29/2020  
**PAGE 5 of 7**

**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Personnel with allergies will notify their supervisor.
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained personnel.	Sites.	Inexperienced personnel and improper training could cause incidents resulting in adverse health effects and/or property damage.	Personnel will be properly trained in this procedure and other applicable procedures. Personnel will implement stop work procedures, if necessary.
<b>SIMOPS (Simultaneous Operations)</b>	Not applicable.			



**SOP-WFM-01  
FIELD MEASUREMENT  
OF pH IN WATER**

**AUTHORIZED  
VERSION:**  
09/29/2020  
**PAGE 6 of 7**

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	<b>Personal Protection Equipment (PPE):</b> Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.
<b>APPLICABLE SDSs</b>	<b>Safety Data Sheets (SDSs):</b> pH 4, pH7, and pH10 buffer solutions.  Safety Data Sheets are available to Pioneer personnel at the link below: <a href="https://pioneertechnicalservices.sharepoint.com/Safety/SafetyDataSheets">https://pioneertechnicalservices.sharepoint.com/Safety/SafetyDataSheets</a>
<b>REQUIRED PERMITS/ FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>DRAWINGS</b>	Map with site location and sample locations.
<b>RELATED SOPs/ PROCEDURES/ WORK PLANS</b>	
<b>TOOLS/ EQUIPMENT</b>	pH field measurement meters, spare batteries for the pH field measurement meters, deionized water, pH 7 buffer solution, pH 4 buffer solution, pH 10 buffer solution, beaker, and field logbook.
<b>FORMS/ CHECKLIST</b>	



**SOP-WFM-01  
FIELD MEASUREMENT  
OF pH IN WATER**

**AUTHORIZED  
VERSION:  
09/29/2020  
PAGE 7 of 7**

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

**SOP TECHNICAL AUTHOR**

**DATE**

A handwritten signature in cursive script that reads "Julie Flammang".

**Julie Flammang**

**09/29/2020**

**SAFETY AND HEALTH MANAGER**

**DATE**

A handwritten signature in cursive script that reads "Tara Schleeman".

**Tara Schleeman**

**09/29/2020**



**SOP-WFM-02**  
**FIELD MEASUREMENT**  
**OF OXIDATION REDUCTION**  
**POTENTIAL IN WATER**

**AUTHORIZED**  
**VERSION:**  
 10/15/2020  
 PAGE 1 of 9

<b>PURPOSE</b>	To provide standard instructions for field measurements of oxidation reduction potential (ORP) in water.
<b>SCOPE</b>	Pioneer Technical Services, Inc. (Pioneer) prepared this practice for the workforce and this Standard Operating Procedure (SOP) applies to all work performed by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent (as defined by OSHA) in the risk-assessed procedure described below before performing the work.
<b>WORK INSTRUCTIONS</b>	
The following instructions provide guidance to perform the task in a safe, accurate, and reliable manner. If these instructions present information that is inaccurate or unsafe, personnel must notify the Project Manager, Safety Manager, and the SOP Technical Author to initiate appropriate revisions. Personnel will perform all work under this SOP in a manner that is consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plans (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).	
<b>TASK</b>	<b>INSTRUCTIONS</b>
<b>Important information about meter's calibration.</b>	<p>Pioneer owns and operates different brands and models of ORP field measurement meters. At this time, Pioneer uses YSI, In-Situ, Thermo Scientific ORION (Orion 3 Star or Orion 5 Star) Portable Meters for ORP measurements. An Orion 9179BNMD epoxy low maintenance ORP/ATC Triode is attached to the ORION meters. The Orion Star meters can perform an automatic ORP calibration adjusted for temperature. User manuals for each meter are available and the specific directions for calibrating and measuring ORP with that meter should be followed.</p> <p>If there is a choice between measuring ORP in the millivolt (mV) or relative millivolt (RmV), measure in <b>mV mode</b>. The Orion meters are calibrated using RmV mode and then changed to mV for measuring. The YSI and In-Situ multi probes, units will be in mV for both calibration and measurements. The mV values can be compared among multiple meters and electrode systems.</p> <p>Listed below is the general calibration procedure. Refer to the meter specific operating manual for detailed calibration instructions.</p>
<b>1. Prepare electrode.</b>	<ol style="list-style-type: none"> <li>1. Remove the protective shipping cap from the sensing element and save the cap for storage.</li> <li>2. Clean any salt deposits from the exterior of the electrode by rinsing with distilled water.</li> <li>3. Shake the electrode downward (similar to a clinical thermometer) to remove air bubbles from the Orion and YSI probes.</li> <li>4. Connect the electrode to the meter.</li> </ol>



**SOP-WFM-02**  
**FIELD MEASUREMENT**  
**OF OXIDATION REDUCTION**  
**POTENTIAL IN WATER**

**AUTHORIZED**  
**VERSION:**  
 10/15/2020  
 PAGE 2 of 9

<p><b>2. Connect the electrode to the meter.</b></p>	<ol style="list-style-type: none"> <li>1. For the Orion meters, insert the ORP connector (large diameter) in the pH or BNC electrode input jack on the meter and the reference electrode connector (small diameter) into the reference electrode input jack.</li> <li>2. For the YSI and In-Situ meters, slide probe into correct slot and turn counterclockwise to tighten. Make sure threads are not cross threaded and tighten. <b>Hand tighten only!</b></li> </ol>
<p><b>3. Calibrate the meter.</b></p>	<p>All field meters must be calibrated prior to use. Calibration shall be performed at a minimum of once per day when the instrument is in use. Calibration shall be performed prior to the first measurements of the day. All calibration results <b>will</b> be recorded in the field logbook, or if stored on the meter, downloaded and saved in the project file. Downloaded calibration files will be included as part of the field logbook record.</p> <ol style="list-style-type: none"> <li>1. For the Orion meters, set the meter to the RmV mode referring to the specific meter’s user guide for instructions. If using YSI or In-Situ meters skip to step 2.</li> <li>2. Rinse the electrode with deionized or distilled water and place the ORP electrode in an appropriate ORP standard. Pioneer uses a 400 mV standard (Orion 967901 or similar) for most calibrations. If project-specific measurements of ORP are expected to be much higher or lower than 400 mV, use an ORP calibration standard with an appropriate concentration. <b>Always</b> use fresh ORP standard for calibrations. Empty the ORP calibration container in the Pioneer Calibration Kit, rinse the bottle with fresh ORP solution, empty it, and then pour enough of the calibration fluid into the bottle to cover the bottom of the electrode.</li> <li>3. For Orion meters, wait for the RmV icon to quit flashing. If using YSI or In-Situ meters, wait for mV to stabilize and accept calibration.</li> <li>4. The Orion Star meters will automatically calculate the mV. Small adjustments may be required to the reading to achieve the mV value of the ORP standard at the measured temperature. Information provided in the Thermo Orion User Guide for Redox/ORP Electrodes or Table 1, on page 4, can be used as a reference for the appropriate reading. Adjust the meter referring to the meter user’s guide for detailed instructions on adjusting the reading.</li> <li>5. For Orion meters, press the measure symbol to end the calibration. The mV offset will be displayed and the meter will proceed to the measurement mode. The In-situ meter will display the mV offset and temperature immediately after accepting the calibration. This information can be stored for downloading.</li> <li>6. If using the YSI meter, calibration is stored on the meter and can be downloaded. To access the calibration information immediately to record in the logbook, return to the main display screen. Press “File,” scroll down to the “GLP” file, and press enter to view. The information from the latest calibration will be displayed at the top. Scroll down to view previous calibrations.</li> </ol>





**SOP-WFM-02**  
**FIELD MEASUREMENT**  
**OF OXIDATION REDUCTION**  
**POTENTIAL IN WATER**

**AUTHORIZED**  
**VERSION:**  
 10/15/2020  
 PAGE 3 of 9

	<p>7. Record the calibration information in the logbook or save for later download.</p>
<p><b>4. Conduct field measurements.</b></p>	<p>Field ORP measurements for surface water may be made by direct submersion of the instrument probe into the sample stream. If flow is turbulent or shallow, or if direct immersion could damage the probe, a grab sample can be collected in a beaker or bottle and the probe should be placed immediately into the beaker for measurement.</p> <p>Field ORP measurements of groundwater may be made by inserting the probe into a flow-through device or by collection of a grab sample and immediate analysis of that sample in the field. Specific requirements may be listed in the project-specific documents (sampling and analysis plan, quality assurance project plan, work plan, etc.). The ORP measurements are considered stable during groundwater sampling when 3 consecutive readings vary by no more than 10 mV units.</p> <p>Oxidation Reduction Potential is always measured and reported in mV. Refer to the meter specific user manual for measurement instructions. Listed below are general measurement instructions:</p> <ol style="list-style-type: none"> <li>1. Rinse the electrode with distilled or deionized water. Shake off any excess water and blot the electrode dry with lint-free tissue.</li> <li>2. Check and make sure that the meter is measuring in mVs.</li> <li>3. Place the electrode directly into the water to be measured. If the probe cannot be placed directly into the water being measured, rinse a decontaminated beaker with sample water 3 times and fill the beaker with the water to be measured.</li> <li>4. Continuously stir or move the probe through the sample at a rate of about 1 foot per second.</li> <li>5. If the meter is in the continuous measurement mode, it will start reading immediately and continuously update the display. The mV icon will flash until the reading is stable.</li> <li>6. Read and record the result in the field logbook or on a field data sheet.</li> <li>7. Remove the electrode from the sample, rinse it with distilled or deionized water, and blot it dry before inserting the probe into the storage sleeve.</li> </ol>
<p><b>Important information about the meter.</b></p>	<ol style="list-style-type: none"> <li>1. Store meter in its case during transport.</li> <li>2. Check batteries before taking meter into the field. Carry spare batteries and deionized water for rinsing probe.</li> <li>3. Inspect probe for damage or dirt.</li> </ol>



**SOP-WFM-02  
FIELD MEASUREMENT  
OF OXIDATION REDUCTION  
POTENTIAL IN WATER**

**AUTHORIZED  
VERSION:  
10/15/2020  
PAGE 4 of 9**

- |  |   |
|--|---|
|  | <p>4. Dust and wipe the meter with a damp cloth. If necessary, warm water or mild water-based detergent can be used to clean the case. Immediately remove any spilled substance from the meter using the proper cleaning procedure for the type of spill.</p> <p>5. If meter readings are erratic, replace the probe. If measurement readings continue to be erratic, return the meter to factory for repair.</p> |
|--|---|

**Table 1. ORP Standard Values – Page 1**

**Table 1– ORP Standard Values**

Absolute mV values may vary by  $\pm 60$  mV

Temperature (°C)	E <sub>H</sub> Value (mV)	Absolute Value with Cat. No. 900011 Filling Solution (mV)	Absolute Value with Cat. No. 900001 Filling Solution (mV)
0	438	218	176
1	437	218	176
2	437	218	176
3	436	218	176
4	435	218	176
5	435	218	176
6	434	218	176
7	433	218	176
8	433	218	175
9	432	219	175



**SOP-WFM-02**  
**FIELD MEASUREMENT**  
**OF OXIDATION REDUCTION**  
**POTENTIAL IN WATER**

**AUTHORIZED**  
**VERSION:**  
 10/15/2020  
 PAGE 5 of 9

**Table 1. ORP Standard Values – Page 2**

<b>Temperature (°C)</b>	<b>E<sub>H</sub> Value (mV)</b>	<b>Absolute Value with Cat. No. 900011 Filling Solution (mV)</b>	<b>Absolute Value with Cat. No. 900001 Filling Solution (mV)</b>
10	431	219	175
11	430	219	175
12	430	219	175
13	429	219	175
14	428	219	175
15	428	219	175
16	427	219	174
17	426	219	174
18	425	219	174
19	424	219	174
20	424	219	174
21	423	219	174
22	422	219	174
23	421	219	173
24	420	220	173
25	420	220	173
26	419	220	173
27	418	220	173
28	417	220	172
29	416	220	172
30	415	220	172
31	414	220	172
32	413	220	172
33	412	220	171
34	412	220	171
35	411	220	171
36	410	220	171
37	409	220	171
38	408	220	170
39	407	220	170
40	406	220	170
41	405	220	170
42	404	220	169
43	403	220	169
44	402	220	169
45	401	220	169
46	400	220	168
47	399	220	168
48	398	220	168
49	397	220	168
50	396	220	167



**SOP-WFM-02  
FIELD MEASUREMENT  
OF OXIDATION REDUCTION  
POTENTIAL IN WATER**

**AUTHORIZED  
VERSION:**  
10/15/2020  
**PAGE 6 of 9**

**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>SOURCE</b>	<b>HAZARDS</b>	<b>WHERE</b>	<b>HOW, WHEN, RESULT</b>	<b>CONTROLS</b>
<b>CHEMICAL</b>	Potential contact with contaminated water.	Testing sites, during field measurements.	Inadvertent exposure to contaminated water could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Personnel will wear nitrile gloves and safety glasses when taking measurements.
	Potential exposure to ORP standard solution.	Equipment calibration.	ORP standard solution is moderately toxic if ingested. It may also irritate eyes and skin.	Personnel will practice proper personal hygiene – wash hands prior to eating and after calibrating equipment. Personnel will wear nitrile gloves and safety glasses when handling the ORP standard solution.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Bending, squatting, and kneeling.	During field measurements.	Bending, squatting, and kneeling during field measurements could result in muscle/back strains or other injuries.	Personnel should stretch prior to starting work and they will take breaks when necessary.
	Drowning and/or entrapment hazards.	Bodies of water, during field measurements.	If personnel need to stand in bodies of water to take measurements, they could be exposed to drowning and/or entrapment hazards from soft soils and/or sudden changes in depth of water.	If necessary, personnel will use rods to test soil stability and/ or depth of water as they walk to sample locations. Also, personnel may be required to wear life vests when crossing deeper bodies of water. When possible, personnel will not enter the water body and take measurements from the bank.



**SOP-WFM-02  
FIELD MEASUREMENT  
OF OXIDATION REDUCTION  
POTENTIAL IN WATER**

**AUTHORIZED  
VERSION:  
10/15/2020  
PAGE 7 of 9**

**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>SOURCE</b>	<b>HAZARDS</b>	<b>WHERE</b>	<b>HOW, WHEN, RESULT</b>	<b>CONTROLS</b>
<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick/muddy/wet surfaces and steep slopes.	Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in falls and injuries.	Personnel will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. Keep work areas as dry as possible. Wear muck boots, as necessary.
<b>WEATHER</b>	Cold/heat stress.	Sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Personnel will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.
	Hypothermia/frostbite.	Sites where air temperature is 35.6 °F (2 °C) or less.	Personnel who become immersed in water or whose clothing becomes wet may be exposed to hypothermia and/or frostbite.	Personnel will change clothing if it becomes wet. When applicable, Personnel will wear waders to prevent clothing from getting wet.
	Lightning.	Outdoor sites.	Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Personnel will follow the 30/30 rule during lightning storms.
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Personnel could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Personnel will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Personnel should wear sunscreen, if necessary.



**SOP-WFM-02  
FIELD MEASUREMENT  
OF OXIDATION REDUCTION  
POTENTIAL IN WATER**

**AUTHORIZED  
VERSION:**  
10/15/2020  
**PAGE 8 of 9**

**HEALTH SAFETY SECURITY ENVIRONMENT (HSSE) CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<i>SOURCE</i>	<i>HAZARDS</i>	<i>WHERE</i>	<i>HOW, WHEN, RESULT</i>	<i>CONTROLS</i>
<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Personnel with allergies will notify their supervisor.
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained personnel.	Sites.	Inexperienced personnel and improper training could cause incidents resulting in adverse health effects and/or property damage.	Personnel will be properly trained in this procedure and other applicable procedures. Personnel will implement stop work procedures, if necessary.
<b>SIMOPS (Simultaneous Operations)</b>	Not applicable.			

**ADDITIONAL HSSE CONSIDERATIONS**

This section to be completed with concurrence from the Safety and Health Manager.

<b>REQUIRED PPE</b>	<b>Personal Protection Equipment (PPE):</b> Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.
<b>APPLICABLE SDSs</b>	<b>Safety Data Sheets (SDSs):</b> ORP Standard Solution  Safety Data Sheets are available to Pioneer personnel at the link below: <a href="https://pioneertechnicalservices.sharepoint.com/Safety/SafetyDataSheets">https://pioneertechnicalservices.sharepoint.com/Safety/SafetyDataSheets</a>





**SOP-WFM-02  
FIELD MEASUREMENT  
OF OXIDATION REDUCTION  
POTENTIAL IN WATER**

**AUTHORIZED  
VERSION:  
10/15/2020  
PAGE 9 of 9**

<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.

<b>DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT</b>	
The following documents should be referenced to assist in completing the associated task.	
<b>DRAWINGS</b>	Map with site location and sample locations.
<b>RELATED SOPs/ PROCEDURES/ WORK PLANS</b>	
<b>TOOLS/ EQUIPMENT</b>	ORP field measurement meters, ORP standard solution, spare batteries for the meters, distilled water or deionized water, lint-free tissue, beaker, and field logbook or field data sheet.
<b>FORMS/ CHECKLIST</b>	

<b>APPROVALS/CONCURRENCE</b>	
By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.	
<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>10/15/2020</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>10/15/2020</b>





**SOP-WFM-03;  
FIELD MEASUREMENT  
OF SPECIFIC CONDUCTANCE**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 1 of 7

<b>PURPOSE</b>	To provide standard instructions for field measurements of specific conductance.
<b>SCOPE</b>	This practice has been prepared for the Pioneer Technical Services, Inc. (Pioneer) workforce and applies to work carried out by and on behalf of Pioneer. All members of the Pioneer workforce who conduct the work shall be trained and competent in the risk-assessed work described below.

**WORK INSTRUCTIONS**

The following instructions are intended to provide sufficient guidance to perform the task in a safe, accurate, and reliable manner. Should these instructions present information that is inaccurate or unsafe, operations personnel must bring the issue to the attention of the Project Manager and the appropriate revisions made. All work carried under this SOP will be consistent with procedures and policies described in the appropriate Operation, Maintenance, and Monitoring (O&M) Plan (where applicable), appropriate Site-Specific Health and Safety Plan (SSHASP), and Pioneer Corporate Health and Safety Plan (HASP).

<b>TASK</b>	<b>INSTRUCTIONS</b>
Important information about the meter.	Pioneer owns and operates different brands and models of specific conductance (SC) field measurement meters. All the units, in general, have automatic temperature correction (ATC) capabilities. Prior to using a SC meter check that it does have the ATC function. User manuals for each meter are available and the specific directions for calibrating and measuring SC with that meter should be followed. The following is a general summary for field measurement of SC.
1. Calibrate the meter.	<p>All field meters must be calibrated prior to use. Calibration shall be performed at a minimum of once per day for each day of instrument use. Calibration shall be performed prior to the first measurements of the day. Refer to the meter specific operating manual for calibration instructions. Listed below are general calibration requirements:</p> <ol style="list-style-type: none"> <li>1. For a new probe, prepare the SC probe according to the directions in the electrode user guide.</li> <li>2. Connect the probe to the appropriate connection on the meter.</li> <li>3. Turn the meter on and make sure it is in the conductivity measurement mode. Calibrate instrument as described in the meter specific operating manual. Unless specified in the Sampling and Analysis Plan (SAP) or work plan, one conductivity standard is used for calibration. Unless directed otherwise, use the 1413 micromhos/centimeter (<math>\mu\text{s}/\text{cm}</math>) calibration standard present in all of Pioneer's calibration cases. Make sure that the calibration standard in the case is fresh. The container of calibration standard should be emptied, rinsed with new calibration standard and filled prior to a field sampling event. Replace batteries and try fresh calibration solutions if meter does not calibrate properly.</li> <li>4. Record the calibration results in the field logbook. If the meter displays an average calculated cell constant, record this in the field logbook.</li> <li>5. Once the SC meter is in measure mode, measure the calibration standard and</li> </ol>



**SOP-WFM-03;  
FIELD MEASUREMENT  
OF SPECIFIC CONDUCTANCE**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 2 of 7

	<p>record this result and the measurement temperature in the field logbook.</p> <p>6. Re-measure the calibration fluid at the end of the day and note any drift. Record the information in the field logbook.</p>
<p>2. Conduct field measurements.</p>	<p>Field conductivity measurements for surface water may be made by direct submersion of the instrument probe into the sample stream. When flow is turbulent or shallow, or when direct immersion of the probe would risk damaging the probe, measurements may be made by collection of a grab sample and immediate analysis of the grab sample in the field.</p> <p>Field SC measurements of groundwater may be made by inserting the probe into a flow through device or by collection of a grab sample and immediate analysis of the grab sample in the field. Specific requirements may be listed in the SAP or work plan.</p> <p>Field SC is measured in units of <math>\mu\text{S}/\text{cm}</math> (micromhos/centimeter) or <math>\text{mS}/\text{cm}</math> (millihos/centimeters) on all Pioneer meters. Refer to the meter specific operating manual for measurement instructions. Listed below are general measurement instructions:</p> <ol style="list-style-type: none"> <li>1. If the probe cannot be placed directly into the water being measured, rinse the decontaminated beaker with sample water three times.</li> <li>2. Fill the beaker with the water to be measured.</li> <li>3. With the meter in measurement mode, rinse the conductivity cell with distilled water, blot dry with a lint-free tissue and place the cell into the water being measured.</li> <li>4. Submerge conductivity probe in sample so that flow cell holes are immersed and wait for the readings to stabilize.</li> <li>5. Read and record the SC result in the field logbook or on a field data sheet making sure that the correct units are recorded, either <math>\mu\text{S}/\text{cm}</math> or <math>\text{mS}/\text{cm}</math>. Record the sample temperature to the nearest 0.1 degree Celsius (<math>^{\circ}\text{C}</math>) from the conductivity meter after temperature has equilibrated.</li> <li>6. Repeat the above steps for all samples.</li> <li>7. When all samples have been measured, store the electrode according to their specific user guides.</li> </ol>
<p>Important information about the meter.</p>	<ol style="list-style-type: none"> <li>1. Store meter in case during transport.</li> <li>2. Check batteries before taking meter into the field. Carry spare batteries and de-ionized water for rinsing probe.</li> <li>3. Inspect probe for damage or dirt.</li> </ol>



**SOP-WFM-03;  
FIELD MEASUREMENT  
OF SPECIFIC CONDUCTANCE**

**DATE ISSUED:  
12/17/2014  
REVISION: 0  
PAGE 3 of 7**

4. Dust and wipe the meter with a damp cloth. If necessary, warm water or mild water based detergent can be used to clean the case. Immediately remove any spilled substance from the meter using the proper cleaning procedure for the type of spill.
5. If meter readings are erratic, replace the probe. If readings continue to be erratic, return the meter to factory for repair.



**SOP-WFM-03;  
FIELD MEASUREMENT  
OF SPECIFIC CONDUCTANCE**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 4 of 7

<b>HSSE CONSIDERATIONS</b>				
This section to be completed with concurrence from the Safety and Health Manager.				
<i><b>SOURCE</b></i>	<i><b>HAZARDS</b></i>	<i><b>WHERE</b></i>	<i><b>HOW, WHEN, RESULT</b></i>	<i><b>CONTROLS</b></i>
<b>CHEMICAL</b>	Potential contact with contaminated water.	Testing sites, during field measurements.	Inadvertent exposure to contaminated water could lead to adverse health effects.	Personnel will practice proper personal hygiene – wash hands prior to eating/drinking and when leaving the site. Personnel will wear nitrile gloves and safety glasses when taking measurements.
	Exposure to 1413 µs/cm calibration standard solution.	Equipment calibration.	The calibration standard solution may cause irritation of eyes and skin.	Personnel will practice proper personal hygiene – wash hands prior to eating and after calibrating equipment. Personnel will wear nitrile gloves and safety glasses when handling the calibration standard solution.
<b>NOISE</b>	Not applicable.			
<b>ELECTRICAL</b>	Not applicable.			
<b>BODY MECHANICS</b>	Bending, squatting, and kneeling.	During field measurements.	Bending, squatting, and kneeling during field measurements could result in muscle/back strains or other injuries.	Employees should stretch prior to starting work and they will take breaks when necessary.
	Drowning and/or entrapment hazards.	Bodies of water, during field measurements.	If employees need to stand in bodies of water to take measurements, they could be exposed to drowning and/or entrapment hazards from soft soils and/or sudden changes in depth of water.	If necessary, personnel will use rods to test soil stability and/or depth of water as they walk to sample locations. In addition, personnel may be required to wear life vests when crossing deeper bodies of water. When possible, workers will not enter the water body and take measurements from the bank.



**SOP-WFM-03;  
FIELD MEASUREMENT  
OF SPECIFIC CONDUCTANCE**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 5 of 7

<b>GRAVITY</b>	Falls from slips and trips.	Uneven terrain, slick/muddy/wet surfaces and steep slopes.	Walking/working on slick/muddy/wet and uneven terrain could cause slips and trips resulting in falls and injuries.	Personnel will wear work boots with good traction and ankle support. Personnel will be aware of working/walking surfaces and choose a path to avoid hazards. Keep work areas as dry as possible. Wear muck boots, as necessary.
<b>WEATHER</b>	Cold/heat stress.	Sites.	Exposure to cold climates may result in cold burns, frostbites, and hypothermia. Exposure to high temperatures may result in heat cramps, heat exhaustion, or heat stroke.	Training on signs and symptoms of cold/heat stress is required. Personnel will wear appropriate clothing when working outdoors. Personnel will remain hydrated and will have sufficient caloric intakes during the day. Personnel will follow procedures outlined in applicable SSHASP and/or Pioneer corporate HASP.
	Hypothermia/frostbite.	Sites where air temperature is 35.6°F (2°C) or less.	Workers who become immersed in water or whose clothing becomes wet may be exposed to hypothermia and/or frostbite.	Employees will change clothing if it becomes wet. When applicable, employees will wear waders to prevent clothing from getting wet.
	Lightning.	Outdoor sites.	Electrocution, injury, death, or equipment damage could be caused by lightning strike.	Employees will follow the 30/30 rule during lightning storms.
<b>RADIATION</b>	Ultraviolet (UV) radiation.	Outdoors.	Employees could be exposed to UV radiation during summer months causing sun burns, skin damage, and eye damage.	Employees will wear safety glasses with tinted lenses, long-sleeve work shirts, and long pants. Employees should wear sunscreen, if necessary.



**SOP-WFM-03;  
FIELD MEASUREMENT  
OF SPECIFIC CONDUCTANCE**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 6 of 7

<b>BIOLOGICAL</b>	Plants, insects, and animals.	Sites.	Exposure to plants, insects, and/or animals may cause rashes, blisters, redness, and swelling.	Training on the signs and symptoms of exposure to plants, insects, and animals is required. Avoid contact with plants, insects, and animals. First-aid kits will be available on site. Employees with allergies will notify their supervisor.
<b>MECHANICAL</b>	Not applicable.			
<b>PRESSURE</b>	Not applicable.			
<b>THERMAL</b>	Not applicable.			
<b>HUMAN FACTORS</b>	Inexperienced and improperly trained worker.	Sites.	Inexperienced workers and improper training could cause incidents resulting in adverse health effects and/or property damage.	Employees will be properly trained in this procedure and other applicable procedures. Employees will implement stop work procedures, if necessary.
<b>SIMOPS</b>	Not applicable.			
<b>ADDITIONAL HSSE CONSIDERATIONS</b>				
This section to be completed with concurrence from the Safety and Health Manager.				
<b>REQUIRED PPE</b>	Hard hat, safety glasses, high-visibility work shirt or vest, long pants, work boots, and nitrile gloves.			
<b>APPLICABLE SDS</b>	1413 $\mu\text{s/cm}$ calibration standard solution. Additional Safety Data Sheets (SDSs) will be maintained based on site characterization and contaminants.			
<b>REQUIRED PERMITS/FORMS</b>	Per site/project requirements.			
<b>ADDITIONAL TRAINING</b>	Per site/project requirements.			



**SOP-WFM-03;  
FIELD MEASUREMENT  
OF SPECIFIC CONDUCTANCE**

**DATE ISSUED:**  
12/17/2014  
**REVISION:** 0  
**PAGE** 7 of 7



**DRAWINGS, DOCUMENTS, AND TOOLS/EQUIPMENT**

The following documents should be referenced to assist in completing the associated task.

<b>P&amp;IDS</b>	
<b>DRAWINGS</b>	Map with site location and sample locations.
<b>RELATED SOPs/PROCEDURES/ WORK PLANS</b>	
<b>TOOLS</b>	Specific conductance field measurement meter, calibration standard solution, calibration kit, spare batteries for the meter, distilled water or de-ionized water, lint-free tissue, beaker, and field logbook or field data sheet.
<b>FORMS/CHECKLIST</b>	

**APPROVALS/CONCURRENCE**

By signing this document, all parties acknowledge the completeness and applicability of this SOP for its intended purpose. Also, by signing this document, it serves as acknowledgement that I have received training on the procedure and associated competency testing.

<b>SOP TECHNICAL AUTHOR</b>	<b>DATE</b>
 <b>Julie Flammang</b>	<b>12/17/2014</b>
<b>SAFETY AND HEALTH MANAGER</b>	<b>DATE</b>
 <b>Tara Schleeman</b>	<b>12/17/2014</b>

**Revisions:**

<b>Revision</b>	<b>Description</b>	<b>Date</b>



# **Appendix B.**

## **Field Forms and Tables**

## **FORMS**

# Test Pit Log

**Project:** Biotreatability Study

**Location No:**

**Arrival/Start Excavation Time:**

**Contrator:**

**Equipment Used:**

**Excavation Stop Time:**

**Date:**

**Operator:**

**GW Depth:**

**Logged By:**

**Weather (including ambient temp.):**

Depth		Soil Characterization	PID (MR)	PID (UR)	Sample Time
IN	FT				

**Notes:**

Butte Reduction Works Phase I, Field XRF Results 2018											Units are mg/kg or ppm NA - Not applicable.
Soil Performance Standards		200	20	1,000	NA	1,000	1,000	If three of the six criteria listed are exceeded, or any one contaminant is above 5,000 mg/kg then the material is considered waste.			
XRF Reading #	Date	Sample ID	XRF Results					Comments			
			As	Cd	Cu	Fe	Pb		Zn		

## **TABLES**

## ORDER FOR DESCRIPTIONS

### Density

- Very soft, Soft, Medium Stiff, Stiff, Stiff, Very Stiff, Hard
- Very loose, Loose, Medium Dense, Dense, Very Dense
- SEE TABLE

### Moisture Content

- Dry, Moist, Wet
- See Table

### General Color

### Soil Description

- Minor soil type name with "y" added if  $\geq 30$  percent and  $\leq 50\%$
- Descriptive adjective for main soil type
  - Particle-size distribution adjective for gravel and sand (fine – coarse)
  - Plasticity adjective (slight to high) and soil texture (silty or clayey) for inorganic and organic silts or clays
- Main soil type's name (**all capital letters**)
- Descriptive adjective such as trace (0-5%), slightly or some (5-12%), for minor soil type

### Structures

- See Tables

### Geologic Classification

- If applicable – alluvium, fill, tailings, slag, debris

### USCS Classification

- See Tables

### Examples:

Medium dense, wet, dark brown, sandy SILT, trace of clay, numerous organics and strong organic odor (marsh deposits) ML.

Medium stiff, moist, dark gray, medium plastic silty CLAY, slightly sandy, laminated with light gray silt (tailings), CL

Very dense, moist, light brown, slightly silty, sandy fine gravel, trace of cobbles, scattered roots, GP-GM

**Density/Consistency**      Word Choices

**Consistency of Fine-Grained Soils-Silts, Clays**

<b>Consistency</b>	<b>Results of Manual Manipulation</b>
Very Soft	Specimen (height = twice the diameter) sags under its own weight; extrudes between fingers when squeezed
Soft	Specimen can be pinched in to between the thumb and forefinger; remolded by light finger pressure
Medium stiff	Can be imprinted easily with fingers; remolded by strong finger pressure
Stiff	Can be imprinted with considerable pressure from fingers or indented by thumbnail
Very stiff	Can be barely imprinted by pressure from the fingers or indented by thumbnail
Hard	Cannot be imprinted by fingers or difficult to indent by thumbnail

<b>Density of Coarse or Cohesionless Soils-Gravels/Sands and Silt</b>
Very loose
Loose
Medium Dense
Dense
Very Dense

**WATER CONTENT**

<b>Description</b>	<b>Conditions</b>
Dry	No sign of water and soil dry to touch
Moist	Signs of water and soil is relatively dry to touch
Wet	Signs of water and soil definitely wet to touch; granular soil exhibits some free water when densified, saturated

## SIZES FOR SOIL DESCRIPTIONS

Term	Example	Size
Boulders	> Basketball size	> 12"
Cobbles	Fist to Basketball size	3"-12"
Gravel – Coarse	Thumb to fist size	¾"-3"
Gravel – Fine	Pea to Thumb size	5 mm to ¾"
Sand – Coarse	Rock salt to pea size	2 mm to 5 mm
Sand – Medium	Sugar to rock salt	0.4 mm to 2 mm
Sand – Fine	Flour to sugar	0.08 mm to 0.4 mm
Fines – Clay and silt	Grains are not visible	<0.08 mm

*Boulders and cobbles are not considered soil or part of the soil's classification or description, except under miscellaneous descriptions; i.e. --, with cobbles at about 5 percent (volume).*

**Well graded coarse-grained soil** - contains a good representation of all particle sizes from largest to smallest, with ≤ 12% **fines**.

**Poorly graded coarse-grained soil** is uniformly graded with most particles about the same size or lacking one or more intermediate sizes, with 12% fines.

### Describe type and size of organic debris

Adjective	Presence as % by Volume
Occasional	0-1%
Scattered	1-10%
Numerous	10-30%
Organic – as a minor constituent in description	30-50%
PEAT – MAJOR constituent	50-100%

### Highly Organic Materials

These materials containing a predominance of undecomposed plant or woody fiber are described as follows:

- *Root Mat*: Pronounced structure of living root fibers characteristic of marsh or swampy deposits.
- *Peat*: Fossiliferous root mat with a varying degree of decomposition, often containing a matrix of amorphous, colloidal organic clays and silts.
- *Humus*: Decomposed root and leaf litter, characteristic of organic forest cover in well-drained areas.



## SOIL PLASTICITY DESCRIPTIONS

Plasticity Adjective	Dry Strength	Smear Test	Thread Smallest Diameter, in. (mm)	ML & MH (SILT)	CL & CH (CLAY)	OL & OH (ORGANIC SILT OR CLAY)
nonplastic	none-crumbles into powder with mere pressure	gritty or rough	ball cracks	----	----	ORGANIC SILT
low plasticity	low-crumbles into powder with some finger pressure	rough to smooth	1/4 to 1/8 (3 to 6)	----	silty	ORGANIC SILT
medium plastic	medium - breaks into pieces or crumbles with considerable finger pressure	smooth and dull	1/16 (0.5 to 1)	clayey	silty to no adj.	ORGANIC clayey SILT
highly plastic	high- cannot be broken with finger pressure; will break into pieces between thumb and a hard surface	shiny	1/32 (0.75)	clayey	----	ORGANIC silty CLAY
very plastic	very high - can't be broken between thumb and a hard surface	very shiny and waxy	1/64 (0.5)	clayey	----	ORGANIC

### Thread Test:

Moisture is added or worked out of a small ball (about 1 1/2-inch diameter) and the ball is kneaded until its consistency approaches medium stiff to stiff and it breaks, or crumbles. A thread is then rolled out to the smallest diameter possible before disintegration. The smaller the thread achieved, the higher the plasticity of the soil. Fine-grained soils of high plasticity will have threads smaller than 1/32 inch in diameter. Soils with low plasticity will have threads larger than 1/8 inch in diameter.

## Layered Soils

<u>Type of Layer</u>	<u>Thickness</u>	<u>Occurrence</u>
Parting	< 1/16 in.	
Lamination	< ¼ in.	
Seam	1/16 to ½ in.	
Layer	½ in. to 12 in.	
Stratum	> 12 in.	
Pocket	Small erratic deposit	
Lens	Lenticular deposit	
Varved (also layered)		Alternating seams or layers of silt and/or clay and sometimes f. sand
Occasional		One or less per foot of thickness or laboratory sample inspected
Frequent		More than one per foot of thickness or laboratory sample inspected

Place the thickness designation before the type of layer, or at the end of each description and in parentheses, whichever is more appropriate.

Examples of descriptions for layered soils are:

- Medium stiff, moist to wet 1/4"-3/4" interbedded seams and layers of: gray, medium plastic, silty CLAY (CL); and lt. gray, low plasticity SILT (ML); (Alluvium).

## Other Layer Adjectives

<b>Description</b>	<b>Criteria (thickness)</b>
Stratified	Alternating Layers
Interbedded	Alternating Layers > ½" thick
Laminated	Alternating layers < ¼" thick
Fractured	Breaks easily along definite fractured planes
Slickensided	Polished, glossy, striated, fracture planes
Blocky	Easily breaks into small angular lumps
Lensed	Small pockets of different soils
Homogeneous	Same color and appearance throughout
Sheared	Disturbed texture, mix of strengths

Coarse- Grained Soils			
Coarse-Grained Soils	Gravel and Gravelly Soils	GW	Well-graded gravels or gravel- sand mixtures, little or no fines
		GP	Poorly graded gravels or gravel- sand mixtures, little or no fines
		GM	Silty gravels, gravel-sand-silt mixtures (more than 12% fines)
		GC	Clayey gravels, gravel-sand- clay mixtures (more than 12% fines)
	Sand and Sandy Soils	SW	Well-graded sands or gravelly sands, little or no fines
		SP	Poorly graded sands or gravelly sands, little or no fines
		SM	Silty sands, sand-silt mixtures (more than 12% fines)
		SC	Clayey sands, sand-silt mixtures (more than 12% fines)
FINE - GRAINED SOILS			
Fine-Grained Soils	Silts and Clays Liquid Limit < 50	ML	Inorganic silts and very fine sands, rock flour, silty or clayey fine sands or clayey silts with slight plasticity
		CL	Inorganic clays of low to medium plasticity, gravelly clays, sandy clays, silty clays, lean clays
		OL	<i>Organic</i> silts and organic silt- clays of low plasticity
	Silts and Clays Liquid Limits $\geq$ 50	MH	Inorganic silts, micaceous or diatomaceous fine sandy or silty soils, elastic silts
		CH	Inorganic clays of high plasticity, fat clays
		OH	<i>Organic</i> clays of medium to high plasticity, organic silts
	Highly <i>Organic</i> Soils	Pt	Peat and other highly organic soils

Well Graded - all particle sizes are present, less than 12% fines

Poorly Graded - most particles are about the same size or missing 1 or 2 sizes, 12% fines



<b>TITLE:</b>	GEOLOGIC LOGGING		
<b>CATEGORY:</b>	GEO 4.8		March 1998




Figure 3 Rock Descriptive Terms

# **Appendix C.**

## **Data Validation Checklists**

**Site:**  
**Project:**  
**Sample Date(s):**  
**Data Validator:**

**Case No:**  
**Sample Matrix:**  
**Analysis Date(s):**  
**Validation Date(s):**

**Laboratory:**  
**Analyses:**

**1. Holding Times**

Analyte	Laboratory	Matrix	Method	Holding Times	Collection Date(s):	Analysis Date(s)	Holding Time Met (Y/N)	Affected Data Flagged (Y/N)
Were any data flagged because of holding time?							Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of preservation problems?							Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:								
Comments:								

**2. Blanks**

Were Method Blanks (MBs) analyzed at the frequency of 1 per analytical batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were MBs within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of blank problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**3. Laboratory Control Samples**

Were Laboratory Control Samples (LCS) analyzed at the frequency of 1 per batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were LCS results within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of LCS problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**4. Duplicate Sample Results**

Were Laboratory Duplicate Samples (LDS) analyzed at the frequency of 1 per batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were LDS results within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of LDS problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**5. Matrix Spike Sample Results**

Were Laboratory Matrix Spike Samples (LMS) analyzed at the frequency of 1 per batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were LMS results within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of LMS problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**6. Field Blanks**

Were field blanks submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were field blanks within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were any data qualified because of field blank problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Describe Any Actions Taken:						
Comments:						

**7. Field Duplicates**

Were field duplicates submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were results for field duplicates within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were any data qualified because of field duplicate problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Describe Any Actions Taken:						
Comments:						

**8. Overall Assessment**

Are there analytical limitations of the data that users should be aware of?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>
If so, explain:				
Comments:				

**9. Authorization of Data Validation**

Data Validator <b>Name:</b> _____  <b>Signature:</b> _____  <b>Date:</b> _____	<b>Reviewed by:</b> _____  _____  _____
---	---

**Site:**  
**Project:**  
**Sample Date(s):**  
**Data Validator:**

**Case No:**  
**Sample Matrix:**  
**Analysis Date(s):**  
**Validation Date(s):**

**Laboratory:**  
**Analyses:**

**1. Holding Times**

Analyte	Laboratory	Matrix	Method	Holding Times	Collection Date(s):	Analysis Date(s)	Holding Time Met (Y/N)	Affected Data Flagged (Y/N)

Were any data flagged because of holding time? Y  N   
 Were any data flagged because of preservation problems? Y  N   
 Describe Any Actions Taken:  
 Comments:

**2. Blanks**

Were Method Blanks (MBs) analyzed at the frequency of 1 per analytical batch? Y  N   
 Were MBs within the control window? Y  N   
 Were any data flagged because of blank problems? Y  N   
 Describe Any Actions Taken:  
 Comments:

**3. Laboratory Control Samples**

Were Laboratory Control Samples (LCS) analyzed at the frequency of 1 per batch? Y  N   
 Were LCS results within the control window? Y  N   
 Were any data flagged because of LCS problems? Y  N   
 Describe Any Actions Taken:  
 Comments:

**4. Duplicate Sample Results**

Were Laboratory Duplicate Samples (LDS) analyzed at the frequency of 1 per batch? Y  N   
 Were LDS results within the control window? Y  N   
 Were any data flagged because of LDS problems? Y  N   
 Describe Any Actions Taken: None required  
 Comments:

**5. Matrix Spike Sample Results**

Were Laboratory Matrix Spike Samples (LMS) analyzed at the frequency of 1 per batch? Y  N   
 Were LMS results within the control window? Y  N   
 Were any data flagged because of LMS problems? Y  N   
 Describe Any Actions Taken: None required  
 Comments:



**6. Field Blanks**

Were field blanks submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were field blanks within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were any data qualified because of field blank problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Describe Any Actions Taken:						
Comments:						

**7. Field Duplicates**

Were field duplicates submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were results for field duplicates within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Were any data qualified because of field duplicate problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A	<input type="checkbox"/>
Describe Any Actions Taken:						
Comments:						

**8. Overall Assessment**

Are there analytical limitations of the data that users should be aware of?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>
If so, explain:				
Comments:				

**9. Authorization of Data Validation**

Data Validator <b>Name:</b> _____  <b>Signature:</b> _____  <b>Date:</b> _____	<b>Reviewed by:</b> _____  _____  _____
---	---

**Site:**  
**Project:**  
**Sample Date(s):**  
**Data Validator:**

**Case No:**  
**Sample Matrix:**  
**Analysis Date(s):**  
**Validation Date(s):**

**Laboratory:**  
**Analyses:**

**1. Holding Times**

Analyte	Laboratory	Matrix	Method	Holding Times	Collection Date	Prep Date	Analysis Date(s)	Holding Time Met (Y/N)	Affected Data Flagged (Y/N)
<p>Were any data flagged because of holding time? <span style="float: right;">Y <input type="checkbox"/> N <input type="checkbox"/></span></p> <p>Were any data flagged because of preservation problems? <span style="float: right;">Y <input type="checkbox"/> N <input type="checkbox"/></span></p> <p>Describe Any Actions Taken:</p> <p>Comments:</p>									

**2. Blanks**

Were Method Blanks (MBs) analyzed at the frequency of 1 per analytical batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were MBs within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of blank problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**3. Surrogates**

Were surrogates present in all extracted samples (including QC)?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were surrogate recoveries within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of surrogate problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Take:		
Comments:		

**4. Laboratory Control Samples**

Were Laboratory Control Samples (LCS) analyzed at the frequency of 1 per batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
What was the source of the LCS?	Unknown	
Were LCS results within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of LCS problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**5. Duplicate Sample Results**

Were Laboratory Duplicate Samples (LDS) analyzed at the frequency of 1 per batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were LDS results within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of LDS problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**6. Matrix Spike Sample Results**

Were Laboratory Matrix Spike Samples (LMS) analyzed at the frequency of 1 per batch?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Were LMS % Recovery (%R) results within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Were any data flagged because of LMS problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Describe Any Actions Taken:					
Comments:					

**7. Field Blanks**

Were field blanks submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Were field blanks within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Were any data qualified because of field blank problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Describe Any Actions Taken:					
Comments:					

**8. Field Duplicates**

Were field duplicates submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input checked="" type="checkbox"/>	N	<input type="checkbox"/>	
Were the field duplicates within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Were any data qualified because of field duplicate problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Describe Any Actions Taken:                      None required					
Comments:					

**9. Overall Assessment**

Are there analytical limitations of the data that users should be aware of?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
If so, explain:					
Comments:					

**10. Authorization of Data Validation**

Data Validator <b>Name:</b> _____	<b>Reviewed by:</b> _____
<b>Signature:</b> _____	_____
<b>Date:</b> _____	_____

**Site:**  
**Project:**  
**Sample Date(s):**  
**Data Validator:**

**Case No:**  
**Sample Matrix:**  
**Analysis Date(s):**  
**Validation Date(s):**

**Laboratory:**  
**Analyses:**

**1. Holding Times**

Analyte	Laboratory	Matrix	Method	Holding Times	Collection Date	Prep Date	Analysis Date(s)	Holding Time Met (Y/N)	Affected Data Flagged (Y/N)
<p>Were any data flagged because of holding time? <span style="float: right;">Y <input type="checkbox"/> N <input type="checkbox"/></span></p> <p>Were any data flagged because of preservation problems? <span style="float: right;">Y <input type="checkbox"/> N <input type="checkbox"/></span></p> <p>Describe Any Actions Taken:</p> <p>Comments:</p>									

**2. Blanks**

Were Method Blanks (MBs) analyzed at the frequency of 1 per analytical batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were MBs within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of blank problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**3. Surrogates**

Were surrogates present in all extracted samples (including QC)?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were surrogate recoveries within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of surrogate problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Take:		
Comments:		

**4. Laboratory Control Samples**

Were Laboratory Control Samples (LCS) analyzed at the frequency of 1 per batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
What was the source of the LCS?	Unknown	
Were LCS results within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of LCS problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**5. Duplicate Sample Results**

Were Laboratory Duplicate Samples (LDS) analyzed at the frequency of 1 per batch?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were LDS results within the control window?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Were any data flagged because of LDS problems?	Y <input type="checkbox"/>	N <input type="checkbox"/>
Describe Any Actions Taken:		
Comments:		

**6. Matrix Spike Sample Results**

Were Laboratory Matrix Spike Samples (LMS) analyzed at the frequency of 1 per batch?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Were LMS % Recovery (%R) results within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Were any data flagged because of LMS problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Describe Any Actions Taken:					
Comments:					

**7. Field Blanks**

Were field blanks submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
Were field blanks within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Were any data qualified because of field blank problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Describe Any Actions Taken:					
Comments:					

**8. Field Duplicates**

Were field duplicates submitted as specified in the Sampling Analysis Plan (SAP)?	Y	<input checked="" type="checkbox"/>	N	<input type="checkbox"/>	
Were the field duplicates within the control window?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Were any data qualified because of field duplicate problems?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	N/A <input type="checkbox"/>
Describe Any Actions Taken:                      None required					
Comments:					

**9. Overall Assessment**

Are there analytical limitations of the data that users should be aware of?	Y	<input type="checkbox"/>	N	<input type="checkbox"/>	
If so, explain:					
Comments:					

**10. Authorization of Data Validation**

Data Validator	
<b>Name:</b> _____	<b>Reviewed by:</b> _____
<b>Signature:</b> _____	
<b>Date:</b> _____	_____